

MONOCOQUE

Sheet 1 of 3

Issue	Signature
2	R. S. ...
3	R. S. ...

		SECTION		
Item	Part No	DRG No.	No. Off	Detail
1	<u>MONOCOQUE ASSEMBLY</u>	38-1-8	792-01-42	1
	- COMPRIZES OF CASTINGS AND SUB ASSEMBLIES			
2	FRONT BULKHEAD	45-11-1	792-01-14	1
3	M.F.B.H. - R.H.	4-84-10	792-01-12	1
4	" - L.H.	4-84-11	792-01-13	1
5	FRONT CRASH HOOP	45-10-13	792-01-58	1
6	REAR CRASH HOOP	3-59-15	792-01-17	1
7	FRONT BULKHEAD BEAM	4-85-8	792-01-18	1
8	REAR BULKHEAD - R.H.	4-84-12	792-01-10	1
9	REAR BULKHEAD - L.H.	4-84-13	792-01-11	1
10	OIL TANK MOUNT R.H.	3-60-12	792-01-66	1
11	" " " L.H.	3-60-13	792-01-67	1
12	ACCESS CLOSURE PLATE	3-61-3	792-01-77	2
13	TUB STIFFENER R.H.	3-62-10	792-01-96	1
14	TUB STIFFENER L.H.	3-62-11	792-01-97	1
15	DASH PANEL	3-48-4	782-01-21	1
16	DASH PANEL MOUNTING HUBBER	8-20-4	FD 8-20-4	3
17	FRONT SKID	4-87-6	792-01-84	2
18	REAR SKID	4-83-11	782-01-150	2
19	STEERING WHEEL	8-1-3	742-04-02	1
20	STEERING WHEEL RETAINING WASHER	4-2-4	712-04-07	1
21	STEERING WHEEL NUT (STEEL)	8-1-4	FD 7	3
22	STEERING COLUMN	3-59-10	792-04-09	1
23	STEERING COLUMN SUPPORT	4-2-2	732-05-05	1
24	STEERING RACK CLAMP	4-7-15	792-04-01	2
25	<u>GEAR LEVER ASSEMBLY</u>		782-11-07	1
	COMPRIZES:			
26	GEAR LEVER	49-1-2	782-11-08	1
27	GEAR LEVER BADGE	8-6-10	752-11-05	1
28	GEAR CHANGE BRACKET		792-11-01	1
29	GEAR LEVER PIVOT	4-5-2	712-11-10	1
30	GEAR LEVER SPACER	4-27-3	762-11-06	2
31	GEAR SHAFT	4-76-5	782-11-04	1
32	GEAR BOX MOUNTING	49-1-1	782-11-05	1
33	GEAR CHANGE BODY	4-79-1	782-11-03	1
34	GEAR CHANGE BEARING RING	4-77-1	782-11-00	1

MEMORANDUM

SHEET 2 of 3

Issue	Signature	Date
2	R. S. ...	23-1-79
3	R. S. ...	31-1-79
4	R. S. ...	12-2-79

SECTION

Item	Part No	DRG No.	No. Off	Detail
35	PONTOON CLOSURE PLATE	3-62-12	792-01-121	2
36	CHASSIS PLATE	8-4-4	732-01-48	1
37	LEFT FOOT REST	3-49-3	782-01-54	1
38	F.T.W.B. STEEL BAR	3-59-9	792-01-43	2
39	FRONT SUSPENSION EAR L.H.	4-85-9	792-01-15	1
40	" " " R.H.	4-85-10	792-01-16	1
41	P.B.W.B. D.S. PLATE	3-60-14	792-01-68	2
42	FUEL TANK BAY CRUSHABLE (BOTTOM)			1
43	THROTTLE CABLE CLAMP BRACKET (FRONT)	3-62-5	792-01-87	1
44	<u>FIRE EXTINGUISHING SYSTEM</u>	<u>29-3-11</u>	<u>TD 29-3-11</u>	1
	COMPRIZES:			
45	5 KG. BOTTLE, HEAD	29-3-15	TD 29-3-15	1
46	5 KG. BOTTLE BRACKET & STRAPS	29-4-2	TD 29-4-2	1
47	PURPLE FLEXIBLE PIPE	29-4-5	TD 29-4-5	1
48	COCKPIT NOZZLE	4-44-4	763-22-01	1
49	COCKPIT NOZZLE LOCKNUT	13-7-1	763-22-02	1
50	2.5 KG. BOTTLE & HEAD & STRAPS	29-4-1	TD 29-4-1	1
51	2.5 KG. BOTTLE BRACKET	3-63-1	792-01-122	1
52	PIPE 2.5 KG BOTTLE TO REAR B.H.	7-8-4	TD 7-8-4	5
53	LIFE SUPPORT BOTTLE & STRAPS	29-3-14	TD 29-3-14	1
54	LIFE SUPPORT BOTTLE BRACKET	3-62-4	792-01-20	1
55	LIFE SUPPORT TUBE	29-3-0	TD 29-3-0	3
56	BATTERY POWER PACK	29-4-4	TD 29-4-4	1
57	SEAT BELT	8-1-11	TD 10	1
58	SEAT BELT PLATE-JOGGLED	2-1-2	722-01-75	2
59	SEAT BELT BACKING PLATE	3-48-14	782-01-48	2
60	GEAR SHIFT SUPPORT	3-62-14	792-16-16	1
61	THROTTLE CABLE BRACKET (REAR)	3-62-6	792-01-88	1
62	NOSE FRAME MOUNTING R.H.	3-62-14	792-01-94	1
63	" " " " L.H.	3-62-13	792-01-93	1
64	NOSE FRAME MOUNTING SPACER LONG	41-34-2	792-20-47	2
65	" " " " SHORT	41-34-1	792-20-46	2
66	NOSE FRAME SUPPORT BRACKET	3-38-12	792-01-80	2
67	" " " " SPACER	41-34-3	792-20-48	2
68	PEDAL STOPS SUPPORT	3-63-12	792-01-433	1

(MODIFIED)

MONOCOQUE - 792

Sheet 3 of 3

Issue	Signature	Date
1	<i>E. S. Taylor</i>	12-2-74

SECTION

Item	Part No	DRG No.	No. Off	Detail
69 SEAT BELT TOP MOUNTING	3-63-10	792-01-132	4	
70 " " " " SPACER	41-33-14	792-20-44	2	
71 FUEL TANK BAY CRUSHABLE - SIDE L.H.			1	
72 " " " " " R.H.			1	
73 PONTOON CRUSHABLE R.H.			1	
74 " " L.H.			1	
75 TOP FLOOR STIFFENER	3-62-15	792-01-124	1	
76 GEAR SHIFT SUPPORT CIRCLIP	23-5-2	TD 23-5-2	2	

FRONT SUSPENSION - 792

SECRET 1 of 2

Issue	Signature	Date

SECTION B 25

Item	Part No	DRG No.	No. Off	Detail
1	FRONT ROCKER	32-4-5	792-02-05	2
2	ROCKER OUTER JOINT INSERT	4-63-8	792-02-02	4
3	" " " CIRCLIP	23-5-12	TD 23-5-12	2
4	" THRUST WASHER	41-32-13	792-20-28	4
5	" BUSH	44-1-8	792-19-01	4
6	" JOURNAL	4-63-7	792-02-16	2
7	" THROUGH BOLT	12-24-7	792-02-15	2
8	" /F.A.R.B. BOLT	4-63-9	792-02-10	2
9	" /DAMPER INSERT - MALE	4-63-10	792-02-13	2
10	" / " " - FEMALE	4-63-11	792-02-14	2
11	" / " " BOLT	12-14-3	792-02-09	2
12	F.B.W.B.	32-4-3	792-02-06	2 <i>see 792-02-27</i>
13	" THRUST WASHER	4-2-6	722-02-08	16
14	" BUSH	4-6-12	72G-02-08	8
15	" SHIM	41-31-4	792-20-04	2
16	" LONG SPACER	41-31-3	792-20-03	2
17	" JOURNAL	4-2-5	732-02-07	4
18	" THROUGH BOLT	4-80-14	792-02-17	2 (722-02-12)
19	"			
	<u>STEERING RACK ASSEMBLY COMPRISES:</u>			1
20	RACK	4-63-12	792-04-03	1
21	HOUSING	4-63-13	792-04-04	1
22	PINION	8-23-2	TD 8-23-2	1 7 TOOTH
23	PINION BEARING	8-1-6	TD 28	2
24	PINION BEARING SHIM	8-17-5	TD 8-17-5	A.R.
25	" " CLAMP RING	4-45-11	712-04-24	1
26	END PLATE	8-17-4	TD 8-17-4	1
27	" " CIRCLIP	8-17-3	TD 8-17-3	1
28	SPRING	4-4-9	712-04-21	1
29	" STOP	4-4-10	712-04-22	1
30	" RETAINER	4-4-11	712-04-23	1
31	TENSION CAP	4-4-8	712-04-19	1
32	OILITE BUSH	8-18-5	TD 8-18-5	2
33	SEAL	8-9-6-	TD 1022	2
34	PINION SEAL (J. K. 6000 42C)			

FRONT SUSPENSION - 792
 SHEET 2 of 2

Issue	Signature	Date
2	P. Sauter	23-1-7

SECTION B 25

Item	Part No	DRG No.	No. of	Detail
24 INNER CLEVIS	4-26-2	762-04-06	2	
25 " " LOCK NUT	13-2-14	762-04-07	2	
26 TRACK ROD	3-21-7	792-04-08	2	
27 RACK STOPS	4-35-11	792-04-10	2	
28 BUMP STEER SPACER - LARGE	41-33-1	792-20-31	2	
29 " " " - SMALL	41-33-2	792-20-32	2	
40 P.A.R.B.	40-5-2	792-05-27	1	9/16" O/D x 7/16
41 " MOUNTING BLOCK	4-77-13	792-05-22	2	
42 " LINK	4-77-10	792-05-14	2	
43 " ARM	4-77-14	792-05-05	2	
44 P.A.R.B. BLOCK STUD SHORT	4-35-12	792-01-82	2	
45 " " " LONG	4-35-13	792-01-83	2	
46 FRONT SPRING (600 lb)	16-4-11	TD 16-4-11	2	6" LONG
47 FRONT DAMPER	16-2-11	TD 16-2-11	2	KONI = 1401 B 15
48 FRONT DAMPER INSERT (BOTTOM)	4-2-12	712-02-09	4	
49 P.A.R.B. ARM JOINT SPACER	41-33-8	792-20-38	4	
50 FRONT TOP ROCKER SPACER	41-33-9	792-20-39	2	
51 FRONT DAMPER CUT DOWN SOFT ABRN			2	

REAR SUSPENSION - 792

Issue	Signature	Date
2	<i>[Signature]</i>	25-1-79

SECTION

Item	Part No	DRG No.	No. Off	Detail
1 RADIUS ARM (STEEL)	37-2-6	792-03-21	2	27.62"
2 RADIUS ARM FORWARD SAFETY WASHER	4-15-13	73B-18-01	4	
3 TOP LINK	4-77-11	792-03-06	2	
4 BOTTOM LINK	4-77-12	792-03-07	2	
5 R.B.W.B	22-4-4	792-03-04	2	
6 R.B.W.B. OUTER JOINT SPACER	4-8-15	712-03-20	4	
7 R.B.W.B OUTER JOINT CIRCLIP	23-5-10	TD 23-5-10	2	
8 R.B.W.B. OUTER JOINT SHIM	41-32-7	708-16-03		.055-.057
9 R.B.W.B. " " "	41-32-8	708-16-03		.060-.062
10 " " " " "	41-32-8	708-16-03		.065-.067
11 " " " " "	41-32-9	708-16-03		.070-.072
12 " " " " "	41-32-10	708-16-03		.075-.077
13 " BEARING JOURNAL	4-24-5	792-03-01	2	
14 " THROUGH BOLT	12-24-1	79B-01-17	2	
15 " INNER BEARING BEARING	44-12-10	792-19-07	4	
16 " THRUST WASHER	41-32-6	708-16-03	8	
17 C.S.D.U. ROD	42-1-10	792-03-18	2	
18 REAR CROSS MEMBER	4-84-14	792-01-44	1	
19 R X M PLATE FRONT R.H.	3-24-7	792-01-38	1	
20 " " " L.H.	3-24-8	792-01-39	1	
21 " " BEAR R.H.	3-24-5	792-01-36	1	
22 " " " L.H.	3-24-6	792-01-37	1	
23 TOP LINK MOUNTING L.H. (INBOARD)	4-80-11	792-01-41	1	
24 " " " R.H. "	4-80-12	792-01-40	1	
25 LINK ANCHOR PLATE	4-85-7	792-01-31	1	
26 " " " STUDS	4-30-10	762-01-107	4	
27 REAR ROCKER	32-4-6	792-03-12	2	
28				
29 REAR ROCKER INNER DELRIN	4-6-12	726-02-08	4	
30 REAR ROCKER INNER THRUST WASHER	41-33-6	792-20-36	4	
31 REAR ROCKER JOURNAL BEARING	4-35-9	792-03-20	2	
32 REAR ROCKER THROUGH BOLT	4-35-10	792-16-01	2	
33 REAR ROCKER D.S. BRACKET	3-59-21	792-01-33	2	

REAR SUSPENSION

Sheet 2 of 2

Issue	Signature	Date
2		23-7-79
3		25-1-79
4		1-2-79

Item	Part No	DRG No.	SECTION		Detail
			No.	Qty.	
34 REAR SKID ^{LAF} ^{WIT} 1/2	4-64-5	772-01-25	2		
35 REAR SKID SUPPORT 1-0	4-58-6	772-01-27	2		
36 REAR SKID SUPPORT STUD	4-59-5	772-01-26	2		
37 DAMPER	16-2-12	ED 16-2-12	2		KONI 1406
38 DAMPER INSERT (STEEL)	4-61-8	771-03-22	4		
39 REAR SPRING (800 lb)	16-4-12	ED 16-4-12	2		7" LONG
40 REAR HELPER SPRING	16-5-10	ED 16-5-10	2		
41 REAR ANTI ROLL BAR	40-5-6	792-05-21	1		3/4" 18 S.W.G.
42 REAR ANTI ROLL BAR MOUNTING BLOCK	4-67-3	792-05-20	2		
43 REAR ANTI ROLL BAR ADJUSTING SCREW	2-02-11	792-05-31	2		
44 REAR ANTI ROLL BAR LINK	4-86-7	792-05-28	2		9 1/2" LONG
45 TOP LINK SPACER	4-82-0	792-03-14	4		
46 RADIUS ROD SAFETY WASHER REAR	4-82-10	792-03-15	4		
47 R.X.M. SPACER.	4-31-8	768-01-13	2		3/4" LONG

FRONT AND REAR UPRIGHTS

Issue	Signature	Date

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1	<u>FRONT UPRIGHT ASSEMBLY</u>		2	
	<u>EACH ASSEMBLY COMPRISES OF:</u>			
2	UPRIGHT	4-86-2	792-06-03	1
3	AXLE	4-27-7	751-06-01	
4	AXLE DRIVE PIN	4-1-9	711-07-04	3
5	WHEEL BEARING	8-1-5	TD 1	2
6	BEARING SPACER	4-4-5	711-06-07	1
7	OUTER SPACER	4-1-13	711-07-05	1
8	WHEEL STUD ASSEMBLY	3-58-4	792-06-02	1
9	WHEEL STUD SPIROL PIN	8-1-7	TD 154	2
10	BRAKE DISC	7-1-5	TD 116	1
11	BRAKE DISC BEEL	4-5-5	732-06-17	1
12	BOTTOM SWIVEL PIN	4-73-7	782-06-09	1
13	BOTTOM SWIVEL PIN SPACER	41-33-3	792-20-33	1
14	BOTTOM SWIVEL PIN WASHER	41-1-10	782-20-10	1
15	UPRIGHT CLEVIS (STEERING) STRAIGHT	4-63-14	792-04-05	1
16	FRONT WHEEL	18-5-8	782-09-09	1
17	WHEEL WASHER	4-52-2	771-09-01	1
18	WHEEL WASHER INSERT	4-6-11	712-07-11	1
19	<u>REAR UPRIGHT ASSEMBLY</u>		2	
	<u>EACH ASSEMBLY COMPRISES OF:</u>			
20	UPRIGHT	4-74-9	792-07-09	1
21	REAR AXLE	4-23-25	792-07-05	1
22	REAR AXLE DRIVE PIN	4-1-9	711-07-04	6
23	TOP LINK MOUNTING (OUTER) R.H.	3-24-14	792-01-34	1
24	TOP LINK MOUNTING (INNER) L.H.	3-24-15	792-01-35	1
25	BOTTOM D.S. PLATE	3-59-6	792-07-01	2
26	REAR WHEEL BEARING	8-22-5	TD 8-22-5	1
27	<u>REAR WHEEL ASSEMBLY (COMPOSITE)</u>			2
				5 1/2" INSET
28	HUB	19-1-10	732-09-10	1
29	CLAMPING RING	4-34-14	752-09-01	1
30	O - RING	8-3-10	TD 191	2
31	OUTER RIM			1
32	INNER RIM			1
33	WHEEL WASHER	4-52-2	771-09-01	1
34	WHEEL WASHER INSERT	4-6-11	712-07-11	1

PEDALS - 792

Issue	Signature	Date
2	R. Sautage	23-1-79
3	R. Sautage	12-1-79

SECTION E 9

Item	Part No	DRG No.	No. Off	Detail
1 <u>CLUTCH PEDAL ASSEMBLY</u>			1	
<u>COMPRISES:</u>				
2 CLUTCH PEDAL	3-24-10	792-08-02	1	
3 CLUTCH PEDAL PIVOT BEARING	8-1-10	TD 126	2	06 DU 08
4 CLUTCH PEDAL CLEVIS BEARING	8-18-1	TD 8-18-1	1	
5 CLUTCH CLEVIS	4-26-11	771-08-04	1	
6 CLUTCH CLEVIS PIN	4-56-14	771-08-09	1	
7 <u>BRAKE PEDAL ASSEMBLY</u>			1	
<u>COMPRISES:</u>				
8 BRAKE PEDAL	3-24-9	792-08-01	1	
9 BRAKE PEDAL PIVOT BEARING	8-1-10	TD 126	2	06 DU 08
10 BRAKE PEDAL PIVOT BUSH	4-5-11	712-08-07	1	
11 BALANCE BAR SHAFT	4-87-1	771-08-12	1	
12 BALANCE BAR YOKE	4-5-14	703-08-01	2	
13 BALANCE BAR YOKE INSERT	4-5-13	703-08-03	2	
14 BALANCE BAR NUT	4-6-1-	703-08-02	2	
15 <u>THROTTLE PEDAL ASSEMBLY</u>			1	
<u>COMPRISES:</u>				
16 THROTTLE PEDAL	3-24-11	792-08-03	1	
17 THROTTLE PEDAL PIVOT BEARING	8-1-10	TD 126	2	06 DU 08
18 THROTTLE PEDAL PIVOT BUSH	4-5-11	712-08-07	1	
19 CLUTCH STOP/ ADJUSTER	4-59-15	782-01-56	1	
20 CLUTCH PEDAL BUFFER RUBBER	8-16-11	TD 8-16-11	1	
21 CLUTCH PEDAL BUFFER SUPPORT	4-64-15	771-01-81	1	
22 THROTTLE STOP			1	

ENGINE INSTALATION KIT - 792 BMW

Issue	Signature	Date
2	R. Santiago	21-1-

SECTION

Item	Part No	DRG No.	No. Off	Detail
1	ENGINE (SUPPLIED BY CUSTOMER)		1	
2	ENGINE SIDEFRAME	36-2-14	792-01-45	2
3	SIDEFRAME BOLT - LONG	4-86-10	792-01-28	2
4	SIDEFRAME BOLT - SHORT	4-86-9	792-01-27	4
5	ENGINE MOUNT RING	4-86-3	792-01-26	1
6	CLEVIS	4-80-15	792-01-29	
7	SIDEFRAME BOLT - MEDIUM	4-86-11	792-01-74	2
8	ADAPTOR PLATE	4-63-15	792-16-04	1
9	ADAPTOR PLATE DOWEL	4-15-1	742-16-07	2
10	ADAPTOR PLATE STUD	4-14-6	74B-16-01	5
11	STARTER MOTOR (SUPPLIED WITH ENGINE)	9-6-2	TD 911	1 BOSCH
12	FLYWHEEL STONEGUARD	1-1-13	735-16-05	1
13	EXHAUST SYSTEM	24-3-6	TD 24-3-6	1
14	EXHAUST BRACKET	3-34-8		1
15	EXHAUST BRACKET METALISTIC BUSH			2
16	TACHOMETER	34-1-1	TD 958	1
17	TACHOMETER FLEXIBLE DRIVE	8-3-3	TD 64	1
18	<u>OIL PRESSURE LINE ASSEMBLY COMPRISES:</u>			1
19	HOSE	8-8-5	TD 542	
20	90° UNION	3-30-7	76B-13-08	2
21	90° " NUT	8-22-4	TD 541	2
22	PRESSURE TAKE OFF	4-80-2	762-16-19	1
23	DOWTY WASHER	20-3-3	TD 1024	2
24	GAUGE (OIL PRESSURE/OIL TEMP)	8-9-9	TD 68	1
25	<u>FUEL PRESSURE LINE ASSEMBLY COMPRISES:</u>			1
26	HOSE	8-8-5	TD 542	
27	90° UNION	3-30-7	76B-13-08	2
28	90° " NUT	8-22-4	TD 541	2
29	GAUGE (FUEL PRESSURE/WATER TEMP)	34-1-14	TD 34-1-14	1 8 FT LONG
30	AIRBOX	11-8-15	782-12-43	1
31	AIRBOX BASE	3-35-8	782-01-96	1
32	AIRBOXE BASE CLAMP	3-18-9	752-01-110	2
33	AIRBOX STONEGUARD	2-10-5	782-12-19	1
34	AIRBOX BASE SEALING RING	35-2-1	782-01-51	4
35	CLUTCH (SUPPLIED WITH ENGINE)	7-12-1	TD 7-12-1	1

ENGINE INSTALATION KIT - 792 BMW

Issue	Signature	Date

SECTION

Item	Part No	DRG No.	No. Off.	Detail	
36	THROTTLE CABLE	8-17-10	TDS-17-10	1	2 metres
37	THROTTLE CABLE CLAMP	8-16-14	TD 8-16-14	2	
38	THROTTLE CABLE CONNECTOR	4-45-6	762-16-42	1	
39	THROTTLE CABLE CLAMP SPACER	3-36-14	772-01-06	2	

Issue	Signature	Date
2	R. S. ...	12.7.7

SECTION					
Item	Part No	DRG No.	No. Off	Detail	
1	<u>GEARBOX ASSEMBLY COMPRISES:</u>				
2	GEARBOX	18-3-3	TD 18-3-3	1	HEWLAND FT 200
3	MAIN CASE MODS	4-62-12	782-16-24		
4	<u>GEARBOX OIL SYSTEM</u>				
5	OIL PUMP ASSEMBLY	18-10-12	TD 18-10-12		
6	OUTLET BANJO	4-62-14	772-14-04	1	
7	OUTLET BANJO BOLT	4-62-15	772-14-05	1	
8	OUTLET ADAPTOR	4-8-13	752-15-10	1	-6/-6
9	OUTLET UNION	21-1-7	TD 299	1	-6 STRAIGHT
10	HOSE - OUTLET TO PUMP	21-2-9	TD 292		-6
11	PUMP INLET UNION	21-1-9	TD 313	1	-6 x90
12	PUMP INLET ADAPTOR	4-32-8	751-14-06	1	-6/3/8" BSP
13	PUMP INLET ADAPTOR SEAL	20-3-8	TD20-3-8	1	3/8" BSP DOWTY
14	FILTER ELEMENT	8-13-9	TD 8-13-9	1	
15	FILTER SPACER	4-55-5	771-14-12	1	
16	FILTER WASHER	4-61-6	771-16-38	1	
17	FILTER SPINDLE	4-54-11	771-16-16	1	
18	FILTER SPRING	16-6-2	771-16-39	1	
19	FILTER O - RING	8-21-1	TD 8-21-1	1	
20	FILTER O - RING	8-14-10	TD 8-14-10	1	
21	FILTER BRACKET	3-52-8	782-16-07	1	
22	FILTER OUTLET ADAPTOR	4-43-5	771-16-17	1	
23	FILTER OUTLET UNION	21-1-9	TD 313	1	-6 x 90
24	HOSE -. FILTER TO MAIN CASE	21-2-9	TD 292		-6
25	MAIN CASE INLET UNION	21-1-7	TD 299	1	-6 x STRAIGHT
26	MAIN CASE INLET ADAPTOR	4-87-13	792-16-10	1	-1/-6
27	SPRAY TUBE	4-62-13	772-14-03	1	
28	5/8" BSP DOWTY SEAL	20-3-2	TD 1023	3	
29	9/16" 1/D DOWTY SEAL	20-3-3	TD 1024	2	
30	FILTER TUBE	4-81-13	782-16-21	1	
31	END COVER	4-69-9	782-16-01	1	
32	FILTER ASSY-DWG (SERIES 3 ONWARDS)		782-16-22	1	
33	CLUTCH SHAFT	18-17-2	TD 18-17-2	1	
34	CLUTCH BOBBIN	4-48-5	782-10-05	1	
35	CLUTCH BOBBIN SPIGOT	18-10-14	TD18-10-14	1	
36	CLUTCH RELEASE BEARING	18-2-9	TD 26	1	

Issue	Signature	Date
2	R. Santiago	12-1-7
3	R. Santiago	12-7-7

Sheet 2 of 3

SECTION

Item	Part No	DRG No.	No. Off	Detail
37	EXHAUST BRACKET STUD		2	
38	<u>DRIVESHAFT ASSEMBLY COMPRISES:</u>		2	
39	PLUNGE JOINT HOUSING	14-2-9	782-10-03	1
40	PLUNGE JOINT HOUSING BOLT	12-13-8	TD 591	6
41	PLUNGE JOINT CAGE	14-1-7	TD 176	1
42	PLUNGE JOINT BALL	14-1-8	TD 175	6
43	PLUNGE JOINT INNER TRACK	14-1-6	TD 179	1
44	PLUNGE JOINT GAITER W	14-2-11	TD 14-2-11	1
45	DRIVESHAFT INNER CIRCLIP	8-1-9	TD 174	1
46	DRIVESHAFT	4-29-10	792-10-01	1
47	DRIVESHAFT OUTER CIRCLIP	23-5-5	TD 23-5-5	1
48	PLUNGE JOINT GREASE	26-4-15	TD 26-4-15	
49	DRIVESHAFT YOKE	14-2-4	741-10-08	1
50	AXLE YOKE	14-2-1	741-10-02	1
51	CENTRE CROSS	14-2-2	TD 192	1
52	AXLE YOKE THRUST RING	4-18-13	741-10-03	1
53	WHEEL RETAINING STUD	4-75-12	792-07-06	1
54	FRONT GEAR ROD	3-27-7	78B-11-01	1
55	MIDDLE GEAR ROD	3-27-11	792-11-02	1
56	REAR GEAR ROD	3-27-12	792-11-03	1
57	<u>TWIN POT CALIPER REAR BRAKE KIT COMPRISES:</u>			
58	GEARBOX SIDEPLATE L.H.	4-74-1	772-16-07	1
59	GEARBOX SIDEPLATE R.H.	4-74-2	772-16-08	1
60	SIDEPLATE STUD	4-75-1	772-18-09	2
61	SIDEPLATE STUD	4-75-2	772-18-09	8
62	SIDEPLATE STUD	4-75-3	772-18-09	2
63	SIDEPLATE STUD	4-75-4	772-18-09	2
64	SIDEPLATE STUD	4-75-5	772-18-09	2
65	SIDEPLATE STUD	4-75-6	772-18-09	2
66	OUTPUT FLANGE	4-79-12	772-16-10	2
67	OUTPUT FLANGE SEAL	18-7-2	TD 18-7-2	2
68	OUTPUT FLANGE CIRCLIP	18-9-2	TD 18-9-2	2
69	SIDEPLATE BEARING	8-20-8	TD 8-20-8	2
70	BEARING SPACER L.H.	4-79-13	772-16-11	1
71	BEARING SPACER R.H.	4-79-14	772-16-12	1

TRANSMISSION - 792 BMW

Sheet 3 of 3

Issue	Signature	Date
2	R. Sautter	13-1-7
3	R. Sautter	21-1-7

SECTION

Item	Part No	DRG No.	No. Off	Detail
72	DISC (SOLID OPTION)	7-6-10	773-10-04	2
73	DISC (VENTED)	7-1-5	TD 116	2
74	DISC BELL (FOR VENTED)	4-66-5	772-10-02	2
75	<u>CALIPERS:</u> see Hydraulics			
76	SLAVE CYLINDER MOUNTING BRACKET	3-45-6	77B-16-12	1
77	GEARBOX INLET BANJO BOLT	4-87-14	792-16-11	1

13/16" THICK

OIL SYSTEM - 792 BMW

Issue	Signature	Date
2	R. Santiago	23-1-7
3	R. Santiago	25-1-
4	R. Santiago	5-3-7

SECTION

Item	Part No	DRG No.	No. Off	Detail
1	<u>OIL TANK ASSEMBLY COMPRISES:</u>			
2	3-24-4	792-14-04	1	
3	4-33-3	762-14-04	1	
4	20-3-10	TD 20-3-10	1	1" BSP DOWTY
5	4-33-13	762-14-23	1	
6	20-3-4	TD 1025	1	1" I.D. DOWTY
7	4-20-1	722-18-11	1	
8	8-8-9	TD 70	1	
9	23-3-7	TD 1033		
10	<u>ENGINE OIL SYSTEM COMPRISES:</u>			
11	21-3-13	TD21-3-13	1	-16 180
12	21-2-13	TD 296		-16
13	21-2-6	TD 317	1	-16 90
14	4-12-5	752-14-03	1	-16/Metric
15	4-12-4	732-14-02	1	-16/ "
16	8-11-12	TD 8-11-12	1	
17	21-3-13	TD21-3-13	1	-16 180
18	21-2-13	TD 296		-16
19	21-2-6	TD 317	1	-16 90
20	8-11-8	TD 8-11-8	1	-16 16 ROW
21	3-61-14	792-01-78	1	
22	21-2-6	TD 317	1	-16 90
23	21-2-13	TD 296		-16
24	21-2-6	TD 317	1	-16 90
25			1	
26	8-7-10	TD 748		5/8" I.D. RUBBER
27	8-7-15	TD 741		1/8" I.D. PLASTI
28			1	
29	11-9-15	792-14-07	1	
30	3-61-2	792-14-05	1	-16
31	20-3-10	TD 20-3-10		1" BSP
32	3-62-15	792-14-06	1	
33	3-64-6	792-01-143	1	
34	3-64-5	792-01-142	1	

WATER SYSTEM 792 BMW

FIELD DRAWING

Issue	Signature	Date

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1 RADIATOR	27-4-11	792-13-01	1	
2 WATER PIPE (CROSSOVER)	3-55-6	792-13-05	1	
3 HEADER TANK BRACKET	3-63-13	792-01-134	1	
4 SWIRL POT	3-66-1	792-13-10	1	
5 HEADER TANK	3-29-14	792-13-04	1	
6 RADIATOR BLEED CAP	4-8-11	763-13-10	1	
7 FILLER CAP	8-6-11	TD 62	1	
8 PIPE FRONT	3-55-8		2	
9 PIPE SIDE	3-55-5	792-13-03	1	
10 PIPE REAR	3-55-7	792-13-06	1	
11 PIPE SIDE	3-55-4	792-13-02	1	HAS TEMP TAKE
12 CYLINDER HEAD BLEED ADAPTOR	4-15-2	75S-13-07	1	
13 RUBBER HOSE - 5/8" I.D.	8-7-10	TD 748	2	
14 RUBBER HOSE - 1" I.D.	8-7-2	TD 751	2"	
15 RUBBER HOSE - 1 1/4" I.D.	8-4-7	TD 753	6"	
16 90 RUBBER HOSE	8-6-12	TD 22	3	
17 RUBBER HOSE - PUMP INLET	8-20-13	TD8-20-13	1	
18 5/16" I.D. PLASTIC HOSE	8-12-8	TD 742	2'	
19 NYLON BLEED PIPE - 5/32" I.D.	8-8-5	TD 542	100'	
20 1/8" BSP STRAIGHT UNION	8-5-12	TD 741	1	
21				
22				
23 1/8" BSP 90 UNION	3-30-7	76B-13-08		

FUEL SYSTEM - 792 BMW

Issue	Signature	Date
2	R. Soutage	73-1-

SECTION

	Item	Part No	DRG No.	No. Off	Detail
1	FUEL TANK	17-2-14	792-15-01	1	
2	COLLECTOR POT	3-59-12	792-15-04	1	
3	COLLECTOR POT FILTER STEM	3-61-4	792-15-05	1	
4	FILTER	8-23-5	792-15-07	1	TD 8-23-5
5	TANK OUTLET ADAPTOR	4-35-14	792-15-06	1	
6	HOSE -- COLLECTOR POT TO OUTLET	21-2-10	TD 293		-8 AEROQUIP
7	FUEL TANK OUTLET UNION	21-1-12	TD 314		-8 90°
8	HOSE - OUTLET TO PUMP	21-2-10	TD 293		-8 AEROQUIP
9	FUEL PUMP	8-16-8	TD 8-16-8	1	
10	FUEL PUMP MOUNTING BRACKET	3-62-7	792-01-86	1	
11	FUEL PUMP OUTLET ADAPTOR	4-71-9	782-15-05		
12	FUEL PUMP OUTLET ADAPTOR SEAL	20-3-7	TD 20-3-7	1	
13	HOSE - FUEL PUMP TO METERING UNIT	21-2-0	TD 292		-6
14	TANK TOP	3-61-5	792-15-02	1	
15	FUEL FILLER CAP	4-20-1	722-18-11	1	
16	FUEL FILLER CAP O - RING	8-8-9	TD 70	1	
17	TANK TOP SEAL	8-23-4	TD 8-23-4	1	
18	BREATHER PIPE	8-10-7	TD 8-10-7		
19	BREATHER VALVE COMPLETES:	4-33-8	762-15-02	1	
20	BOTTOM	4-37-6	753-15-05	1	
21	TOP	4-33-9	765-15-01	1	
22	BALL	8-4-13	TD 287	1	
23	METERING UNIT FILTER ELEMENT	4-76-13	783-15-05	1	
24	METERING UNIT INLET UNION	21-1-8	TD 306	1	
25	METERING UNIT INLET UNION	4-80-8	782-15-18	1	
26	METERING UNIT BANJO BOLT	4-80-5	782-15-17		
27	METERING UNIT OUTLET UNION	4-16-6	755-13-14		
28	METERING UNIT OUTLET UNION	3-30-7	76B-13-08		
29	METERING UNIT OUTLET UNION NUT	8-22-4	TD 541	1	
30	HOSE - METERING UNIT TO TANK	8-8-5	TD 542		
31	FUEL TANK INLET UNION	3-30-7	76B-13-08		1/8" BSP 90
32					
33					
34					

SPHERICAL JOINTS - 792

Issue	Signature	Da
2	R. Sauter	23-
3	R. Sauter	31-
4	R. Sauter	17-

SECTION

Item	Part No	DRG No.	No. Off	Detail
1 FRONT TOP ROCKER OUTER	15-3-14	TD 15-3-14	2	RSTWR 07B
2 FRONT BOTTOM WISHBONE OUTER	15-3-15	TD 15-3-15	2	RC 10H
3 TRACK ROD OUTER	15-3-2	TD 15-3-2	2	RMR 5 UF
4 TRACK ROD INNER	15-3-3	TD 15-3-3	2	RMLR 5 UF
5 F.A.R.B. LINK (TOP)	15-1-11	TD 49	2	RMP 5 U
6 F.A.R.B. LINK (BOTTOM)	15-3-5	TD 15-3-5	2	RMLP 5 U
7 R.A.R.B. LINK (TOP)	15-3-5	TD 15-3-5	2	RMLP 5 U
8 R.A.R.B. LINK (BOTTOM)	15-1-13	TD 51	2	RC 6 H
9 TOP LINK INNER	15-3-10	TD 15-3-10	2	RCL 6 E
10 TOP LINK OUTER	15-1-14	TD 52	2	RC 6 E
11 TRACK CONTROL ARM OUTER	15-2-1	TD 54	2	RC 8 H
12 TRACK CONTROL ARM INNER	15-3-10	TD 15-3-10	2	RCL 6 E
13 R.L.W.B. OUTER	15-2-3	TD 56	2	RSTWR 08E
14 GEAR LEVER LOCATION BEARING	15-2-12	TD 1013	2	RBJ 67U
15 GEAR LINKAGE MID. SUPPORT (SIDEFRAME)	15-2-2	TD 55	1	RMP 8 U
16 THROTTLE CABLE TO FRONT JOINT	15-2-7	TD 15-2-7	1	RF 3U
17 MIRROR MOUNT	4-73-11	782-12-25	2	RMP 4U - MOD
18 RADIUS ROD (LEFT)	15-3-12	TD 15-3-12	2	RCL 6 H
19 RADIUS ROD (RIGHT)	15-1-13	TD 51	2	RC 6 H
20 C.S.D.U. ROD	15-3-8	TD 15-3-8	4	RC 6 F
21 GEAR LINKAGE SUPPORT (REAR PLATE)	15-2-14	TD 1011	1	RAC 8

HYDRAULICS - 792 BMW

Issue	Signature	Date
2	R. Santos	25-1-

		SECTION			
Item	Part No	DRG No.	No. Off	Detail	
1	<u>FRONT BRAKES</u>				
2	PUSH ROD	7-1-7	TD 7-1-7	1	
3	MASTER CYLINDER	7-3-14	TD 1078	1	0.75" SIZE
4	MASTER CYLINDER RESERVOIR	7-3-13	TD 1120	1	
5	MASTER CYLINDER TOP HAT WASHER	44-12-9	792-19-06	6	
6	BANJO BOLT	7-3-8	TD 690	1	
7	BANJO	7-3-5	TD 691	1	2 WAY 90
8	BANJO ADAPTOR	4-8-7	732-06-18	2	1/8" BSP/3/8" UNF
9	BANJO OUTLET UNION	21-1-3	TD 701	2	-3 90
10	HOSE - MASTER CYLINDER TO CALIPERS	21-2-7	TD 290		-3 AERQUIP
11	CALIPER INLET UNION	21-1-1	TD 697	2	-3 STRAIGHT
12	CALIPER INLET ADAPTOR	4-8-7	732-06-18	2	1/8" BSP/3/8" UNF
13	CALIPER	7-2-1	TD 107	2	7 lb. springs
14	BRAKE PAD (SUPPLIED WITH CALIPER)	7-2-8	TD 276	4	
15	<u>REAR BRAKES</u>				
16	PUSH ROD	7-1-7	TD 7-1-7	1	
17	MASTER CYLINDER	7-3-14	TD 1078	1	0.75" SIZE
18	MASTER CYLINDER RESERVOIR	7-3-13	TD 1120	1	
19	MASTER CYLINDER ADAPTOR	4-8-7	732-06-18	1	1/8" BSP/3/8" UNF
20	MASTER CYLINDER UNION	21-1-3	TD 701	1	-3 90
21	HOSE - MASTER CYLINDER TO RH CALIPER	21-2-7	TD 290		-3
22	CALIPER INLET UNION	21-1-3	TD 701	1	-3 90
23	CALIPER INLET ADAPTOR	4-8-7	732-06-18	1	1/8" BSP/3/8" UNF
24	CALIPER R.H.	7-5-2	TD 968	1	7 lb. springs
25	CALIPER L.H.	7-5-1	TD 967	1	7 lbs springs
26	BRAKE PAD (SUPPLIED WITH CALIPER)	7-2-8	TD 276	4	
27	CALIPER OUTLET ADAPTOR	4-8-7	732-06-18	1	1/8" BSP/3/8" UNF
28	CALIPER OUTLET UNION	21-1-2	TD 699	1	-3 45
29	HOSE - RH CALIPER TO LH CALIPER	21-2-7	TD 290	12"	-3 AERQUIP
30	CALIPER INLET UNION	21-1-2	TD 699	1	-3 45
31	CALIPER INLET ADAPTOR	4-8-7	732-06-18	1	1/8" BSP/3/8" UNF
32	<u>CLUTCH</u>				
33	PUSH ROD	7-1-7	TD 7-1-7	1	
34	MASTER CYLINDER	7-3-14	TD 1078	1	0.75" SIZE
35	MASTER CYLINDER RESERVOIR	7-3-13	TD 1120	1	
36	MASTER CYLINDER ADAPTOR	4-8-8	722-18-08	1	1/8" BSP/3/8" UNF

HYDRAULICS - 792 BMW

Page 2 of 2

Issue	Signature	Date
2	P. Gupta	23-1-

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
37	MASTER CYLINDER UNION (NUT)	7-8-7	TD 7-8-7	1 7/16" UNF MAI
38	HOSE	21-2-8	TD 291	50' -4 AEROQUIP
39	HYDRAULIC LINE SUPPORT	3-31-5	762-16-30	3
40	SLAVE CYLINDER INLET UNION	21-1-6	TD 702	1 -4 90
41	SLAVE CYLINDER INLET ADAPTOR	4-8-8	722-18-08	1 1/4" BSP/3/8" UNF
42	COPPER WASHER 3/8" THIN	20-2-14	TD 689	A. B.
43	COPPER WASHER 1/2" THICK	20-2-13	TD 952	A. B.
44	COPPER WASHER 7/16" THIN	20-4-3	TD 688	A. B.
45	CLUTCH SLAVE CYLINDER	7-7-1	TD 7-7-1	1
46	<u>CALIPER OPTIONS</u>			
47	CALIPER - L.H. (FOR SOLID DISC OPTION)	7-5-8	TD 7-5-8	1
48	CALIPER - R.H. (FOR SOLID DISC OPTION)	7-5-9	TD 7-5-9	1
49	CALIPER M.T.G. PLATE L.H.	4-89-13	792-26-01	1
50	" " " " R.H.	4-89-14	792-26-02	1

Issue	Signature	Date
2	R. Santiago	23-1-79
3	R. Santiago	25-1-79
4	R. Santiago	17-2-79

		SECTION			
Item	Part No	DRG No.	No. Off	Detail	
1	BATTERY	8-3-11	TD 124	1	12 VOLT
2	BATTERY CABLE	9-7-14	TD 9-7-14		FEPSIL 6
3	BATTERY TERMINAL CAP	4-78-8	782-28-06	4	
4	BATTERY LEAD TERMINAL	9-9-4	TD 9-9-4		
5	BATTERY LEAD TERMINAL	9-8-7	TD 9-8-7		5/16"
6	MASTER SWITCH	9-1-15	TD 428	1	
7	MASTER SWITCH MOUNTING BRACKET	3-61-7	792-01-69	1	
8	MASTER SWITCH MOUNTING GROMMET	8-15-12	TD 8-15-12	2	
9	MASTER SWITCH MOUNTING SPACER	8-20-7	78B-01-05	2	
10	MASTER SWITCH KNOB	9-5-3	TD 428	1	
11	MASTER SWITCH SHAFT	4-86-8	792-01-72	1	
12	MASTER SWITCH LEVER	3-61-9	792-01-71	1	
13	FIRE PULL CLEVIS	3-51-8	TD 3-51-8	1	
14	FIRE PULL CLEVIS PIN	8-2-7	TD 86	1	
15	FIRE PULL HANDLE	3-63-9	792-22-01	1	
16	FIRE EXTINGUISHER FIRING BUTTON	9-1-2	TD 274	1	
17	FIRE EXTINGUISHER MASTER SWITCH	9-1-12	TD 426	1	
18	SPARK BOX	3-63-2	792-28-01	1	
19	SPARK BOX LID	3-63-3	792-28-02	1	
20	SPARK BOX RETAINER	3-64-2	792-01-141	1	
21	SPARK BOX BRACKET	3-64-1	792-01-140		
22	FUEL PUMP SWITCH	9-1-12	TD 426	1	
23	IGNITION SWITCH	9-1-12	TD 426	1	
24	REAR LIGHT SWITCH	9-1-12	TD 426	1	
25	KILL SWITCH (STEERING WHEEL)	9-1-12	TD 426	1	
26	STARTER BUTTON	9-1-12	TD 426	1	
27	REAR LIGHT	9-1-12	TD 426	1	
28	REAR LIGHT RUBBER MOUNTING BUSH	8-20-4	TD 8-20-4	2	
29	JUMP PLUG	9-5-13	TD 1101	1	
30	JUMP PLUG PROTECTIVE CAP	9-8-9	TD 1102	1	
31	JUMP PLUG BRACKET	3-58-10	79B-01-23	1	
32	OIL PRESSURE SWITCH	9-4-6	TD 951	1	
33	OIL PRESSURE WARNING LIGHT	9-9-6	TD 9-9-6	1	
34	WIRING LOOM			1	
35	BATTERY CARRIER	3-62-3	792-01-85	1	

BODYWORK - 792 BMW

Sheet 1 of 2

Issue	Signature	Date

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1 NOSE	11-7-10	792-12-26	1	
2 FRONT WING	46-3-13	79C-12-01	2	
3 FRONT WING END PLATE	46-3-12	792-12-15	2	
4 FRONT WING SUPPORT BAR	46-3-14	79C-12-02	1	
5 FRONT WING END CAP	3-61-11	792-12-18	2	
6 SPLIT PIN	23-6-2	TD 23-6-2	1	
7 FRONT WING LOCATING SPIGOT	4-86-15	792-12-13	2	
8 NOSE FRAME	3-38-11	792-01-79	1	
9 NOSE FRAME TIE ROD	3-62-8	792-01-101	2	
10 RADIATOR STAY	3-62-9	792-01-102	2	
11 RADIATOR MOUNTING GROMMET	8-15-12	TD 8-15-12	2	
12 RADIATOR MOUNTING SPACER	8-20-7	78B-01-05	2	
13 RADIATOR SCREEN	2-16-11	792-13-07	1	
14 COCKPIT	11-7-12	792-12-28	1	
15 SCREEN	11-7-11		1	
16 MIRROR R.H.			1	
17 MIRROR L.H.			1	
18 MIRROR SHROUD R.H.			1	
19 MIRROR SHROUD L.H.			1	
20 SEAT			1	
21 SIDE WING R. & L.H.	11-7-13	792-12-27	2	
22 SIDE WING MOUNTING TUBE	3-63-4	792-12-20	2	
23 REAR SIDE POD WING	11-7-14	792-12-29	2	
24 REAR OVERTRAYS	3-67-6	792-12-30	1	
25 REAR SIDE WING MOUNT R.H.	3-67-8	792-01-162	1	
26 REAR SIDE WING MOUNT L.H.	3-67-7	792-01-161	1	
27 COCKPIT RETAINER	3-49-10	792-01-123	2	
28 COCKPIT MOUNTING BRACKET -FRONT-	3-49-10	782-12-31	2	
29 BADGE	8-6-9	TD 8-6-9	1	
30 OVERTRAY LOWER MOUNTING BRACKET L.H.	3-64-4	792-12-25	1	
31 OVERTRAY LOWER MOUNTING BRACKET R.H.	3-64-3	792-12-24	1	
ROLLER SKIRT ASSY. L.H. & R.H.	3-67-5	792-12-53	1	
" " " " " " " "	3-67-6	792-12-53	1	

Issue	Signature	Date

		SECTION			
Item		Part No	DRG No.	No. Off	Detail
32	<u>REAR WING ASSEMBLY COMPRISES:</u>	46-2-12	792-12-01	1	
33	MAINPLANE	46-2-15	792-12-01	1	
34	FLAP	46-2-6	792-12-01	1	
35	CROSS TUBE	46-2-7	792-12-02	1	
36	SIDE PLATE	46-2-12	792-12-01	2	
37	CLAMPING PLATE	46-2-10	792-12-05	2	
38	ADJUSTING PLATE	46-2-9	792-12-04	2	
39	R-FLAP	46-2-1	792-12-28		
40	L/D FLAP PACKER	46-3-9	792-12-09	2	
41	MAINPLANE FLAP WASHER	46-2-11	792-12-08	2	
42	MAINPLANE PACKER	46-3-10	792-12-10	2	

engine instalation kit 79A
(1)

Issue	Signature	D

SECTION

Item	Part No	DRG No.	No. Off	Detail
1	CLUTCH (BDA) ASSEMBLY	7-12-3	TD 7-12-3	1
2	ENGINE SIDE FRAME	36-2-13	79A-01-01	2
3	ENGINE SIDE FRAME CLEVIS	4-80-15	792-01-29	4
4	SIDE FRAME BOLT LONG	4-86-11	792-01-74	2
5	SIDE FRAME BOLT SHORT	4-86-9	792-01-27	2
6	SIDE FRAME CLEVIS STUD	4-84-15	792-01-73	2
7	ENGINE MOUNTING PLATE		79A-16-02	1
8	ENGINE SUPPORT L.H.		79A-16-03	1
9	ENGINE SUPPORT R.H.			1
10	ENGINE SUPPOT SPACER L.H.			1
11	ADAPTOR PLATE			1
12	ADAPTOR PLATE STUD	4-14-6	74B-16-01	3
13	ENGINE MOUNTING RING	4-86-4	792-01-64	1
14	A.R.E. SUMP			1
15	EXHAUST SYSTEM			1
16	EXHAUST BRACKET			1
17	EXHAUST BRACKET METALISTIC BUSH			
18	EXHAUST FLAGE NUT	13-2-8	TD 419	12
19	AIR BOX	11-10-6	782-12-16	1
20	AIR BOX BASE	3-35-7	78B-01-08	1
21	AIR BOX GAUZE	2-10-5	782-12-19	1
22	TACHOMETER	34-1-1	TD 958	1
23	TACHOMETER ANTI-VIBRATION O - RING	8-14-3	TD 8-14-3	1
24	" " " GROMMET	8-15-4	TD 1140	1
25	" " " "	8-15-5	TD 1141	1
26	" FLEXIBLE DRIVE	34-1-6	TD 1131	1
27	GAUGE (WATER TEMP)	8-3-7	TD 63	1
28	GAUGE (OIL PRESSURE/TEMP)	8-9-9	TD 68	1
29	UNION $\frac{1}{8}$ BSP 90	3-30-7	76B-13-08	2
30	UNION $\frac{1}{8}$ BSP NUT	8-22-4	TD 541	2
31	OIL PRESSURE HOSE	8-8-5	TD 542	1
32	$\frac{1}{8}$ BSP/ $\frac{3}{8}$ UNF ADAPTOR	4-8-7	732-06-18	1
33	$\frac{3}{8}$ COPPER WASHER	20-2-14		
34				
35				
36				

ENGINE INSTALATION KIT 79A

Issue for new

Issue	Signature	Date

Item	SECTION		No. Off	Detail	
	Part No	DRG No.			
37	THROTTLE CABLE CLAMP	8-16-14	TD 8-16-14	1	
38	THROTTLE CABLE CONNECTOR	4-45-6	762-16-42	1	
39	<u>THROTTLE LINKAGE ASSEMBLY COMPRISES:</u>				
40	BALL JOINT CONNECTOR	4-4-15	76B-16-09	1	
41	QUADRANT	3-38-5	79B-16-03	1	
42	MORSE CABLE	8-16-15	TD 8-16-15	1	6 FT LONG
43	BOLT	4-75-15	79B-16-02	1	
44	THREADED ROD	4-84-4	79B-16-04	1	
45	TIE ROD	4-77-7	79B-16-05	1	
46	CABLE CLAMP SUPPORT	3-51-10	78B-16-08	1	
47	BALL JOINT CIRCLIP	23-5-3	TD 23-5-3	1	900 -31A
48	GLACIER 05 DU 06 BUSH	8-18-6	TD 8-18-6	1	
49	CABLE CLAMP SPACER	3-36-14	772-01-06	2	

TRANSMISSION 79A

Issue	Signature	Date

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1	GEARBOX ASSEMBLY		1	
	COMPRISES:			
2	GEARBOX		1	
3	4-62-12	782-16-24	1	
4	4-69-9	782-16-01	1	
5	18-17-6	79B-16-01	1	
6	CLUTCH BOBBIN		1	
7	CLUTCH SPIGOT		1	
8	4-74-1	772-16-07	1	
9	" " R.H.	4-74-2	1	
10	" " STUD	4-75-1	2	10.1" LONG.
11	" " "	4-75-2	8	2.06" "
12	" " "	4-75-3	2	8.62" "
13	" " "	4-75-4	2	3.00" "
14	" " "	4-75-5	2	1.50" "
15	" " "	4-75-6	2	7.87" "
16	" " BEARING	8-20-8	2	
17	BEARING SPACER L.H.		1	
18	" " R.H.	4-79-14	1	
19	OUTPUT FLANGE		2	
20	" " SEAL	18-7-2	2	FT 2054
21	" " CIRCLIP	18-9-2	2	FT 2191 A
22	OIL OUTLET BANJO		1	
23	" " " BOLT	4-62-15	1	
24	" " ADAPTOR	4-8-13	1	-6/-6
25	" FILTER ASSEMBLY DRAWING			
26	" " PUMP INLET ADAPTOR	4-32-8	1	-6/8" BSP
27	" " " SEAL	20-3-8	1	3/8" BSP DOWT
28	" " FILTER ELEMENT	8-13-9	1	
29	" " SPACER	4-55-5	1	
30	" " WASHER	4-61-6	1	
31	" " SPINDLE	4-54-11	1	
32	" " SPRING	16-6-2	1	
33	" " O - RING	8-21-1	1	137377
34	" " O - RING	8-14-10	1	
35	" " BRACKET		1	

TRANSMISSION 79A

Issue	Signature	Date

Item	SECTION		No. Off	Detail	
	Part No	DRG No.			
36	OIL FILTER OUTLET ADAPTOR	4-43-5	771-16-17	1	
37	AEROQUIP -6 HOSE	21-2-9	TD 292	32"	
38	AEROQUIP -6 STRAIGHT UNION	21-1-7	TD 299	1	
39	" -6 90 UNION	21-1-9	TD 313	1	
40	MAIN CASE INLET ADAPTOR	4-8-13	752-15-10	1	
41	SPRAY TUBE	4-62-13	772-14-03	1	
42	OIL PUMP ASSEMBLY	8-10-12	TD 8-10-12	1	
43	REAR DISC	7-6-10	773-10-04	2	
44	" " BOLT	12-13-8	TD 591		
45	" " NUT	13-2-1	TD 406		
46	<u>DRIVESHAFT ASSEMBLY</u>			2	
	<u>COMPRISES:</u>				
47	PLUNGE JOINT HOUSING	14-2-9	782-10-03	1	89 ST
48	" " CAGE	14-1-7	TD 176	1	89 ST
49	" " BALL	14-1-8	TD 175	6	89 ST
50	" " INNER TRACK	14-1-6	TD 179	1	89 ST
51	" " GAITER	14-2-11	TD 14-2-11	1	VW
52	DRIVESHAFT INNER CIRCLIP	8-1-9	TD 174	1	1700-100
53	DRIVESHAFT	4-29-10	792-10-01	1	
54	" OUTER CIRCLIP	23-5-5	TD 23-5-5	1	1700-30
55	" YOKE	14-2-4	741-10-08	1	
56	CENTRE CROSS	14-2-2	TD 192	1	
57	AXLE YOKE	14-2-1	741-10-02	1	
58	" " THRUST RING	4-18-13	741-10-03	1	
59	PLUNGE JOINT GREASE	26-4-15	TD 26-4-15	A.R.	Q 5795
60	U/J GREASE			A.R.	
61	WHEEL RETAINING STUD	4-75-12	792-07-06	1	5.87" LONG
62	FRONT GEAR ROD			1	
63	REAR GEAR ROD			1	

OIL SYSTEM 79A

Issue	Signature	D

Item	SECTION		No. Off	Detail	
	Part No	DRG No.			
1	OIL TANK	3-24-4	792-14-04	1	
2	FILTER HOUSING ASSEMBLY	3-58-6	79B-14-01	1	-12
3	TEMP TAKE OFF BOSS	4-33-3	762-14-04	1	
4	TAKE OFF BOSS SEAL	20-3-10	TD 20-3-10	1	
5	DRAIN PLUG	4-33-13	762-14-23	1	
6	DRAIN PLUG SEAL	20-3-4	TD 1025		
7	FILLER CAP	4-20-1	722-18-11	1	
8	O - RING	8-8-9	TD 20	1	
9	MOUNTING RAWL NUT	23-3-7	TD 1033		
10	PUMP AND FILTER HOUSING	4-69-10	78B-16-01	1	
11	FILTER ELEMENT	8-7-3	TD 75	1	
12	PUMP HOUSING BLANKING PLUG	4-71-12	78B-16-05	1	
13	FILTER SPIGOT	4-71-13	78B-16-06	1	
14	PUMP MAIN INLET ADAPTOR	4-71-11	78B-14-02	1	
15	FILTER SUPPORT	3-51-9	78B-16-11	1	
16	SCAVENGE PUMP OUTLET ADAPTOR	4-71-11	78B-14-02	1	
17	OIL COOLER			1	
18	AEROQUIP -12 HOSE	21-2-12	TD 295		
19	AEROQUIP UNION				
20	AEROQUIP "				
21	AEROQUIP "				
22	TAPER PLUG	4-76-14	78B-16-14	1	
23	BREATHER PIPE ELBOW	3-54-11	78B-16-16	1	

water system 79A

Issue	Signature	I

SECTION

Item	Part No	DRG No.	No. Off	Detail
1 RADIATOR		792-J3-01	1	
2 RADIATOR STAY			2	
3 RADIATOR SCREEN			1	
4 SWIRL POT			1	
5 HEADER TANK			1	
6 RADIATOR BLEED CAP			1	
7 FILLER CAP			1	
8 PIPE FRONT			2	
9 PIPE SIDE (LONG)			2	
10 PIPE REAR L.H.			1	
11 PIPE REAR R.H.			1	
12 RUBBER HOSE (1 $\frac{1}{4}$ ")	8-4-7	TD 753		
13 RUBBER HOSE (1 $\frac{1}{2}$ ")	8-4-8	TD 755		
14 90° RUBBER HOSE	8-6-12	TD 22		
15 RADIATOR MOUNTING GROMMET	8-15-12	TD 8-15-12	2	
16 RADIATOR MOUNTING SPACER	8-20-7	79B-01-05	2	

FUEL SYSTEM 79A

Issue	Signature	D.

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1 FUEL TANK	17-2-14	792-15-01	1	
2 COLLECTOR POT				
3 COLLECTOR POT OUTLET ADAPTOR				
4 FUEL PUMP	8-10-8	TD 1103	1	MITSUBA
5 FILTER ELEMENT	8-22-1	TD 8-22-1	1) SUPPLIED AS
6 FILTER SEAL	8-22-2	TD 8-22-2	1) PART OF PUM
7 PUMP ADAPTOR	4-32-2	76B-15-01	2	
8 P.R.V. (SUPPLIED BY CUSTOMER)			1	
9 P.R.V. ADAPTOR			2	
10 FRONT CARBURETTOR TEE BANJO	3-49-14	78B-15-07	1	
11 REAR CARBURETTOR BANJO	3-49-15	78B-15-08	1	
12 TANK TOP			1	
13 FILLER CAP	4-20-1	722-16-11	1	
14 FILLER CAP O RING	8-8-9	TD 70	1	
15 TANK TOP SEAL				
16 BREATHER PIPE	8-10-7	TD 8-10-7	6'	$\frac{3}{8}$ " ID TEKPLAS
17 BREATHER VALVE	4-33-8	763-15-02	1	
COMPRISES:				
18 BOTTOM	4-37-6	753-15-05	1	
19 TOP	4-33-9	765-15-01	1	
20 BALL	8-4-13	TD 287	1	
21 AEROQUIP -6 HOSE	21-2-9	TD 292	5'	
22 AEROQUIP -6				
23 AEROQUIP -6				
24 TANK OUTLET PIPE				

Issue	Signature	Date

SECTION

Item	Part No	DRG No.	No. Off	Detail
1	<u>FRONT BRAKES</u>			
2	7-1-7	TD 7-1-7	1	
3	MASTER CYLINDER			
4	7-3-13	TD 1120	1	0.70" SIZE
5	MASTER CYLINDER RESERVOIR			
6	7-3-8	792-19-06	6	
7	7-3-5	TD 690	1	
8	7-3-5	TD 691	1	2 WAY 90
9	4-8-7	732-06-18	2	1/8" BSP/3/8" UNF
10	21-1-3	TD 701	2	-3 90°
11	21-2-7	TD 290		-3 AEROQUIP
12	21-1-1	TD 697	2	-3 STRAIGHT
13	4-8-7	732-06-18	2	1/8" BSP/3/8" UNF
14	7-2-1	TD 107	2	
15	7-2-8	TD 276	4	
16	BRAKE PAD (SUPPLIED WITH CALIPER)			
17	<u>REAR BRAKES</u>			
18	7-1-7	TD 7-1-7	1	
19	7-3-14	TD 1078	1	0.75" SIZE
20	7-3-13	TD 1120	1	
21	4-8-7	732-06-18	1	1/8" BSP/3/8" UNF
22	21-1-3	TD 701	1	-3 90°
23	29-2-7	TD 290		-3
24	21-1-3	TD 701	1	-3 90°
25	4-8-7	732-06-18	1	1/8" BSP/3/8" UNF
26	7-5-9	TD 7-5-9	1	
27	7-5-8	TD 7-5-8	1	
28	BRAKE PAD			
29	4-8-7	732-06-18	1	1/8" BSP/3/8" UNF
30	21-1-2	TD 699	1	-3 45°
31	21-2-7	TD 290	12"	-3 AEROQUIP
32	21-1-2	TD 699	1	-3 45°
33	4-8-7	732-06-18	1	1/8" BSP/3/8" UNF
34	<u>CLUTCH</u>			
35	7-1-7	TD 7-1-7	1	
36	7-3-14	TD 1078	1	0.75" SIZE
37	7-3-13	TD 1120	1	
38	4-8-8	722-18-08	1	1/4" BSP/3/8" UNF

HYDRAULICS 79A

Issue	Signature	Da

SECTION

Item	Part No	DRG No.	No. Off	Detail
37 MASTER CYLINDER UNION (NUT)	7-8-7	TD 7-8-7	1	7/16" UNF MALE
38 HOSE	21-2-8	TD 291	50"	-4 AEROQUIP
39 HYDRAULIC LINE SUPPORT	3-31-5	762-16-30	3	
40 SLAVE CYLINDER INLET UNION	21-1-6	TD 702	1	-4 90°
41 SLAVE CYLINDER INLET ADAPTOR	4-8-8	722-18-08	1	1/4" BSP/3/8" UNF
42 COPPER WASHER 3/8" THIN	20-2-14	TD 689	A.R	
43 COPPER WASHER 3/8" THICK	20-2-13	TD 952	A.R	
@@ COPPER WASHER 7/16" THIN	20-4-3	TD 688	A.R	
SLAVE CYLINDER				