

FRONT & REAR UPRIGHTS - 793

SHEET 1 OF 2

Issue	Signature	Date
	SUB	160077

SECTION D26

Item	Part No	DRG No.	No. Off	Detail
1	FRONT UPRIGHT ASSEMBLY LH COMPRISES:			1
2	TOP SPACER	4-44-15	712-02-09	1
3	TOP PIN INSERT	4-78-1	783-02-05	1
4	TOP NUT WASHER	4-47-4	702-02-09	1
5	UPRIGHT LH	4-40-13	772-06-01	1
6	AXLE	4-1-9	711-07-04	3
7	WHEEL BEARING	8-1-5	TD1	2
8	BEARING SPACER	4-1-5	711-06-07	1
9	OUTER SPACER	4-1-12	711-07-05	1
10	WHEEL STUD ASSEMBLY	3-58-4	742-06-02	1
11	BRAKE DISC	7-11-0	783-06-01	1
12	BOTTOM PIN	4-76-7	782-06-09	1
13	BOTTOM PIN RETAINING COMPOUND	26-4-12	TD26-4-12	AR LOCKTITE 35
14	RETAINING COMPOUND PRIMER	26-4-11	TD26-4-11	AR LOCKTITE 1T
15	FRONT OUTER JOINT INSERT	4-68-11	782-02-10	1
16	FRONT OUTER JOINT RETAINING WASHER	41-1-10	782-20-10	1
17	FRONT UPRIGHT ASSEMBLY RH COMPRISES: AS ABOVE BUT			
18	UPRIGHT RH	4-40-12	772-06-02	1
19	FRONT WHEEL	19-5-2	783-09-01	2 13x9 (4" OFFSET)
20	WHEEL WASHER	4-52-2	771-09-01	2
21	WHEEL WASHER INSERT	4-6-11	712-07-11	2
22	FRONT TYRE	10-2-1	TD10-2-1	2 654 SLICK
23	REAR UPRIGHT ASSEMBLY COMPRISES:			2
24	UPRIGHT	4-74-9	792-07-09	1
25	AXLE	4-83-15	792-07-05	1
26	AXLE DRIVE PIN	4-1-9	711-07-04	3
27	WHEEL BEARING	8-22-5	TD8-22-5	1
28	REAR WHEEL ASSEMBLY COMPRISES:			2 13x10 (5 1/2" OFFSET)
29	DRUM	19-2-14	702-09-02	1
30	SEALING RING	19-2-7	703-09-12	1
31	O-RING	19-2-2	TD1921	2
32	OUTWARD SPRING	19-2-2	703-09-02	1 2 1/2"
33	INWARD SPRING	19-2-8	703-09-09	1 2 1/2"
34	WHEEL WASHER	4-52-2	771-09-01	2
35	WHEEL WASHER INSERT	4-6-11	712-07-11	2
36	FRONT TYRE	10-2-2	TD10-2-2	2 654 SLICK

Issue	Signature	Date

SECTION

Item	FRONT UPRIGHT ASSY	Part No	DRG No.	No. OFF	Detail
FRONT AXLE			802-06-04	2	
WHEEL BEARING		6-1-5	TD1	2	
BEARING SPACER				1	
OUTER SPACER		4-1-12	711-07-05	1	
WHEEL STUD ASSY			803-06-07	2	
BRAKE DISC		7-7-13	803-06-01	1	
AXLE DRIVE PIN		4-1-9	711-07-04	3	
WHEEL WRENCH		4-52-2	771-09-01	2	
WHEEL WASHED INSERT		4-6-11	712-07-11	2	
FRONT UPRIGHT		4-92-1	803-06-02	2	
SPACER PLATE (UPRIGHT)			803-06-08	2	
BOTTOM PIN			802-06-01	2	
BOTTOM PIN SPACER			802-06-04	2	

REAL UPRIGHT PTO

FRONT & REAR UPRIGHTS - 793

SHEET 2 OF 2

Issue	Signature	Det
1	SCB	1160

SECTION D26

Item	Part No	DRG No.	No. Off	Detail
37 REAR UPRIGHT D.S PLATE - REAR	3-50-15	793-07-01	2	
38 " " R.B.W.B BUSH	44-1-7	732-01-102*	2	* SHEET 6
39 " " TOP LINK D.S. BRACKET	3-59-5	798-01-10	2	
40 " " DAMPER SUPPORT PLATE <sup>LH</sup>	3-59-3	792-07-11	1	
41 " " " " " RH	3-59-4	792-07-11	1	

Issue	Signature	Date

**SECTION**

Item	Part No	DRG No.	No. Diff	Detail
REAR UPRIGHT ASSY				
REAR UPRIGHT				OLD T/E
REAR AXLE	4-93-15	792-07-05	1	
AXLE PLIVE PIN	4-1-9	711-07-04	6	
WHEEL BEARINGS	8-22-5	708-22-5	1	
WHEEL WASHER	4-52-2	771-09-01	11	
WHEEL WASHER INSERT	4-6-11	712-07-11	1	
REAR UPRIGHT D.S. PLATE (REAR)	3-50-15	793-07-01	1	
" " RBWS BUSH	44-1-7	732-01-102	1	
" " TOP LINK D.S. BRACKET	3-59-5	798-01-10	1	
" " DAMPER SUPP PLATE LH	3-59-3	792-07-11	1	
" " " " RH	3-59-4	712-07-12	1	

PEDALS - 792

PEDALS.

Issue	Signature	Date
2	R. Sullivan	11-17

SECTION E 9

Item	Part No	DRG No.	No. Off	Detail
1 <u>CLUTCH PEDAL ASSEMBLY</u>			1	
<u>COMPRISES:</u>				
2 CLUTCH PEDAL ✓	3-24-10	792-08-02	1	
3 CLUTCH PEDAL PIVOT BEARING	8-1-10	TD 126	2	06 DU 08
4 CLUTCH PEDAL CLEVIS BEARING	8-18-1	TD 8-18-1	1	
5 CLUTCH CLEVIS	4-26-11	771-08-04	1	
6 CLUTCH CLEVIS PIN	4-56-14	771-08-09	1	
7 <u>BRAKE PEDAL ASSEMBLY</u>			1	
<u>COMPRISES:</u>				
8 BRAKE PEDAL ✓	3-24-9	792-08-01	1	
9 BRAKE PEDAL PIVOT BEARING	8-1-10	TD 126	2	06 DU 08
10 BRAKE PEDAL PIVOT BUSH	4-5-11	712-08-07	1	
11 BALANCE BAR SHAFT	4-87-1	771-08-12	1	
12 BALANCE BAR YOKE	4-5-14	703-08-01	2	
13 BALANCE BAR YOKE INSERT	4-5-13	703-08-03	2	
14 BALANCE BAR NUT	4-6-1-	703-08-02	2	
15 <u>THROTTLE PEDAL ASSEMBLY</u>			1	
<u>COMPRISES:</u>				
16 THROTTLE PEDAL ✓	3-24-11	792-08-03	1	
17 THROTTLE PEDAL PIVOT BEARING	8-1-10	TD 126	2	06 DU 08
18 THROTTLE PEDAL PIVOT BUSH	4-5-11	712-08-07	1	
19 CLUTCH STOP, ADJUSTER	4-59-15	782-01-56	1	
20 CLUTCH PEDAL BUFFER RUBBER	8-16-11	TD 8-16-11	1	
21 CLUTCH PEDAL BUFFER SUPPORT	4-64-15	771-01-81	1	
22 THROTTLE STOP ✓			1	

Issue	Signature	Date

SECTION

Item	Part No	DRG No.	No. Off	Detail
PEDAL ASSY (A5792) BRACE BALANCE BAR ?				

# ENGINE INSTALLATION - 793

SHEET 1 OF 1

ENGINE INST.		
Issue	Signature	Date
1	S.B.	16 OCT 78
2	S.B.	23 OCT 78
3	S.B.	30 OCT 78
4	S.B.	15 NOV 78
5	S.B.	22 NOV 78

## SECTION F45

Item	Part No	DRG No.	No. Off	Detail
1 ENGINE (NORMALLY SUPPLIED BY CUSTOMER)			1	
2 CLUTCH (SUPPLIED WITH ENGINE)	7-3-11	TD 7-3-11	1	CP 2125
3 ENGINE SIDEFRAE LH	36-2-9	793-01-15	1	
4 ENGINE SIDEFRAE RH	36-2-10	793-01-15	1	
5 SIDEFRAE WOLF	4-59-14	782-01-18	2	
6 ENGINE MOUNTING PLATE	3-60-2	793-01-23	1	
7 ENGINE MOUNTING - FORWARD - LOWER	4-85-5	793-01-22	1	
8				
9				
10				
11				
12 ADAPTOR PLATE	4-74-11	793-01-01	1	
13 SIDEFRAE SPACER	41-32-12	708-16-03	2	0.43 LONG
14				
15 STARTER MOTOR (SUPPLIED WITH ENGINE)	9-9-5	TD 9-9-5	1	
16 EXHAUST SYSTEM	24-3-2	TD 24-3-2	1	
17 EXHAUST FLANGE NUT	13-2-13	TD 13-2-13	5	
18 EXHAUST BRACKET	3-34-10		1	
19 TACHOMETER	34-1-2	TD 959	1	(0.0000 RPM)
20 TACHOMETER ANTI-VIBRATION O-RING	8-14-3	TD 8-14-3	1	
21 TACHOMETER ANTI-VIBRATION ORGANELT	8-15-4	TD 1149	1	
22 TACHOMETER ANTI-VIBRATION ORGANELT	8-15-5	TD 1141	1	
23 TACHOMETER FLEXIBLE DRIVE	8-3-4	TD 95	1	6" LENGTH
24 GAUGE (OIL PRESSURE/OIL TEMP)	8-9-9	TD 68	1	6ft CAPILLARY
25 OIL PRESSURE LINE ASSEMBLY				
COMPRISES:				
26 UNION	3-30-7	702-13-08	1	1" BSP 90°
27 HOSE LEGAL GAUGE LINES	8-8-5	TD 542	30"	NYLON
28 UNION	3-30-7	702-13-08	1	1" BSP 90°
29 GAUGE (FUEL PRESSURE/WATER TEMP)	8-9-9	TD 68	1	6ft CAPILLARY
30 FUEL PRESSURE LINE ASSEMBLY				
COMPRISES:				
31 UNION	3-30-7	702-13-08	1	1" BSP 90°
32 HOSE	8-8-5	TD 542	30"	
33 UNION	3-30-7	702-13-08	1	1" BSP 90°
34 THROTTLE CABLE	8-22-6	TD 8-22-6	1	2-12m
35 THROTTLE CABLE CLAMP	8-1-14	TD 8-1-14	2	
36 REAR BULKHEAD WASHER	3-57-2	782-01-149	2	
37 EXHAUST TAILPIPE (REF ONLY)	24-3-3	TD 24-3-1	1	PART OF 24-3-
38 THROTTLE CLAMP SPACER - FRONT	3-36-14	772-01-06	1	
39 " " " " - REAR			1	

Issue	Signature	Date

SECTION

Item	Part No	DRG No.	No. Off	Detail
ADAPTOR PLATE	4-74-11			

TRANSMISSION - 793

SHEET 1 OF 2

TRANSMISSION

Issue	Signature	Date
1	S.B.	10-17

SECTION G31

Item	Part No	DRG No.	No. Off	Detail
1				
2				
3				
4				
5				
7				
8				
9				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				

Issue	Signature	Date

SECTION

Item	TRANSITION	Part No	FIG No.	No. of	Detail
REAR BRACE DISC		7-11-3	768-16-01	2	
HOOKE'S JOINT INNER			762-16-05	2	
DRIVE SHAFT CIRCLIP OUTER		23-8-5	4013-5-5	2	1700-32
DRIVE SHAFT			795-10-01	2	
CENTRAL CROSS					
HOOKE'S JOINT OUTER			762-10-03	2	
THRUST RINGS			762-10-04	2	

TRANSMISSION - 793

SHEET 2 OF 2

Issue	Signature	Date
1	Sch	11 OCT 73
2	Sch	7 NOV 73

SECTION G 31

Item	Part No	DRG No.	No. Off	Detail
24 DRIVESHAFT INNER CIRCLIP	8-1-9	TD 184	1	1700-10"
25 DRIVESHAFT	4-20-8	700-10-02	1	
26 DRIVESHAFT OUTER CIRCLIP	8-1-8	TD 180	1	1000-12"
27 CONSTANT VELOCITY JOINT GAITER	14-1-5	TD 182	1	
28 CONSTANT VELOCITY JOINT GAITER CLIP	28-3-11	TD 937	1	No. 4 SIZE
29 CONSTANT VELOCITY JOINT HORN	14-1-1	742-10-03	1	(100 AC JOINT)
30 <del>CONSTANT VELOCITY JOINT HORN</del> <b>HOOKS</b>	14-1-3	TD 182	1	(100 AC JOINT)
31 CONSTANT VELOCITY JOINT GASKET	14-1-2	TD 181	0	(100 AC JOINT)
32 <del>CONSTANT VELOCITY JOINT BALL</del> <b>JOINT</b>	14-1-4	711-10-10	1	(100 AC JOINT)
33 CONSTANT VELOCITY JOINT INNER TRACE	4-75-12	702-07-01	1	5.87" LONG
34 WHEEL RETAINING STOP				
35 FRONT GEAR ROF	3-27-7	788-11-01	1	
36 REAR GEAR ROF	3-27-10	793-11-01	1	
37 CLUTCH PUSH ROD STOP	3-60-15	793-16-01	1	

# OIL SYSTEM - 793 (TOYOTA)

OIL SYSTEM.

Issue	Signature	Date
1	S.P.	16.01.78
2	S.P.	30.07.78
3		

SECTION H 39

Item	Part No	DRG No.	No. Off	Detail
1	OIL TANK ASSEMBLY COMPRISES:			
2	3-20-14	793-14-01	1	
3	3-20-15	793-14-01		
4	8-21-7	TD8-21-7	1	R3225
5	3-58-6	798-14-01	1	
6	<i>Regular Plastic</i>			
7	20-3-10	TD20-3-10	1	1" BSP
8	4-33-3	762-14-04	1	
9	20-3-10	TD20-3-10	1	1" BSP
10	4-20-1	722-18-11	1	
11	8-8-9	TD70	1	
12	4-73-4	783-16-05	1	
13	4-71-8	783-14-02	1	-12x $\frac{1}{2}$ BSP
14	20-3-5	TD1027	1	$\frac{1}{2}$ " BSP
15	4-71-14	783-14-03	1	-12x $\frac{1}{2}$ BSP
16	20-3-5	TD1027	1	$\frac{1}{2}$ " BSP
17	OIL FILTER ASSEMBLY COMPRISES:			
18	8-7-3	TD75	1	
19	8-20-5	TD8-20-5	1	
20	4-71-11	78B-14-02	2	-12x $\frac{1}{2}$ BSP
21	20-3-5	TD1027	2	$\frac{1}{2}$ " BSP DOWTY
22	4-8-10	753-12-03	1	-12 x 20 mm.
23	8-20-14	TD8-20-14	18"	$\frac{5}{8}$ " I/D RUBBER
24	4-71-11	78B-14-02	1	-12x $\frac{1}{2}$ BSP
25	20-3-5	TD1027	1	$\frac{1}{2}$ " BSP
27	8-7-15	TD741	36"	$\frac{1}{8}$ " ID PLASTIC
28	8-7-15	TD741	36"	$\frac{1}{8}$ " ID PLASTIC
29	8-22-9	TD8-22-9	1	
30	21-2-12	TD295	6FT	
31	21-2-1	TD302	1	
32	21-2-2	TD304	2	
33	21-2-3	TD316	4	
34	23-3-13	TD23-3-13	2	MINOX NOO
35	3-66-3		1	
36	8-22-10	TD8-22-10	1	
37			1	

# WATER SYSTEM - 793 (TOYOTA)

SHEET 1 OF 1

## WATER SYSTEM

Issue	Signature	Date
1	SAB	15 NOV 78
2		

### SECTION I 41

No.	Item	Part No	DRG No.	No. Off	Detail
1	RADIATOR	27-4-9	793-13-01	1	
2	RADIATOR STONEGUARD	2-10-10	783-13-03	1	
3	RADIATOR RETAINING BAND	8-21-3	TDS-21-3	2	
4	SWIRL POT	3-29-13	793-13-03	1	
5	HEADER TANK CAP	8-6-11	TD72	1	
6	HEADER TANK OVERFLOW PIPE	8-12-8	TD742	30"	5/16" ID PLASTIC
7	WATER PIPE - SIDE - RH	3-42-5	782-13-04	1	
8	WATER PIPE - FRONT	3-28-15	PATTERN	2	
9	WATER PIPE - REAR - LH			1	
10	WATER PIPE - REAR - RH			1	
11	AVIMO RUBBER - 1 1/4"	8-13-6	TDS-13-6	2	
12	AVIMO PACKING - 1 1/4"	8-13-7	TDS-13-7	4	
13	WATER PIPE - SIDE - LH			1	
14	ENGINE OUTLET ELBOW			1	
15	HEADER TANK			1	
16	HEADER TANK BRACKET	3-24-12	793-01-24	1	


FUEL SYSTEM - 793

SHEET 1 OF 1

FUEL SYSTEM		
Issue	Signature	Date
1	Sub	22 Nov 78
2		

SECTION J41

Item	Part No	DRG No.	No. Off	Detail
1 FUEL TANK	17-3-4	783-15-04	1	
2 <del>COLLECTOR PCT</del>	3-57-15	79B-15-01	1	
3 FILTER	8-17-11	TD8-17-11	1	
4 <del>FUEL PUMP INLET END CAP</del>	4-13-6	752-15-04	1	- 8
5 FUEL PUMP (CHARGED EXTRA TO CUSTOMER)	8-16-8	TD8-16-8	1	BOSCH
6 FUEL PUMP MOUNTING BRACKET	3-19-12	753-15-14	1	
7 FUEL PUMP OUTLET ADAPTOR	4-71-9	782-15-05	1	- 6/11.85mm
8 METERING UNIT FILTER HOUSING	4-71-15	783-15-03	1	
9 METERING UNIT FILTER ELEMENT	4-76-13	783-15-05	1	
10 METERING UNIT OUTLET ADAPTOR	4-10-6	755-13-14	1	1/8" BSP WELD-ON
11 FUEL FILLER	3-60-6	79B-15-02	1	
12 FUEL FILLER CAP	4-20-1	722-18-11	1	
13 FUEL FILLER CAP 'O' RING	8-8-9	TD70	1	
14 FUEL FILLER RUBBER HOSE	8-4-8	TD755	4"	1 1/2" I.D.
15 PUMP-OUT ADAPTOR	4-80-1	782-15-06	1	
16 PUMP-OUT BLANKING CAP	4-33-5	783-15-11	1	
17 ADAPTOR LOCK NUT	4-13-1	752-17-02	1	
18 FUEL BREATHER VALVE	4-33-8	763-15-02	1	
COMPRISES:				
19 BOTTOM	4-37-6	753-15-05	1	
20 TOP	4-33-9	763-15-01	1	
21 BALL	8-4-13	TD287	1	
22 AEROQUIP -6 HOSE	21-2-9	TD292	50"	
23 AEROQUIP -6 STRAIGHT UNION	21-1-7	TD299	1	
24 AEROQUIP -6 45° UNION	21-1-8	TD306	1	
25 AEROQUIP -8 HOSE	21-2-10	TD293	12"	
26 AEROQUIP -8 UNION	21-1-10	TD300	1	
27 NYLON HOSE - 5/32" I.D.	8-8-5	TD542	50"	
28 1/8" BSP 90° UNION	3-30-7		2	
29 TEEPLAS HOSE - 3/8" I.D.	8-10-7	TD8-10-7	120"	



Issue	Signature	Date

SECTION

Item	Part No	DRG No.	No. Off	Detail
FUEL TANK		203-	1	
FUEL FILTER				
FUEL FILTER HOUSING CAP				
FUEL FILTER HOUSING				

SPHERICAL JOINTS.

SPHERICAL JOINTS - 792

Issue	Signature	Date
2		
3		
4		

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1 FRONT TOP ROCKER OUTER	15-3-14	TD 15-3-14	2	BSTWR 07B
2 FRONT BOTTOM WISHBONE OUTER	15-3-15	TD 15-3-15	2	BC 10H
3 TRACK ROD OUTER	15-3-2	TD 15-3-2	2	RMR 5 UF
4 TRACK ROD INNER	15-3-3	TD 15-3-3	2	RMR 5 UF
5 F.A.R.B. LINE (TOP)	15-1-11	TD 49	2	RMP 5 U
6 F.A.R.B. LINE (BOTTOM)	15-3-5	TD 15-3-5	2	RMLP 5 U
7 R.A.R.B. LINE (TOP)	15-3-5	TD 15-3-5	2	RMLP 5 U
8 R.A.R.B. LINE (BOTTOM)	15-1-13	TD 51	2	RC 6 H
9 TOP LINK INNER	15-3-10	TD 15-3-10	2	RCL 6 E
10 TOP LINK OUTER	15-1-14	TD 52	2	BC 6 E
11 TRACK CONTROL ARM OUTER	15-2-1	TD 54	2	RC 8 H
12 TRACK CONTROL ARM INNER	15-3-10	TD 15-3-10	2	RCL 6 E
13 R.L.W.B. OUTER	15-2-3	TD 56	2	BSTWR 08E
14 GEAR LEVER LOCATION BEARING	15-2-12	TD 1013	2	EBJ 6TU
15 GEAR LINKAGE MID. SUPPORT (SIDEFRAME)	15-2-2	TD 55	1	RMP 8 U
16 THROTTLE CABLE TO PEDAL JOINT	15-2-7	TD 15-2-7	1	RF 3U
17 MIRROR MOUNT	4-73-11	782-12-25	2	RMP 4U - MOD
18 RADIUS ROD (LEFT)	15-3-12	TD 15-3-12	2	RCL 6 H
19 RADIUS ROD (RIGHT)	15-1-13	TD 51	2	BC 6 H
20 C.S.D.U. ROD	15-3-8	TD 15-3-8	4	RC 6 F
21 GEAR LINKAGE SUPPORT (REAR PLATE)	15-2-14	TD 1011	1	RAC 8

SPHERICAL JOINTS

803 805V

Issue	Signature	Date

SECTION

Item	Part No	DRG No.	No. Off	Detail
FRONT TOP LOCKER OUTER			2	RBFBB
FRONT BTM WISHBONE OUTER				SPECIAL
TRACK ROD OUTER	15-3-3	TD 15-3-3	2	RMR 50F
TRACK ROD INNER	15-3-2	TD-15-3-2	2	RMR 50F
FARB LINK (TOP)	15-1-11	TD 49	2	RMP5U
" LINK (BTM)	15-3-5	TD 15-3-5	2	RMP5U
RARB LINK (TOP)	15-1-11	TD 49	2	RMP5U
" LINK (BTM)	15-3-5	TD 15-3-5	2	RMP5U
TOP LINK INNER	15-3-9		2	RCL 7
TOP LINK OUTER	15-1-14	TD 52	2	RC6E
RADIUS ARM	15-1-13	TD 51	4	RC6H
RADIUS ARM	15-3-12	TD 15-3-12	4	RCL6H
RWBUB INNER	15-2-3	TD 56	2	RWR 08E
" OUTER FRONT	15-2-1	TD 54	2	RC 8H
" OUTER REAR	15-2-4	TD 57	2	RC 8
GEAR LEVER LOCATION BEARING	15-2-12	TD 1015	2	RBJ 57U
GEAR LINKAGE MID. SUPP	15-2-2	TD 55	1	RMP5U
THROTTLE CABLE TO PEDAL	15-2-7	TD 15-2-7	1	RFSU
mirror ?	4-73-11	762-12-25	2	RMP4U (MOD)

HYDRAULICS - 793

\* OK.

SHEET 1 OF 2

HYDRAULICS.

Issue	Signature	Date
1	LAB	22 NOV 7

SECTION L28

Item	Part No	DRG No.	No. Off	Detail
FRONT BRAKES				
1	PUSH ROD	7-1-7	TD7-1-7	1
2	MASTER CYLINDER	7-3-14	TD1078	1 0.75" SIZE
3	MASTER CYLINDER RESEVOIR	7-3-13	TD1120	1
4	RESERVOIR SEAL	20-3-7	TD20-3-7	1 7/16" I/D DOWN
5	BANJO BOLT	7-3-8	TD690	1
6	BANJO	7-3-5	TD591	1 2 WAY 90°
7	BANJO ADAPTOR	4-8-7	732-06-18	1 1/8" BSP/3/8" UNF
8	BANJO OUTLET UNION	21-1-3	TD701	2 -3 90°
9	HOSE-MASTER CYLINDER TO CALIPERS	21-2-7	TD290	54" -3 AEROQUIP
10	CALIPER INLET UNION	21-1-1	TD697	2 -3 STRAIGHT
11	CALIPER INLET ADAPTOR	4-8-7	732-06-18	2 1/8" BSP/3/8" UNF
*	CALIPER	7-2-8	TD111	2
12	CALIPER SPACER	4-24-9	753-06-02	4
*	BRAKE PAD	7-2-8	TD726	4
REAR BRAKES				
15	PUSH ROD	7-1-7	TD7-1-7	1
16	MASTER CYLINDER	7-3-14	TD1078	1 0.75" SIZE
17	MASTER CYLINDER RESERVOIR	7-3-13	TD1120	1
18	RESERVOIR SEAL	20-3-7	TD20-3-7	1 7/16" I/D DOWN
19	MASTER CYLINDER ADAPTOR	4-8-7	732-06-18	1 1/8" BSP/3/8" UNF
20	AEROQUIP -3 HOSE	21-2-7	TD290	12FT
21	AEROQUIP -3 90° UNION	21-1-3	TD701	4
*	CALIPER	7-2-2	TD108	2
*	BRAKE PAD	7-2-9	TD277	4
24	CALIPER MOUNTING BLOCK	4-53-7	773-19-01	2
25	CALIPER ADAPTOR	4-8-7	732-06-18	3 1/8" BSP/3/8" UNF
26	CALIPER MOUNTING BOLT	12-1-11	722-10-03	4
CLUTCH				
27	PUSH ROD	7-1-7	TD7-1-7	1
28	MASTER CYLINDER	7-3-14	TD1078	1 0.75" SIZE
29	MASTER CYLINDER RESERVOIR	7-3-13	TD1120	1
30	RESERVOIR SEAL	20-3-7	TD20-3-7	1 7/16" I/D DOWN
31	MASTER CYLINDER ADAPTOR	4-8-8	722-18-09	1 1/8" BSP/3/8" UNF
32	AEROQUIP -4 HOSE	21-2-8	TD291	10FT
33	AEROQUIP -4 STRAIGHT UNION	21-1-4	TD698	1

Issue	Signature	Date

SECTION

Item	Part No	DRG No.	No. Off	Detail
<u>HYDRAULICS</u>				
CALIPER (FRONT)	7-2-3	TD 111	2	
BRAKE PAD	7-2-8	TD 726	4	
CALIPER (REAR)	7-2-2	TD 108	2	
BRAKE PAD	7-2-9	TD 277	4	
<u>FRONT BRAKES</u>				
PUSH ROD	7-1-7	TD 7-1-7	1	
MASTER CYLINDER	7-3-14	TD 1078	1	0.75" $\phi$
MASTER CYLINDER RESERVOIR	7-3-13	TD 1120	1	REMOTE RESERVOIR LINE
RESERVOIR SEAL	20-3-7	TD 20-3-7	1	3/16" ID HOLES
BANJO BOLT	7-3-8	TD 690	1	
BANJO	7-3-5	TD 691	1	2 WAY 90°
BANJO ADAPT	4-8-7	732-06-18	1	1/2 BSP / 3/8 UNF
BANJO OUTLET UNION	21-1-3	TD 701	2	-3 90°
HOSE - MASTER CYL TO CALIPERS	21-2-7	TD 290		-3 AEROPUMP
CALIPER INLET UNION	21-1-1	TD 697	2	-3 STRAIGHT
CALIPER INLET ADAPTOR	4-8-7	732-06-18	2	1/2 BSP / 3/8 UNF
<u>REAR BRAKES</u>				
PUSH ROD	7-1-7	TD 7-1-7	1	
MASTER CYL	7-3-14	TD 1078	1	0.75" $\phi$
MASTER CYL RESERVOIR	7-3-13	TD 1120	1	REMOTE RESERVOIR LINE
RESERVOIR SEAL	20-3-7	TD 20-3-7	1	3/16" ID HOLES
MASTER CYL ADAPT	4-8-7	732-06-18	1	1/2 BSP / 3/8 UNF
AEROPUMP -3 HOSE	21-2-7	TD 290		
" -3 90° UNION	21-1-3	TD 701	4	
CALIPER MTB BLOCK	4-8-7	773-19-01	2	
CALIPER ADAPTOR	4-8-7	732-06-18	3	1/2 BSP / 3/8 UNF
CALIPER MOUNTING BOLT	12-1-11	722-10-06	4	
<u>CLUTCH</u>				
MASTER CYLINDER DISAPPEARING	7-7-12		3	1/2 BSP / 3/8 UNF

HYDRAULICS - 793

SHEET 2 OF 2

Issue	Signature	Date
	SOB	21 NO

SECTION L 28

	Item	Part No	DRG No.	No. Off	Detail
34	AEROQUIP -4 90° UNION	21-1-6	TD702	1	
35	SLAVE CYLINDER INLET ADAPTOR	4-8-8	722-18-08	1	1" BSP / 3/8" UNF
36	COPPER WASHER 3/8" I.D. THIN	20-2-14	TD689	A.R.	
37	COPPER WASHER 3/8" I.D. THICK	20-2-13	TD952	A.R.	
38	COPPER WASHER 7/16" I.D. THIN	20-4-3	TD688	A.R.	
80	HYDRAULIC LINE SUPPORT	3-31-5	762-16-30	1	

ELECTRICS - 793

SHEET 1 OF 1

ELECTRICS

Issue	Signature	Date
1		

SECTION M 28

Item	Part No	DRG No.	No. Off	Detail
1 <del>BATTERY</del>	8-3-11	TD124	1	
2 BATTERY LEAD	8-5-3	TD226	20"	FEPSIL 2
3 BATTERY LEAD TERMINAL (1/2")	9-3-6	TD1104	1	
4 BATTERY LEAD TERMINAL (5/16")	9-3-7	TD1105	4	
5 BATTERY LEAD TERMINAL (3/8")	9-3-8	TD1106	1	
6 BATTERY LEAD TERMINAL COVER	9-3-14	TD915	4	
7 <del>MASTER SWITCH</del>	9-1-15	TD428	1	
8 <del>MASTER SWITCH BRACKET</del>	3-23-6	762-01-74	1	
9 <del>MASTER SWITCH BRACKET GROMMET</del>	8-15-12	TD8-15-12	2	1/2"x9/16"x1/16"
10 <del>MASTER SWITCH BRACKET SPACER</del>	8-20-7	785-01-05	2	
11 <del>MASTER SWITCH SHAFT</del>	4-76-12	782-01-35	1	
12 <del>MASTER SWITCH ENOP</del>	9-5-3	TD428	1	
13 <del>MASTER SWITCH LEVER</del>	3-51-11	782-01-33	1	
14 <del>FIRE PULL CLEVIS</del>	3-51-8	TD3-51-8	1	
15 <del>FIRE PULL CLEVIS PIN</del>	8-2-7	TD36	1	
16 <del>FIRE PULL HANDLE</del>	3-48-10	782-22-01	1	
17 FIRE EXTINGUISHER FIRING BUTTON	9-1-2	TD274	2	
18 FIRE EXTINGUISHER MASTER SWITCH	9-1-12	TD426	1	
19 FUEL PUMP SWITCH	9-1-12	TD426	1	
20 IGNITION SWITCH	9-1-12	TD426	1	
21 REAR LIGHT SWITCH	9-1-12	TD426	1	
22 HILL SWITCH (STEERING WHEEL)	9-1-12	TD426	1	
23 STARTER BUTTON SWITCH	9-1-2	TD274	1	
24 REAR LIGHT	9-9-7		1	
25 REAR LIGHT RUBBER MOUNTING BUSH	8-20-4	TD8-20-4	2	
26 WIRING LOOM			1	
27 SPARK BOX	3-62-2	793-28-02	1	
28 SPARK BOX BASE <i>79C</i>			1	
29 SPARK BOX MOUNT	3-62-1	793-28-01	1	

Issue	Signature	Date

SECTION

Item	ELECTRICALS 793	Part No	DRG No.	No. Off	Detail
BATTERY LEAD		8-5-3	TD626	<del>2</del>	FEP512
" LEAD TERMINAL (1/4")		9-3-6	TD1104	1	CHECK AMOUNT
" " " (3/16)		9-3-7	TD1105	4	" "
" " " (3/8)		9-3-8	TD1106	1	" "
" " " COVER		9-3-14	TD915	4	
FIRE EXT FIRING BUTTON		9-1-2	TD274	1	
" " MASTER SWITCH		9-1-12	TD426	1	
FUEL PUMP SWITCH		9-1-12	TD426	1	
IGNITION SWITCH		9-1-12	TD426	1	
REAR LIGHT SWITCH		9-1-12	TD426	1	
KILL SWITCH (STEERING WHEEL)		9-1-12	TD426	1	
STARTER BUTTON		9-1-2	TD274	1	
REAR LIGHT		9-9-7		1	
" " RUBBER NTC BUSH		8-20-A	TD8-20-A	2	
WIRING LOOM					
SPARK BOX					

Issue	Signature
2	K. S. ...
3	...

Item	SECTION		No. Off	Detail		
	Part No	DRG No.				
1	<u>MONOCOQUE ASSEMBLY</u>		38-1-8	792-01-42	1	
	- COMPRISES OF CASTINGS AND SUB ASSEMBLIES					
2	FRONT BULKHEAD	45-11-1	792-01-14	1		
3	M.F.B.H. - R.H.	4-84-10	792-01-12	1		
4	" - L.H.	4-84-11	792-01-13	1		
5	FRONT CRASH HOOP	45-10-13	792-01-58	1		
6	REAR CRASH HOOP	3-59-15	792-01-17	1		
7	FRONT BULKHEAD BEAM	4-85-8	792-01-18	1		
8	REAR BULKHEAD - R.H.	4-84-12	792-01-10	1		
9	REAR BULKHEAD - L.H.	4-84-13	792-01-11	1		
10	OIL TANK MOUNT R.H.	3-60-12	792-01-66	1		
11	" " " L.H.	3-60-13	792-01-67	1		
12	ACC ESS CLOSURE PLATE	3-61-3	792-01-77	2		
13	TUB STIFFENER R.H.	3-62-10	792-01-96	1		
14	TUB STIFFENER L.H.	3-62-11	792-01-97	1		
15	DASH PANEL	3-48-4	782-01-21	1		
16	DASH PANEL MOUNTING RUBBER	8-20-4	TD 8-20-4	3		
17	FRONT SKID	4-87-6	792-01-84	2		
18	REAR SKID	4-83-11	782-01-150	2		
19	STEERING WHEEL	8-1-3	742-04-02	1		
20	STEERING WHEEL RETAINING WASHER	4-2-4	712-04-07	1		
21	STEERING WHEEL RIVET (STEEL)	8-1-4	TD 7	3		
22	STEERING COLUMN	3-59-10	792-04-09	1		
23	STEERING COLUMN SUPPORT	4-2-2	732-05-05	1		
24	STEERING RACK CLAMP	4-77-15	792-04-01	2		
25	<u>GEAR LEVER ASSEMBLY</u>		782-11-07	1		
	<u>COMPRISES:</u>					
26	GEAR LEVER	49-1-2	782-11-08	1		
27	GEAR LEVER BADGE	8-6-10	752-11-05	1		
28	GEAR CHANGE BRACKET		792-11-01	1		
29	GEAR LEVER PIVOT	4-5-2	712-11-10	1		
30	GEAR LEVER SPACER	4-27-3	762-11-06	2		
31	GEAR SHAFT	4-76-5	782-11-04	1		
32	GEAR ROD MOUNTING	49-1-1	782-11-05	1		
33	GEAR CHANGE BODY	4-79-1	782-11-03	1		
34	GEAR CHANGE BEARING LINE	4-77-1	782-11-06	1		

Issue	Signature	Date

SECTION

Item	Part No	DRG No.	No. Off	Detail
MONOCOQUE ASSY		803-01-52	1	
DASH PANEL				
" " MTC TUBER	3-48-4	782-01-21	1	
FRONT SKID	3-20-4	70-8-20-4	3	
REAR SKID	4-87-6	792-01-84	2	
STEERING WHEEL		803-01-33	2	CHECK
" " RETAINING WASHER	8-1-3	742-04-02	1	
" " RIVET (STEEL)	4-2-4	712-04-07	1	
" " RIVET (STEEL)	8-1-4	TD7	3	
STEERING COLUMN	3-59-10	792-04-09	1	
" " SUPPORT	4-2-2	732-05-05	1	
STEERING RACK CLAMP	4-77-15	792-04-01	2	CHECK DEPTH
GEAR LEVER ASSY				
GEAR LEVER	49-1-2	782-11-08	1	
GEAR LEVER BADGE	8-6-10	752-11-05	1	
GEAR CHANGE BRACKET			1	
GEAR LEVER PIVOT	4-5-2	712-11-10	1	
GEAR LEVER SPACER	4-27-3	782-11-06	1	
GEAR SHAFT	4-76-5	782-11-04	1	
GEAR ROD MOUNTING	49-1-1	782-11-05	1	
GEAR CHANGE BODY			1	EXTRUSION
GEAR CHANGE RETURNING LINK				
CHASSIS PLATE	5-4-4	732-01-48	1	
LEFT FOOT REST	3-04-3	782-01-54	1	
FRONT SUSPENSION EAR (PLATE)				
FRONT SUSPENSION EAR (CAST)		DRG NO		
F.B.U.B. D.B. PLATE		803-01-28	2	CANALS
THROTTLE CABLE BKT FRONT	3-62-5	792-01-87	1	
SEAT BKT	8-1-11	TD10	1	
SEAT BKT PLATE - DOGGLED	2-1-2	722-01-75	2	
" " BACKING PLATE	3-48-14	782-01-08	2	
THROTTLE CABLE BKT REAR				
NOSE FRAME MTC BKT (TOP) L/H				
" " " " " " R/H				
NOSE FRAME MTC BKT (Btm)	3-38-12	792-01-80		
" " " " " " SPACER	41-54-3	792-20-48		
PEDAL STOPS SUPPORT	3-63-12	792-01-153		
SEAT BKT TOP MTC BKT	3-63-10	792-01-152		
" " " " " " SPACER	41-53-14	792-20-44		
" " " " " " 2DA BOLT				

Issue	Signature	Da
2	R. Santiago	25-
3	R. Santiago	...
4	R. Santiago	...

		SECTION			
Item	Part No	DRG No.	No. Off	Detail	
35	PONTOON CLOSURE PLATE	3-62-12	792-01-121	2	
36	CHASSIS PLATE	8-4-4	732-01-48	1	
37	LEFT FOOT REST	3-49-3	782-01-54	1	
38	F.T.W.B. STEEL EAR	3-59-9	792-01-43	2	
39	FRONT SUSPENSION EAR L.H.	4-85-9	792-01-15	1	
40	" " " R.H.	4-85-10	792-01-16	1	
41	F.B.W.B. D.S. PLATE	3-60-14	792-01-68	2	
42	FUEL TANK BAY CRUSHABLE (BOTTOM)			1	
43	THROTTLE CABLE CLAMP BRACKET (FRONT)	3-62-5	792-01-87	1	
44	<u>FIRE EXTINGUISHING SYSTEM</u>	29-3-11	TD 29-3-11	1	
	<u>COMPRIZES:</u>				
45	5 KG. BOTTLE, HEAD	29-3-15	TD 29-3-15	1	
46	5 KG. BOTTLE BRACKET & STRAPS	29-4-2	TD 29-4-2	1	
47	PURPLE FLEXIBLE PIPE	29-4-5	TD 29-4-5	1	
48	COCKPIT NOZZLE	4-44-4	763-22-01	1	
49	COCKPIT NOZZLE LOCKNUT	13-7-1	763-22-02	1	
50	2.5 KG. BOTTLE & HEAD & STRAPS	29-4-1	TD 29-4-1	1	
51	2.5 KG. BOTTLE BRACKET	3-63-1	792-01-122	1	
52	PIPE 2.5 KG BOTTLE TO REAR B.H.	7-8-4	TD 7-8-4	5	
53	LIFE SUPPORT BOTTLE & STRAPS	29-3-14	TD 29-3-14	1	
54	LIFE SUPPORT BOTTLE BRACKET	3-62-4	793-01-20	1	
55	LIFE SUPPORT TUBE	29-3-9	TD 29-3-9	3	
56	BATTERY POWER PACK	29-4-4	TD 29-4-4	1	
57	SEAT BELT	8-1-11	TD 10	1	(MODIFIED)
58	SEAT BELT PLATE-JOGGLED	2-1-2	722-01-75	2	
59	SEAT BELT BACKING PLATE	3-48-14	782-01-48	2	
60	GEAR SHIFT SUPPORT	3-62-14	792-01-88	1	
61	THROTTLE CABLE BRACKET (REAR)	3-62-6	792-01-88	1	
62	NOSE, NOSE FRAME MOUNTING R.H.	3-62-14	792-01-94	1	
63	" " " " L.H.	3-62-13	792-01-93	1	
64	NOSE FRAME MOUNTING SPACER LONG	41-34-2	792-20-47	2	
65	" " " " SHORT	41-34-1	792-20-46	2	
66	NOSE FRAME SUPPORT BRACKET	3-38-12	792-01-80	2	
67	" " " " SPACER	41-34-3	792-20-48	2	
68	PEDAL STOPS SUPPORT	3-63-12	792-01-33	1	

Issue	Signature	Date
1	L.S. [unclear]	[unclear]

MONOCOQUE - 792

Sheet 3 of 3

		SECTION		
Item	Part No	DRG No.	No. Off	Detail
69	SEAT BELT TOP MOUNTING	3-63-10	792-01-132	4
70	" " " " SPACER	41-33-14	792-20-44	2
71	FUEL TANK BAY CRUSHABLE - SIDE L.H.			1
72	" " " " " R.H.			1
73	PONTOON CRUSHABLE R.H.			1
74	" " L.H.			1
75	TUB FLOOR STIFFENER	3-62-15	792-01-124	1
76	GEAR SHIFT SUPPORT CIRCLIP	23-5-2	TD 23-5-2	2

FR. Susp.

## FRONT SUSPENSION - 792

SHEET 1 of 2

Issue	Signature	Date

## SECTION B 25

Item	Part No	DRG No.	No. Off	Detail
1	FRONT ROCKER	32-4-5	792-02-05	2
2	ROCKER OUTER JOINT INSERT	4-63-8	792-02-02	4
3	" " " CIRCLIP	23-5-12	TD 23-5-12	2
4	" THRUST WASHER	41-32-13	792-20-28	4
5	" BUSH	44-1-8	792-19-01	4
6	" JOURNAL	4-63-7	792-02-16	2
7	" THROUGH BOLT	12-24-7	792-02-15	2
8	" /F.A.R.B. BOLT	4-63-9	792-02-10	2
9	" /DAMPER INSERT - MALE	4-63-10	792-02-13	2
10	" / " " - FEMALE	4-63-11	792-02-14	2
11	" / " " BOLT	12-14-3	792-02-09	2
12	F.B.W.B.	32-4-3	792-02-06	2
13	" THRUST WASHER	4-2-6	722-02-08	16
14	" BUSH	4-6-12	726-02-08	8
15	" SHIM	41-31-4	792-20-04	2
16	" LONG SPACER	41-31-3	792-20-03	2
17	" JOURNAL	4-2-5	732-02-07	4
18	" THROUGH BOLT	4-80-14	792-02-17	2
19	"			
	<u>STEERING RACK ASSEMBLY COMPRISES:</u>			1
20	RACK	4-63-12	792-04-03	1
21	HOUSING	4-63-13	792-04-04	1
22	PINION	8-23-2	TD 8-23-2	1
23	PINION BEARING	8-1-6	TD 28	2
24	PINION BEARING SHIM	8-17-5	TD 8-17-5	A.B.
25	" " CLAMP RING	4-45-11	712-04-24	1
26	END PLATE	8-17-4	TD 8-17-4	1
27	" " CIRCLIP	8-17-3	TD 8-17-3	1
28	SPRING	4-4-9	712-04-21	1
29	" STOP	4-4-10	712-04-22	1
30	" RETAINER	4-4-11	712-04-23	1
31	TENSION CAP	4-4-8	712-04-19	1
32	OILITE BUSH	8-18-5	TD 8-18-5	2
33	SEAL	8-9-6-	TD 1022	2
34	PINION SEAL (J. K. 6000 42C)			

72-01-28

(722-02-12)

7 TOOTH

Issue	Signature	I

SECTION

Item	Part No	DRG No.	No. Off	Detail
FRONT ROCKER L/H		803-02-09	1	
" " R/H		803-02-08	1	
ROCKER THRUST WASHER	41-32-13	792-20-28	4	
ROCKER JOURNAL	4-63-7	792-02-16	2	
ROCKER THRO. BOLT	12-24-7	792-02-15	2	
ROCKER / FARB BOLT		803-02-10	2	
DAMPER TOP SPACER		803-02-11	4	
F. B. W. B.		803-02-02	2	
" THRUST WASHER	4-2-6	712-02-08	8	
" BUSH	4-6-12	712-02-08	8	
" SHIM		802-20-01	4	
" SPACER		803-02-03	2	
" JOURNAL	4-2-5	732-02-07	4	
STEERING SHOCK ASSY.				
RACK		803-04-01	1	
HOUSING	4-63-13	792-04-24	1	} 6 TOOTH
PINION				
PINION BEARING	8-1-6	TD 28	2	
PINION BEARING SHIM	8-17-5	TD 8-17-5	AS REQ	
PINION BEARING CLAMP RING	4-45-A	712-04-24	1	
END PLATE	8-17-4	TD 8-17-4	1	
END PLATE CIRCUIT	8-17-3	TD 8-17-3	1	
SPRING	4-4-9	712-04-21	1	
SPRING STOP	4-4-10	712-04-22	1	
SPRING RETAINER	4-4-11	712-04-23	1	
TENSION CAP	4-4-8	712-04-19	1	
OLIVE BUSH	8-18-5	TD 8-18-5	2	
SEAL	8-9-6	TD 1022	2	
PINION SEAL (JK. 6000 92C)				
TRACK ROD		803-04-03	2	
BUMP STOP SPACER (LARGE)		802-20-02	AS REQ	
" " (SMALL)		802-20-03	AS REQ	

FRONT SUSPENSION - 792

SHEET 2 of 2


Issue	Signature
2	R. Sawicki

SECTION B 25

Item	Part No	DRG No.	No. Off	Detail
34 INNER CLEVIS	4-26-2	762-04-06	2	
35 " " LOCK NUT	13-2-14	762-04-07	2	
36 TRACK ROD	3-21-7	792-04-08	2	
37 RACK STOPS	4-35-11	792-04-10	2	
38 BUMP STEER SPACER - LARGE	41-33-1	792-20-31	2	
39 " " " - SMALL	41-33-2	792-20-32	2	
40 F.A.R.B.	40-5-2	792-05-27	1	9/16" O/D x
41 " MOUNTING BLOCK	4-77-13	792-05-22	2	
42 " LINK	4-77-10	792-05-14	2	
43 " ARM	4-77-14	792-05-05	2	
44 F.A.R.B. BLOCK STUD SHORT	4-35-12	792-01-82	2	
45 " " " LONG	4-35-13	792-01-83	2	
46 FRONT SPRING (300 lb)	16- - - 1	TD 16- - - 1	2	6" LONG
47 FRONT DAMPER	16-2-11	TD 16-2-11	2	KONI 1401
48 FRONT DAMPER INSERT (BOTTOM)	4-2-12	712-02-09	4	
49 F.A.R.B. ARM JOINT SPACER	41-33-8	792-20-38	4	
50 FRONT TOP ROCKER SPACER	41-33-9	792-20-39	2	
51 FRONT DAMPER CUT DOWN SOFT AEON			2	

Issue	Signature

SECTION

Item	Part No	DRG No.	No. Off	Detail
F.A.R.B. Re-RATED	792-05-18			
" MOUNTING BLOCK	4-77-13	792-05-22		
" LINK				
" ARM	4-77-14	792-05-05		
F.A.R.B. BLOCK STUD SHORT	4-35-12	792-01-82		
" " " LONG	4-35-13	792-01-83		
FRONT SPRING				6/20/76
FRONT DAMPER				
FRONT DAMPER INSERT			B	
FARB ALM JOINT SPACER				

16

REAR SUSPENSION - 793

SHEET 1 OF 1

Issue	Signature	Date
1	SCB	16 OCT 7
2	SCB	30 OCT 7
3		

SECTION C 29

Item	Part No	DRG No.	No. Off	Detail
1 TOP RADIUS ARM	37-2-3	793-03-05	2	26 3/4" LONG
2 BOTTOM RADIUS ARM	37-2-4	793-03-05	2	23" LONG
3 RADIUS ARM FORWARD SAFETY WASHER	4-15-13	731-18-01	8	
4 DAMPER CLEVIS BOLT	4-63-6	793-03-08	2	
5				
6 TOP LINK	4-77-4	711-03-40	2	5 1/2" LONG
7 " " D.S. PLATE L.H.	3-50-13	793-01-18		
8 REAR BOTTOM WISHBONE	32-2-2	773-02-02	2	
9 RBWB SLEEVE NUT	4-84-2	793-03-02	2	
10 " OUTER FRONT JOINT SPACER	4-82-8	712-03-20	4	
11 RBWB OUTER REAR JOINT SLEEVE	41-2-12	708-16-03x	2	* SHEET 16
12				
13				
14 RBWB INNER JOINT INSERT	4-2-12	712-02-09	4	
15 RBWB INNER JOINT SPACER	4-78-5	783-20-01	2	
16 RBWB INNER JOINT CIRCLIP	6-2-9	TD120	4	1700-31
17 REAR DAMPER	16-2-8	TD16-2-8	2	
18 " " INSERT	4-61-8	771-03-22	4	
19 " " BOTTOM SPACER	4-2-15	712-03-20	2	
20				
21 REAR SPRING	16-9-7	TD16-9-7	2	220-02
22 REAR HELPER SPRING	16-3-10	TD683	2	
23 REAR ANTI-ROLL BAR	40-4-5	793-05-03	1	3/2" O/D x 16 SWG
24 REAR MOUNTING BLOCK	4-84-1	793-05-02	2	
25 REAR CLAMP	1-7-10	708-05-01	2	3/4" ID
26 REAR LINK	4-77-9	782-05-03	2	8" LONG
27 REAR MOUNTING SPACER	41-30-13	708-16-03	4	
28				
29 TOP LINK D.S. PLATE RH	3-50-14	793-01-18	1	

Issue	Signature	Date

SECTION

Item	Part No	DRG No.	No. Off	Detail
TOP RADIUS ARM 1x205MG (CDSZ.)				
BTM RADIUS ARM BUSH FITL?				
RADIUS ARM FORWARD SAFETY WASHED	4-15-13	735-18-01	8	
DAMPEN CLEVIS BOLT	4-63-6	793-03-08	2	
TOP LINK	4-77-4	711-03-04	2	5/4 LG
TOP LINK D.S. PLATE R/H				
" " " " L/H				
REAR BOTTOM WISHBONE	32-2-2	773-03-02	2	
RBWB SLEEVE NUT	4-84-2	793-03-02	2	
" OUTER FRONT JOINT SPACER	4-82-8	712-03-20	4	
" OUTER REAR JOINT SLEEVE	41-2-12	708-16-03	2	SHIT #5
" INNER JOINT INSERT	4-2-12	712-02-09	4	
" INNER JOINT SPACER	4-78-5	783-20-01	2	
" INNER JOINT CIRCLIP ?				
REAR DAMPER	46-2-8	7016-2-8	2	
" " INSERT	4-61-8	771-03-22	4	
" " BTM SPACER	4-2-15	712-03-20	2	
REAR SPRING	16-9-7	706-9-7	2	220-2
REAR RECKER SPRING	46-3-10	70683	2	
REAR ANTI-ROLL BAR				
RARB MOUNTING BLOCK				
RARB CLAMP				
RARB LINK				