

Issue	Signature	Date

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1	<u>MONOCOQUE ASSEMBLY COMPRISES OF CASTINGS AND SUB ASSEMBLIES:</u>		1	
2	FRONT BULKHEAD	45-12-7	803-01-11	1
3	M.F.B.H. R.H.	45-12-6	803-01-08	1
4	" L.H.	45-12-5	803-01-09	1
5	FRONT BOTTOM DAMPER/B.HEAD INSERT	4-96-3	803-01-84	2
6	FRONT BULKHEAD BEAM	4-85-8	792-01-18	1
7	FRONT CRASH HOOP	45-12-8	803-01-29	1
8	" " " DOUBLER L.H.	45-15-5	803-01-47	1
9	" " " " R.H.	45-15-4	803-01-48	1
10	REAR BULKHEAD R.H.	45-12-10	803-01-02	1
11	" " L.H.	45-12-9	803-01-01-	1
12	FRONT TOP PANEL	45-15-3	803-01-10	1
13	INNER SKIN	45-12-11	803-01-03	1
14	OUTER SKIN r.h.	45-12-12	803-01-04	1
15	" " L.H.	45-12-13	803-01-05	1
16	SEAT PANEL UPPER	45-12-14	803-01-27	1
17	REAR TOP PANEL	45-12-15	803-01-17	1
18	FLOOR STIFFENER	3-62-15	792-01-124	1
19	FRONT SUSPENSION EAR	4-98-1	80A-01-08	2
20	FRONT UPPER FUEL TANK PANEL	45-13-1	803-01-14	1
21	STEEL TOWER SIDE R.H.	45-13-2	803-01-30	1
22	" " " L.H.	45-13-3	803-01-31	1
23	REAR PANEL SIDE BRACKET L.H.	45- 13-5	803-01-45	1
24	" " " " R.H.	45-13-4	803;01-46	1
25	PEDAL BRACKET BASE	45-13-6	803-01-52	1
26	FOOT BOX TOP PANEL	45-13-7	803-01-55	1
27	FOOT BOX STIFFENER R.H.	45-14-4	803-01-24	1
28	" " " L.H.	45-14-1	803-01-25	1
29	F.B.H./INNER SKIN BRACKET R.H.	45-13-8	803-01-76	1
30	" " " " L.H.	45-13-9	803-01-77	1
31	REAR CHAMF PANEL R.H.	45-13-12	803-01-80	1
32	" " " L.H.	45-13-13	803-01-81	1
33	SEAT BACK STIFFENER	45-13-14	803-01-62	1
34	" " CORNER STIFFENER L.H.	45-13-15	803-01-63	1
35	" " " " R.H.	45-14-2	803-01-64	1

USA SPEC ONLY

FOR USA CRASH HO

MONOCOQUE CON.

Issue	Signature	Date

MONOCOQUE ASSEMBLY - 80A

Sheet 2 of 3

		<u>SECTION</u>			
	<u>Item</u>	<u>Part No</u>	<u>DRG No.</u>	<u>No. Off</u>	<u>Detail</u>
36	F.B.H. LOWER CORNER ANGLE R.H.	45-13-10	803-01-78	1	
37	" " " " L.H.	45-13-11	803-01-79	1	
38	REAR PANEL FIXING BRACKET (BOTTOM)	45-14-3	803-01-37	1	
39	SEAT BACK (LOWER) BRACKET	45-14-5	803-01-42	1	
40	CENTRAL BULKHEAD L.H.	45-15-7	803-01-83	1	
41	" " R.H.	45-15-8	803-01-82	1	
42					
43	SEAT BACK LOWER	45-14-10	803-01-19	1	
44	TANK BAY PANEL	45-15-6	80A-01-11	1	
45	SIDE PANEL (TANK BAY) R.H.	45-14-12	803-01-38	1	
46	" " " " L.H.	45-14-13	803-01-39	1	
47	PEDAL CHANNEL L.H.	45-14-15	803-01-53	3	
48	" " R.H.	45-14-14	803-01-54	3	
49	FRONT SUSPENSION BOX FLOOR R.H.	45-15-2	803-01-56	1	
50	" " " " L.H.	45-15-1	803-01-57	1	
51	FRONT SKID	4-87-6	792-01-84	2	
52	REAR SKID	3-68-11	803-01-33	2	
53	REAR CRASH HOOP	3-68-7	803-01-75	1	
54	DASH PANEL	3-48-4	782-01-21	1	
55	" " MOUNTING RUBBER	8-20-4	TD8-20-4	3	
56	STEERING WHEEL	8-23-3	742-04-02	1	
57	" " RETAINING WASHER	4-2-4	712-04-07	1	
58	" " RIVET (STEEL)	8-1-4	TD 7	3	
59	STEERING COLUMN	3-59-10	792-04-09	1	
60	" " SUPPORT	4-2-2	732-05-05	1	
61	STEERING RACK CLAMP	4-98-9	803-04-06	2	
62	" " MOUNTING PLATE	3-69-3	80A-04-02	2	
63	<u>GEAR LEVER ASSEMBLY COMPRISES:</u>				
64	GEAR LEVER	49-1-2	782-11-08	1	
65	" " BADGE	8-6-10	782-11-05	1	
66	" CHANGE BRACKET	3-67-10	792-11-01	1	
67	" LEVER PIVOT	4-5-2	712-11-10	1	
68	" " SPACER	4-27-3	762-11-06	1	
69	" SHAFT	4-76-5	782-11-04	1	
70	" ROD MOUNTIN G	49-1-1	782-11-05	1	
71	" CHANGE BODY	4-79-1	782-11-03	1	

MONOCOQUE ASSEMBLY - 80A

Sheet 3 of 3

MONOCOQUE CON.		
Issue	Signature	Date

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
72	GEAR CHANGE BEARING LINK	4-77-1	782-11-06	1
73	CHASSIS PLATE	8-4-4	732-01-48	1
74	LEFT FOOT REST	3-69-12	803-01-98	1
75	FRONT SUSPENSION EAR PLATE	3-68-13	80A-01-01	2
76	F.B.W.B. D.S. PLATE	3-68-6	803-01-28	2
77	THROTTLE CABLE BRACKET FRONT	3-62-5	792-01-87	1
78	SEAT BELT	8-1-11	TD 10	1
79	SEAT BELT BACKING PLATE	3-48-14	782-01-48	2
80	SEAT BELT PLATE -JOGGLED	2-1-2	722-01-75	2
81				
82	NOSE FRAME MOUNTING STUB	4-96-5	803-01-90	2
83	NOSE FRAME MOUNTING BRACKET BOTTOM	3-38-12	792-01-80	2
84	NOSE FRAME MOUNTING BRACKET SPACER	41-34-3	792-20-48	4
85	SEAT BELT TOP MOUNTING BRACKET	3-63-10	792-01-132	4
86	" " " " " SPACER	41-33-14	792-20-44	2
87	DAMPER MOUNTING STRUT	3-69-1	803-01-86	2
88	SEAT BACK UPPER BRACKET R.H.	45-15-10	803-01-40	1
89	" " " " L.H.	45-15-9	803-01-41	1
90	5.0 KG. BOTTLE + BRACKET	29-1-8	TD 1008	1
91	" " " " STRAPS	29-2-5	TTD 1063	1
92	FIRE BOTTLE T-PIECE	29-4-6	TD 29-4-6	1
93	FLEXIBLE HOSE	29-4-5	TD 29-4-5	
94	BUNDY PIPE	7-8-4	TD 7-8-4	
95	ENGINE BAY FIRE NOZZLE	4-84-9	79B-22-01	1
96	DASH PANEL " "	4-44-4	763-22-01	1
97	" " " " LOCK NUT	13-7-1	763-22-02	1
98	ENGINE BAY FIRE NOZZLE " "	7-8-7	TD 7-8-7	1

FR. SUSP.

Issue	Signature	Date

FRONT SUSPENSION - 80A

Item	SECTION		No. Off	Detail	
	Part No	DRG No.			
1	FRONT TOP ROCKER R.H.	32-5-8	80A-02-02	1	
2	" " " L.H.	32-5-7	80A-02-03	1	
3	ROCKER THRUST WASHER	41-32-13	792-20-28	4	
4	" BUSH	4-95-1	792-19-01	4	
5	" JOURNAL	4-63-7	792-02-16	2	
6	" THROUGH BOLT	12-24-7	792-02-15	2	
7					
8	F.L.W.B.	32-5-6	80A-02-01	2	
9	" THRUST WASHER	41-33-6	792-20-36	16	
10	" BUSH	4-6-12	72G-02-08	8	
11	" SHIM	4-92-9	802-20-01	4	
12	" SPACER	4-92-10	803-02-03	2	
13	" THROUGH BOLT	4-80-14	792-02-17	2	
14	" JOURNAL	4-2-5	732-02-07	4	
15	<u>STEERING RACK ASSEMBLY:</u>	4-96-13		1	
16	RACK	4-92-14	803-04-01	1	
17	HOUSING	4-98-11	80A-04-01	1	
18	housing extension	4-97-1	803-04-05	2	
18	PINION	8-23-14	TD8-23-14	1	
19	PINION BEARING	8-1-6	TD 28	2	
20	PINION BEARING SHIM	8-17-5	TD8-17-5	2	A.R.
21	PINION BEARING CLAMP RING	4-45-11	712-04-24	1	
22	END PLATE	8-17-4	TD8-17-4	1	
23	END PLATE CIRCLIP	8-17-3	TD8-17-3	1	
24	SPRING	4-4-9	712-04-21	1	
25	SPRING STOP	4-4-10	712-04-22	1	
26	SPRING RETAINER	4-4-11	712-04-23	1	
27	TENSION CAP	4-4-8	712-04-19	1	
28	OILITE BUSH	8-18-5	TD8-18-5	2	
29	SEAL	8-9-6	TD 1022	2	
30	PINION SEAL (J.K. 6000 42C)	8-22-11	TD8-22-11		
31	TRACK ROD	4-98-2	80A-04-03	2	
32	BUMP STEER SPACER (LARGE)	4-15-6	712-04-11		A.R.
33	" " " (SMALL)	4-24-10	712-04-12		A.R.
34	STEERING RACK CLEVIS	4-26-2	762-04-06	2	
35	" " " LOCK NUT	4-53-2	762-04-19	2	

FRONT SUSPENSION - 80A

Issue	Signature	Date

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
36	F.A.R.B.	40-5-8	792-05-38	1 .686 DRILLED
37	" MOUNTING BLOCK	4-93-5	803-05-03	2
38	" LINK	4-93-12	803-05-05	2
39	" ARM	3-68-8	803-05-04	2
40	" " JOINT INSERT	4-93-7	803-05-02	4
41	" LINK BOTTOM JOINT BOLT	4-93-8	803-05-01	2
42	FRONT SPRING	16-9-9	TD16-9-9	2 350 lb x 6"
43	FRONT DAMPER	16-2-11	TD16-2-11	2 1401 B 15.
44	" " INSERT (BOTTOM)	4-2-12	712-02-09	4
45	" " " (TOP)	4-82-13	80A-02;04	2
46	" " BOTTOM MTG. BOLT	4-92-15	803-02-13	2
47	F.T. ROCKER OUTER JOINT SPACER INSERT	4-96-6	803-02-16	4
48	" " " " BOLT	4-96-9	803-06-09	2
49	F.B.W.B. SAFETY WASHER	4-82-14	802-06-07	2

REAR SUSP.

Issue	Signature	Date

REAR SUSPENSION - 80A

Item	SECTION		No. Off	Detail	
	Part No	DRG No.			
1	RADIUS ARM	37-2-15	80A-03-01	2	
2	TOP LINK	4-93-13	782-03-03	2	6.12" LONG
3	" " INBOARD SPACER	4-98-10	79B-03-06		
4	R.B.W.B.	32-4-2	79B-03-02	2	
5	" LINK	3-24-3	79B-03-05	2	6.75" LONG
6	" OUTER JOINT SPACER	4-2-15	712-03-20	4	
7	BOTTOM LINK OUTER SPACER	4-82-8	712-03-20	4	
8	DAMPER	16-2-2	TD 958	2	1133 B SP4.
9	" INSERT	4-61-8	771-03-22	4	Steel
10	" BOTTOM SPACER	4-2-15	712-03-20	2	
11	R.B.W.B. OUTER JOINT CIRCLIP	23-5-10	TD23-5-10	2	NAM 1300-112
12	REAR SPRING	16-1-8	TD 438	2	400 lb x 8"
13	" HELPER SPRING	16-3-10	TD 683	2	
14	REAR ANTI-ROLL BAR	40-3-4	78B-05-01	1	1" x 16 S.w.g.
15	R.A.R.B. MOUNTING BLOCK	4-96-15	80A-05-01	2	
16	" CLAMP	1-7-2	763-05-01	2	1" I.D
17	" LINK	4-86-7	792-05-28	2	
18	" " /BOTTOM LINK BOLT	4-75-14	79B-03-03	2	
19	" " SPACER	44-12-7	732-01-102	2	Std. Sheet 6
20	TOP LINK D.S. PLATE L.H.	3-68- 15	80A-01-03	1	
21	" " " " R.H.	3-68-14	80A-01-02	1	
22	R.B.W.B. BEARING JOURNAL	4-84-5	792-03-01	2	
23	" THROUGH BOLT	12-24-1	79B-01-17	2	
24	" BEARING BUSH	4-95-2	792-19-07	4	Std. Sheet 6
25	" THRUST WASHER	41-32-6	708-16-03	8	" " 16
26	" OUTER JOINT SHIM	41-32-7	"	A.R.	.055/.057
27	" " " "	41-32-5	"	A.R.	.060/.062
28	" " " "	41-32-8	"	A.R.	.065/.067
29	" " " "	41-32-9	"	A.R.	.070/.072
30	" " " "	41-32-10	"	A.R.	.075/.077
31	RADIUS ROD SAFETY WASHER (REAR)	4-82-10	792-03-15	4	
32	" " JOINT INSERT (FRONT)	42-3-7	802-19-06	4	

FR. UPRIGHTS.

Issue	Signature	Date

FRONT UPRIGHTS- 80A

		SECTION			
	Item	Part No	DRG No.	No. Off	Detail
1	<u>FRONT UPRIGHT ASSY. COMPRISES:</u>			2	
2	UPRIGHT	4-89-15	802-06-03	1	
3	FRONT AXLE	4-27-7	751-06-01	1	
4	" " DRIVE PIN	4-1-9	711-07-04	3	
5	WHEEL BEARING	8-1-5	TD 1	2	
6	" " SPACER	4-1-5	711-06-07	1	
7	OUTER SPACER	4-1-43	711-07-05	1	
8	WHEEL STUD ASSEMBLY	3-58-4	792-06-02	1	
9	" " SPIROL PIN	8-1-7	TD 154	2	
10	BRAKE DISC	7-1-5	TD 116	1	
11	" " BELL	4-66-6	802-06-02	1	
12	BOTTOM PIN	4-92-4	802-06-01	1	
13	BOTTOM PIN SPACER	4-92-5	802-06-04	1	
14	UPRIGHT D.S. PLATE	3-68-3	802-06-05	2	
15	" " " SPACER	4-91-15	802-06-06	1	
16	" " " " STUD	4-93-3	803-06-10	4	
17	WHEEL WASHER	4-52-2	771-09-01	1	
18	" " INSERT	4-6-11	712-07-11	1	
19	FRONT WHEEL	19-5-3	782-09-09	2	13 x 10" CAST
20	FRONT TYRE			2	
21	DISC BELL BOLT	4-59-8	771-10-17		
22	" " " NUT	13-2-6	TD13-2-6		

REAR UPRIGHT - 80A

REAR UPRIGHT.		
Issue	Signature	Date

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1	L.H. ASSEMBLY COMPRISES:			
2	UPRIGHT	4-74-9	792-07-09	1
3	REAR AXLE	4-83-15	792-07-05	1
4	" " DRIVE PIN	4-1-9	711-07-04	6
5	" WHEEL BEARING	8-22-5	TD8-22-5	1
6	" " " BOLT	4-94-13	80A-07-03	5
7	BOTTOM REAR D.S. PLATE	3-59-6	79B-07-01	1
8	" FRONT D.S. PLATE L.H.	3-59-3	792-07-12	1
9	TOP LINK D.S. BRACKET L.H.	3-68-9	80A-07-01	1
10	UPRIGHT TIE ROD L.H.	3-71-15	792-01-167	1
11	R.H. ASSEMBLY COMPRISES:			
12	UPRIGHT	4-74-9	792-07-09	1
13	REAR AXLE	4-83-15	792-07-05	1
14	" " DRIVE PIN	4-1-9	711-07-04	6
15	" WHEEL BEARING	8-22-5	TD8-22-5	1
16	" " " BOLT	4-94-13	80A-07-03	5
17	BOTTOM REAR D.S. PLATE	3-59-6	79B-07-01	1
18	" FRONT " " R.H.	3-59-4	792-07-11	1
19	TOP LINK D.S. BRACKET R.H.	3-68-10	80A-07-02	1
20	REAR UPRIGHT TIE ROD R.H.	3-72-2	792-01-168	1
21	REAR WHEEL ASSEMBLY COMPRISES OF:			2
22	HUB	19-1-10	732-09-10	1
23	OUTER RIM	19-1-13	732-09-04	1
24	INNER RIM	19-1-15	732-09-02	1
25	SEALING RING	8-3-10	TD1 191	2
26	CLAMPING RING	4-34-14	752-09-01	2
27	BOLT	12-3-7	TD 209	12
28	NUT	13-3-1	TD 378	12
29	WASHER	20-1-6	TD 322	24
30	REAR TYRE			2
31	WHEEL SPACER			2

PEDALS.

Issue	Signature	Date

PEDALS - 80A

		SECTION			
Item	Part No	DRG No.	No. Off	Detail	
1	CLUTCH PEDAL ASSEMBLY COMPRISES:		1		
2	2-10-12	803-08-02	1		
3	8-1-10	TD 126	2	06 DU 08	
4	8-18-1	TD8-18-1	1		
5	4-26-11	771-08-04	1		
6	4-56-14	771-08-09	1		
7	4-5-11	712-08-07	1		
8	BRAKE PEDAL ASSEMBLY COMPRISES:				
9	3-24-9	792-08-01	1		
10	8-1-10	TD 126	2	06 DU 08	
11	4-3-11	752-08-02	1		
12	4-5-11	712-08-07	1		
13	4-5-14	703-08-01	2		
14	4-5-13	703-08-03	2		
15	4-6-1	703-08-02	2		
16	THROTTLE PEDAL ASSEMBLY COMPRISES:				
17	3-24-11	792-08-03	1		
18	8-1-10	TD 126	2	06 DU 08	
19	4-5-11	712-08-07	1		
20	8-16-11	TD8-16-11	1		
21	4-64-15	771-01-81	1		
22	3-71-3	80V-13-01	1		
			1		

ENGINE INSTALLATION.

Issue	Signature	Date

ENGINE INSTALATION - 80A

Item	SECTION	Part No	DRG No.	No. Off	Detail
1	ENGINE (SUPPLIED BY CUSTOMER)	----	----	1	
2	CLUTCH (SUPPLIED WITH ENGINE)	7-12-3	TD7-12-3	1	CP 2418
3	ENGINE SIDEFAME L.H.	36-3-7	80A-16-03	1	
4	ENGINE SIDEFAME R.H.	36-3-8	80A-16-04	1	
5	FRONT LOWER ENGINE MOUNT	4-94-15	80A-01-05	1	
6	ENGINE SIDEFAME MTG. STUD (BOTTOM)	4-99-11 4-93-10	80A-16-14 803-01- 05 67	2	
7	REAR BULKHEAD STUD	4-97-15	80A-01-07	6	
8	SIDEFAME CLEVIS	4-94-1	803-01-73	2	
9	TOP ENGINE FRAME L.H.	36-3-5	80A-16-05	1	
10	TOP ENGINE FRAME R.H.	36-3-6	80A-16-06	1	
11	ENGINE FRONT PLATE	4-96-2	80A-16-08	1	BUILT INTO ENC
12	ENGINE SUPPORT	4-96-1	80A-16-07	1	
13	ADAPTOR PLATE	4-74-12	79B-01-01	1	
14	ADAPTOR PLATE STUD	4-14-6	74B-16-01	5	
15	STARTER MOTOR	9-1-9	TD 272	1	
16	AIRBOX	11-10-6	782-12-16	1	
17	AIRBOX BASE	3-35-7	78B-01-08	1	
18	AIRBOX GAUZE	2-10-5	782-12-19	1	
19	EXHAUST SYSTEM	24-3-12		1	
20	" FLANGE NUT	13-2-8	TD 419	12	1/4 UNF BRASS
21	" BRACKET	3-34-13		1	
22	" " STUD	4-30-9	76B-16-10	2	
23	TACHOMETER	34-1-1	TD 958	1	0 - 12,000 RPM
24	" CABLE	34-1-6	TD 1131	1	8 FT.
25	OIL PRESS/TEMP GAUGE	8-9-9	TD 68	1	6 FT.
26	WATER TEMP GAUGE	34-2-3		1	3 FT.
27	THROTTLE LINKAGE ASSY. COMPRISES:				
28	THROTTLE QUADRANT	3-58-5	79B-16-03	1	
29	" LINKAGE BOLT	4-98-4	80A-16-09	1	
30	" " BRACKET	3-71-14	80A-16-10	1	
31	THROTTLE QUADRANT BUSH	8-18-6	TD 8-18-6	1	05 DU 06
32	THROTTLE BALL JOINT CONNECTOR	4-40-15	76B-16-09	1	
33	" " " CIRCLIP	23-5-3	TD23-5-3	1	900-31A
34	" TIE ROD	4-99-5	80A-16-11	1	
35	THREADED ROD	4-99-6	80A-16-12	1	
36	THROTTLE CABLE (MORSE)	8-16-15	TD 8-16-15	1	2.00 M.

OIL SYSTEM.

Issue	Signature	Date
1	P. S. [Signature]	12.12.75

OIL SYSTEM - 80A

SECTION

Item	Part No	DRG No.	No. Off	Detail
1 OIL TANK	3-71-13	80A-14-01	1	
2 FILTER ASSEMBLY	3-58-6	79B-14-01	1	
3 FILTER HOUSING SEAL	20-3-10	TD20-3-10	1	1" B.S.P.
4 TEMP TAKE OFF BOSS	4-33-3	762-14-04	1	
5 " " " " SEAL	20-3-10	TD20-3-10	1	1" B.S.P.
6 OIL TANK CAP	4-20-1	722-18-11	1	
7 " " " O-RING	8-8-9	TD 70	1	
8 PUMP & FILTER HOUSING	4-69-10	78B-16-01	1	
9 PUMP HOUSING PARALLEL PLUG	4-84-6	78B-16-13	1	
10 " " BLANKING PLUG	4-71-12	78B-16-05	1	
11 TAPER PLUG.	4-76-14	78B-16-14	1	
12 PRESSURE REGULATING VALVE SEAT	8-20-15	TD8-20-15	1	
13 FILTER ELEMENT	8-7-3	TD 75	1	
14 " SPIGOT	4-71-13	78B-16-06	1	
15 " SUPPORT	3-51-9	78B-16-11	1	
16 " BOLTS MODS	4-76-15	78B-14-03	1	
17 OIL FILTER BOWL ASSEMBLY	8-22-8	TD8-22-8	1	
18 OIL PUMP BANJO	4-99-13	80A-14-03	1	
19 " " " BOLT	4-99-14	80A-14-02	1	
20 " " " " SEAL			2	
21 SCAVENGE PUMP OUTLET ADAPTOR	4-71-11	78B-14-02	1	-12/1/2" B.S.P.
22 " " " SEAL	20-3-5	TD 1027	1	1/2" B.S.P.
23 OIL COOLER -12 x 19 ROW	8-11-9	TD 78	1	
24 " " MOUNTING BRACKET	3-73-7	80A-01-13	1	
25 AEROQUIP HOSE -12	21-2-12	TD 295		
26 " -12 x 90 UNION	21-2-3	TD 316		
27 " -12 45 UNION	21-2-2	TD 304		
28 " -12 ST UNION	21-2-1	TD 302		
29 BREATHER PIPE	8-7-15	TD 741		
30 " "	8-7-9	TD 730		3/8" I.D.
31 " " ELBOW	3-54-11	78B-16-16	1	
32 " " CLIPS	25-1-4	TD 721	2	3/8"
33 " " "	25-1-7		1	3/8"
34 CATCH TANK	8-23-12	TD8-23-12	1	
35 " " TOP	3-73-2	803-14-02	1	

Issue	Signature	Date
1	R. S. [unclear]	12.12.

OIL SYSTEM - 80A

Sheet 2 of 2

SECTION

	Item	Part No	DRG No.	No. Off	Detail
37	OIL PRESSURE LINE	21-2-7	TD290		-3 AEROQUIP
38	" " " UNION	21-1-3	TD 701	2	-3 90
39	" " TAKE OFF UNION	4-8-7	732-06-18	1	
40	OIL TANK RETAINER	3-72-12	80a-01-12	1	

WATER SYSTEM -

Issue	Signature	Date
1	R. Steg	12.12

WATER SYSTEM - 80A

SECTION

Item	Part No	DRG No.	No. Off	Detail
1 RADIATOR	27-4-11	792-13-01	1	
2 " STONE GUARD	2-10-13	80A-13-01	1	
3 FRONT RADIATOR PIPE L.H.	3-70-13		1	
4 " " " R.H.	3-70-12		1	
5 FRONT TUB WATER PIPE (L. & R.H.)	3-70-3	803-13-01	2	
6 REAR TUB WATER PIPE L.H.	3-70-2	80SV-13-01	1	
7 " " " " R.H.	3-70-1	80SV-13-02	1	
8 1 1/4" I.D. 90 RUBBER BEND	8-6-12	TD 22	2	
9 1 1/4" I.D. x 3" " HOSE	8-4-7	TD 753	6	
10 SWIRLPOT/HEADER TANK	3-70-14		1	
11 " " " CAP	8-6-11	TD 72	1	
12 JUBILEE CLIPS	25-1-8	TD 725	12	1X

FUEL SYSTEM.

Issue	Signature	Date
1	<i>P. S. [Signature]</i>	12.12.7

FUEL SYSTEM - 80A

SECTION

Item	Part No	DRG No.	No. Off	Detail
1 FUEL TANK	17-3-7	80A-15-01	1	
2 COLLECTOR POT	3-72-13	80A-15-02	1	Built into tank
3 FUEL FILLER STEM	3-71-12	80A-15-04	1	
4 TANK OUTLET ADAPTOR	4-98-6	80A-15-05	1	
5 TANK TOP	3-71-11	80A-15-03	1	
6 " " CAP	4-20-1	722-18-11	1	
7 " " O-RING	8-8-9	TD 70	1	
8 FUEL TANK FLOOR CRUSHABLES	11-12-12		1	
9 FUEL REGULATOR VALVE UNION	4-98-5	80A-15-08	1	
10 FUEL BANJO BOLT	4-98-5	80A-15-06	1	
11 FUEL PRESSURE REGULATOR	8-18-15	TD8-18-15	1	
12 CARBURETTOR BANJO	3-49-15	78B-15-08	2	
13 -6 AEROQUIP HOSE	21-2-9	TD 292	5	
14 -6 90 UNION	21-1-7	TD 313	3	
15 -6 STRAIGHT UNION	21-1-7	TD 299	3	
16 BREATHER PIPE	8-10-7	TD 8-10-7		
17 BREATHER VALVE CO	4-33-8	763-15-02	1	
18 COLLECTOR POT FILTER	8-23-5	792-16-07	1	MOD.
19 FUEL PUMP (FACET BLUE TOP)	8-22-15	TD 8-22-15	1	
20 " " UNION	4-98-12	80A-15-07	1	
21				
22				
23				

SPHERICAL JOINTS.

Issue	Signature	Date

SPHERICAL JOINTS - 80A

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1 FRONT TOP ROCKER OUTER	15-4-3	TD15-4-3	2	RBF 8B
2 F.B.W.B. OUTER	15-4-2	TD15-4-2	2	RA 10
3 TRACK ROD OUTER	15-3-3	TD15-3-3	2	RMLR 5 UF
4 " " INNER	15-3-2	TD15-3-2	2	RMR 5 UF
5 F.A.R.B. LINK TOP	15-1-11	TD 49	2	RMP 5U
6 F.A.R.B. LINK BOTTOM	15-3-5	TD15-3-5	2	RMLP5U
7 R.A.R.B. LINK TOP	15-3-5	TD15-3-5	2	RMLP 5U
8 " " BOTTOM	15-3-3	TD15-3-3	2	RMR 5 UF
9 TOP LINK INNER	15-3-10	TD15-3-10	2	RCL 6E
10 " " OUTER	15-1-14	TD 52	2	RC 6E
11 TRACK CONTROL ARM OUTER	15-2-1	TD 54	2	RC 8H
12 " " " INNER	15-3-10	TD 15-3-10	2	RCL 6E
13 R.L.W.B. OUTER	15-2-3	TD 56	2	RSTWR 08E
14 GEARLEVER LOCATION BEARING	15-2-12	TD 1013	2	RBJ 67U
15 C	-	-	-	-
16 TROTTLE CABLE/PEDAL JOINT	15-2-7	TD15-2-7	1	RF 3U
17 RADIUS ROD L.H.	15-3-12	TD15-3-12	2	RCL 6H
18 " " R.H.	15-1-13	TD 51	2	RC 6H
19 MIRROR MOUNT	4-73-11	782-12-25	2	RMP 4U (MOD)
20 THROTTLE LINKAGE FEMALE	15-2-8	TD 15-2-8	1	RM 3U
21 " " MALE	15-2-15	TD 1014	1	RFP 4U

Issue	Signature	Date
1	<i>[Signature]</i>	12.17.75

HYDRAULICS - 80A

Sheet 1 of 2

SECTION

Item	Part No	DRG No.	No. Off	Detail
1	FRONT BRAKES			
2	7-3-14	TD 1078	1	.75" size
3	7-3-13	TD 1120	1	
4	7-1-7	TD7-1-7	1	<u>OPTIONAL</u>
5	20-3-7	TD20-3-7	1	7/16" I.D. DOWTY
6	7-7-12		1	
7	7-3-8	TD 690	1	
8	7-3-5	TD691	1	
9	4-8-7	732-06-18	4	
10	21-2-7	TD290		
11	21-1-3	TD 701	4	
12	7-2-1	TD 107	2	
13	7-2-8	TD 276	4	
14	REAR BRAKES			
15	7-3-14	TD 1078	1	.75" size
16	7-3-13	TD 1120	1	
17	7-1-7	TD7-1-7	1	<u>OPTIONAL</u>
18	20-3-7	TD20-3-7	1	7/16 ID DOWTY
19	7-7-12		1	
20	4-8-7	732-06-18	4	
21	21-2-7	TD 290		
22	21-1-3	TD 701	4	
23	7-5-8	TD7-5-8	1	
24	7-5-9	TD7-5-9	1	
25	7-2-8	TD276	4	
26	CLUTCH			
27	7-3-14	TD1078	1	.75" size
28	7-3-13	TD1120	1	
29	7-1-7	TD7-1-7	1	<u>OPTIONAL</u>
30	20-3-7	TD20-3-7	1	3/16 ID DOWTY
31	7-7-12		1	
32	4-8-8	722-18-08	2	
33	21-2-8	TD 291		
34	21-2-6	TD 702	2	

HYDRAULICS CON.		
Issue	Signature	I
1	R. Stier	12

HYDRAULICS - 80A

Sheet 2 of 2

SECTION

Item	Part No	DRG No.	No. Off	Detail
35 COPPER WASHER 7/16 THIN	20-4-3	TD 688	1	
36 " " 3/8 THIN	20-2-14	TD 689	10	
37 " " 3/8 WIDE			1	
38 MASTER CYLINDER TOP HAT SPACER	44-12-9	792-19-07	6	
39 MASTER CYLINDER STUD	4-35-12	792-01-82	3	

ELECTRICS.

Issue	Signature	Date
1	R. S. [Signature]	17.12.0

ELECTRICS - 80A

Sheet 1 of 2

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1 BATTERY	9-9-2	TD9-9-2	2	6 VOLT
2 BATTERY LEAD	9-6-8	TD 993		
3 " " TERMINAL 1"	9-3-6	TD 1104		
4 " " " 5/16	9-3-7	TD 1105		
5 " " " 3/8"	9-3-8	TD 1106		
6 FIRE EXTINGUISHER BUTTON (DASH)	9-1-2	TD 274	1	
7 FIRE EXTINGUISHER SWITCH	9-1-12	TD 426	1	
8 FUEL PUMP SWITCH	9-1-12	TD 426	1	
9 IGNITION SWITCH	9-1-12	TD 426	1	
10 REAR LIGHT SWITCH	9-1-12	TD 426	1	
11 KILL SWITCH	9-1-12	TD 426	1	
12 STARTER BUTTON	9-1-2	TD 274	1	
13 REAR LIGHT	9-9-7		1	
14 " " MOUNTING RUBBER	8-20-4	TD8-20-4	2	
15 SOLENOID	9-1-3	TD 273	1	
16 JUMP PLUG	9-5-13	TD 1101	1	
17 JUMP PLUG CAP	9-6-9	TD 1102	1	
18 JUMP PLUG SOCKET	9-5-12	TD 1101	1	
19 JUMP PLUG BRACKET	3-58-10	79B-01-23	1	
20 OIL PRESSURE SWITCH	9-4-6	TD 951	1	
21 " " WARNING LIGHT	9-9-6	TD 9-9-6	1	
22 WIRING LOOM	9-9-15	TD 9-9-15	1	
23 FIRE POWER PACK	29-1-6	TD 1006	1	
24 MASTER SWITCH ASSEMBLY	35-2-4	80A-28-06	1	
25 MASTER SWITCH BRACKET	3-73-10	80A-01-16	1	
26 FIRE PULL CONNECTOR	4-97-12	803-01-100	1	
27 FIRE PULL BRACKET	3-71-5	803-01-99	1	
28 FIRE PULL HANDLE	3-71-7	803-22-01	1	
29 FIRE PULL BRACKET GROMMET	8-18-9	TD8-18-9	1	
30 CABLE INNER	8-2-2	TD 31		
31 " OUTER	8-2-1	TD 30		
32 " ADJUSTER	8-2-3	TD 32	2	
33 " " SUPPORT	8-2-14	TD 39	2	
34 " FERRULE	8-2-4	TD 33	2	
35 " NIPPLE	8-2-5	TD 34		

ELECTRICS CON.

Issue	Signature	Date
1	R. Selig	12.12.79

ELECTRICS - 80A

Sheet 2 of 2

SECTION

Item	Part No	DRG No.	No. Off	Detail
36 CABLE CLEVIS	8-2-6	TD 35	1	
37 " " PIN	8-2-7	TD 36	1	
38 RED PLASTIC SLEEVE	8-18-13	TD 8-18-13		

Bodywork.

Issue	Signature	Date
1	R. S. Lewis	12. 11

BODYWORK - 80A

Item	SECTION		No. Off	Detail
	Part No	DRG No.		
1	RADIATOR STAY		2	
1	NOSE FRAME	3-72-13	1	803-01-74
2	" " STAYS	3-71-4	2	80SV-01-07
3	NOSE	11-12-6	1	
4	" MOUNT BRACKET	3-72-6	1	
5	" FASTENER	23-1-1	1	TD 155 DZUS
6	COCKPIT	11-11-12	1	
7	" FRONT FASTENER	8-18-12	4	TD8-18-12 HEADLOCK
8	" REAR "	23-1-1	2	TD 155 DZUS
9	FUEL TOWER CRUSHABLE L.H.	11-12-7	1	
10	" " " R.H.	11-12-8	1	
11	COCKPIT SCREEN	11-7-11	1	
12	" " BOLT	12-2-9	13	TD12-2-9 3/8 x 2BA NYLON
13	" " NUT	13-1-10	13	TD13-1-10 2BA WASHER FAC
14	MIRROR L.H.	11-11-13	1	
15	MIRROR R.H.	11-11-14	1	
16	SIDEPOD L.H.	11-12-9	1	
17	" R.H.	11-12-10	1	
18	" MOUNTING BLOCK	4-98-15	2	803-12-11
19	" " STUD	4-97-10	2	803-12-09
20	" " CONE	4-97-14	2	803-12-10
21	" SIDEPLATE	11-12-11	2	80A-12-02
22	HEADREST	11-11-15	1	
23	HELMET REST	11-12-4	1	
24	SEAT	11-12-5	1	
25	REAR WING ASSY COMPRISES:	46-5-2	1	
26	CROSSTUBE	46-2-7	1	792-12-02
27	SIDEPLATE	46-4-10	2	80A-12-01
28	CLAMPING PLATE	46-2-10	2	792-12-05
29	MAINPLANE	46-2-5	1	792-12-06
30	" PACKER	46-3-10	2	792-12-10
31	ADJUSTING PLATE	46-2-9	2	792-12-04
32	FLAP	46-2-6	1	783-12-05 Ref. Flap Brkt 792-12-07
33	" PACKER	46-3-9	2	792-12-09
34	" WASHER	46-2-11	2	792-12-08
35	REAR LIGHT BRACKET	3-58-15	1	79B-12-01
36	BATTERY BOX	3-73-9	2	80A-01-15
37	NOSE FLAP		1	80A-12-07