

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

MONOCOQUE ASSEMBLY-822

SHEET 1 of 3

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|---------------------------|----------|-----------|-----|-------|----------|
| 1 | MONOCOQUE ASSY. | | | | | |
| 2 | FRONT BULKHEAD | | 822-01-20 | 1 | | |
| 3 | M.F.B.H. RH | | 822-01-10 | 1 | | 6.15.14 |
| 4 | M.F.B.H. LH | | 822-01-11 | 1 | | 6.15.13 |
| 5 | REAR CRASH HOOP | | 822-01-08 | 1 | | |
| 6 | FRONT BULKHEAD BEAM | | 822-01-45 | 1 | | 6.15.12 |
| 7 | REAR BULKHEAD RH | | 822-01-02 | 1 | | |
| 8 | REAR BULKHEAD LH | | 822-01-01 | 1 | | |
| 9 | REAR BUTRESS RH | 46-16-6 | 802-01-12 | 1 | | 6.12.8 |
| 10 | REAR BUTRESS LH | 46-16-7 | 802-01-11 | 1 | | 6.12.7 |
| 11 | INNER SKIN | | 822-01-16 | 1 | | |
| 12 | OUTER SKIN TOP RH | | 822-01-32 | 1 | | |
| 13 | OUTER SKIN TOP LH | | 822-01-33 | 1 | | |
| 14 | OUTER SKIN BOTTOM RH | 45-20-2 | 822-01-69 | 1 | | |
| 15 | OUTER SKIN BOTTOM LH | 45-20-1 | 822-01-89 | 1 | | |
| 16 | REAR PANEL | | 822-01-12 | 1 | | |
| 17 | SEAT BACK PANEL | | 822-01-13 | 1 | | HONEYCOM |
| 18 | DASH BULKHEAD | | 822-01-17 | 1 | | HONEYCOM |
| 19 | FRONT TOP PANEL | | 822-01-22 | 1 | | |
| 20 | FRONT LOWER PANEL | | 822-01-18 | 1 | | |
| 21 | STEEL TOWER SIDE RH | | 822-01-14 | 1 | | |
| 22 | STEEL TOWER SIDE LH | | 822-01-15 | 1 | | |
| 23 | TOWER OUTER PANEL RH | | 822-01-24 | 1 | | |
| 24 | TOWER OUTER PANEL LH | | 822-01-23 | 1 | | |
| 25 | SEAT BACK CORNER ANGLE | | 822-01-54 | 2 | | |
| 26 | SEAT BACK CORNER GUSSET | | 822-01-55 | 2 | | |
| 27 | REAR PANEL TOP BRK | | 822-01-46 | 1 | | |
| 28 | REAR PANEL FLOOR BRK | | 822-01-47 | 1 | | |
| 29 | REAR PANEL BRK RH | | 822-01-49 | 1 | | |
| 30 | REAR PANEL BRK LH | | 822-01-48 | 1 | | |
| 31 | M.F.B.H. BRACE | | 822-01-21 | 2 | | |
| 32 | M.F.B.H. BRK | | 822-01-50 | 2 | | |
| 33 | DASH B.H. CORNER PLATE LH | | 822-01-25 | 1 | | |
| 34 | DASH B.H. CORNER PLATE RH | | 822-01-26 | 1 | | |
| 35 | DASH B.H. CORNER ANGLE LH | | 822-01-27 | 1 | | |
| 36 | DASH B.H. CORNER ANGLE RH | | 822-01-28 | 1 | | |

Monocoque

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

MONOCOQUE ASSEMBLY-822

Sheet 2 of 3

| Description | Part No. | Drg. No. | No. | Price | Detail |
|--|----------|------------|-----|-------|--------|
| 37 F.B.H. INNER SKIN ANGLE LH | | 822-01-29 | 1 | | |
| 38 F.B.H. INNER SKIN ANGLE RH | | 822-01-30 | 1 | | |
| 39 DIAPHRAM FRONT UPPER RH | | 822-01-38 | 1 | | |
| 40 DIAPHRAM FRONT UPPER LH | | 822-01-59 | 1 | | |
| 41 DIAPHRAM REAR UPPER RH | | 822-01-60 | 1 | | |
| 42 DIAPHRAM REAR UPPER LH | | 822-01-61 | 1 | | |
| 43 DIAPHRAM FRONT LOWER RH | | 822-01-62 | 1 | | |
| 44 DIAPHRAM FRONT LOWER LH | | 822-01-63 | 1 | | |
| 45 DIAPHRAM REAR LOWER RH | | 822-01-64 | 1 | | |
| 46 DIAPHRAM REAR LOWER LH | | 822-01-65 | 1 | | |
| 47 TOP HAT BUSH RH UPPER DIAPHRAM | | 822-01-66 | 2 | | |
| 48 RACK HOLE DOUBLER LH | | | 1 | | |
| 49 RACK HOLE DOUBLER RH | | | 1 | | |
| 50 PEDAL BRACKET BASE | | 822-01-53 | 1 | | |
| 51 TUB STIFFENER | | 792-01-60 | 1 | | |
| 52 REAR BULKHEAD CLOSURE PLATE | | 822-01-51 | 2 | | |
| 53 FUEL TANK TOP PANEL | | 812-01-59 | 1 | | |
| 54 BRAKE/CLUTCH PEDAL CHANNEL | | 81C-08-06 | 2 | | |
| 55 THROTTLE PEDAL CHANNEL | | 822-08-01 | 1 | | |
| 56 CLUTCH FOOT REST | | 803-01-98 | 1 | | |
| 57 THROTTLE CABLE BRK FRONT | 3-62-5 | 792-01-87 | 1 | | |
| 58 SEAT BELT DIMPLE | | 822-01-31 | 2 | | |
| 59 SEAT BELT BACKING PLATE | 3-48-14 | 782-01-48 | 2 | | |
| 60 SEAT BELT JOGGLED PLATE | 2-1-2 | 722-01-75 | 2 | | |
| 61 SEAT DIMPLE | | 822-01-74 | 1 | | |
| 62 SEAT BELT | 8-25-9 | | 1 | | 3" |
| 63 SEAT BELT TOP MTG. BRACKET | 3-63-10 | 792-01-132 | 4 | | |
| 64 SEAT BELT TOP MTG. BRACKET SPACER | | 822-20-01 | 2 | | |
| 65 SEAT BELT TOP MTG. BRK. SPACER BOLT | 12-19-15 | | 2 | | |
| 66 DAMPER MOUNTING STRUT | | 822-01-77 | 2 | | |
| 67 FRONT DAMPER/BULKHEAD INSERT | 4-96-3 | 803-01-84 | 2 | | |
| 68 FRONT SKID | | 822-01-86 | 2 | | |
| 69 DASH PANEL | | 822-01-35 | 1 | | |
| 70 DASH PANEL MOUNTING RUBBER | 8-20-4 | | 3 | | |
| 71 STEERING WHEEL | 8-1-3 | | 1 | | |

MONOCOQUE CON

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

MONOCOQUE ASSEMBLY-822

Sheet 3 of 3

| Description | Part No. | Drg. No. | No. | Price | Detail |
|--|----------|-----------|-----|-------|-----------------|
| 72 STEERING WHEEL RETAINING WASHER | 4-2-4 | | 1 | | |
| 73 STEERING WHEEL (STEEL) RIVET | 8-1-4 | | 3 | | |
| 74 STEERING COLUMN | 3-59-10 | | 1 | | |
| 75 STEERING COLUMN SUPPORT | | 81C-04-03 | 1 | | |
| 76 STEERING COLUMN SUPPORT BRK. | | 81C-04-02 | 1 | | |
| 77 GEAR LEVER | 49-1-5 | 782-11-08 | 1 | | |
| 78 GEAR CHANGE BLOCK | | 822-11-01 | 1 | | |
| 79 GEAR CHANGE BODY | 4-79-1 | 782-11-03 | 1 | | |
| 80 GEAR LEVER PIVOT | 4-5-2 | 712-11-10 | 1 | | |
| 81 GEAR LEVER SPACER | 4-27-3 | 762-11-06 | 1 | | |
| 82 GEAR CHANGE SHAFT | 4-76-5 | 782-11-04 | 1 | | |
| 83 GEAR CHANGE BEARING LINK | | 822-11-02 | 1 | | |
| 84 GEAR CHANGE BEARING FRONT SPACER | | 822-11-03 | 2 | | |
| 85 REAR MONO GEARSHIFT BEARING CIRCLIP | 23-5-12 | | 1 | | NAM 1300/137 |
| 86 5.0KG FIRE BOTTLE | 29-1-8 | TD1008 | 1 | | |
| 87 5.0KG FIRE BOTTLE BRK. | 29-4-2 | TD29-4-2 | 1 | | |
| 88 5.0KG FIRE BOTTLE STRAPS | 29-2-5 | TD1063 | 2 | | |
| 89 FLEXIBLE HOSE | 29-4-5 | | 1 | | |
| 90 DASH PANEL FIRE NOZZLE | 4-44-4 | 763-22-01 | 1 | | |
| 91 DASH PANEL FIRE NOZZLE LOCK NUT | 13-7-1 | 763-22-02 | 1 | | |
| 92 2.5KG FIRE BOTTLE | 29-1-10 | TD1009 | 1 | | |
| 93 2.5KG FIRE BOTTLE BRACKET | 29-4-3 | TD29-4-3 | 1 | | |
| 94 2.5KG FIRE BOTTLE STRAPS | 29-2-4 | TD1062 | 2 | | |
| 95 BUNDY PIPE | 7-8-4 | | 1 | | |
| 96 BUNDY PIPE OLIVE | 29-4-8 | | 1 | | |
| 97 BUNDY PIPE NUT | 29-4-7 | | 1 | | |
| 98 ENGINE BAY FIRE NOZZLE | 4-84-9 | 798-22-01 | 1 | | |
| 99 ENGINE BAY FIRE NOZZLE NUT | 7-8-7 | | 1 | | |
| 100 LIFE SUPPORT BOTTLE | 29-3-14 | | 1 | | |
| 101 LIFE SUPPORT BOTTLE BRACKET | 3-62-4 | 793-01-26 | 1 | | |
| 102 LIFE SUPPORT BOTTLE STRAPS | | | 2 | | |
| 103 LIFE SUPPORT HOSE | 29-3-9 | | | | |
| 104 FRONT CRASH HOOP EXT | | 822-12-27 | 1 | | |

3 Fr.

FRONT SUSP.

FRONT SUSPENSION-822

SHEET 1 of 2

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|-------------------------------------|----------|-----------|-----|-------|-----------------|
| 1 | FRONT SUSPENSION EAR PLATE | | 822-01-44 | 1 | | |
| 2 | FRONT SUSPENSION EAR LH | | 822-01-67 | 1 | | 6-15-15 |
| 3 | FRONT SUSPENSION EAR RH | | 822-01-68 | 1 | | 6-15-15 |
| 4 | FRONT TOP ROCKER LH | 32-7-1 | 812-02-07 | 1 | | |
| 5 | FRONT TOP ROCKER RH | 32-7-2 | 812-02-08 | 1 | | |
| 6 | FRONT TOP ROCKER BUSH | 4-95-1 | 792-19-01 | 4 | | DELTRIN |
| | FRONT TOP ROCKER JOURNAL | 4-63-7 | 792-02-16 | 2 | | |
| 8 | F.T.R. THRUST WASHER 0.150" | 41-32-13 | 792-20-28 | 4 | | |
| 9 | F.T.R. THRUST WASHER 0.125" | 41-10-12 | 812-20-31 | AR | | |
| 10 | F.T.R. THRUST WASHER 0.050" | 41-7-12 | 802-20-33 | AR | | |
| 11 | FRONT TOP ROCKER THROUGH BOLT | | 822-02-03 | 2 | | |
| 12 | F.T.R. OUTER JOINT INSERT | 4-96-6 | 803-02-16 | 4 | | |
| 13 | F.T.R. OUTER JOINT CIRCLIP | 23-5-13 | | 2 | | NAM 1300-150 |
| 14 | F.B.W.B. REAR MOUNT | | 822-01-03 | 2 | | |
| 15 | F.B.W.B. FRONT D/S PLATE | | 822-02-02 | 4 | | |
| 16 | F.B.W.B. LH | | 822-02-07 | 1 | | |
| 17 | F.B.W.B. RH | | 822-02-01 | 1 | | |
| 18 | F.B.W.B. REAR JOINT INSERT | 4-112-6 | 812-02-01 | 4 | | |
| | F.B.W.B. FRONT JOINT FRONT INSERT | | 822-02-06 | 2 | | |
| 20 | F.B.W.B. FRONT JOINT REAR INSERT | | 822-02-05 | 2 | | |
| 21 | F.B.W.B. INNER JOINT CIRCLIP | 23-5-10 | | 4 | | |
| 22 | F.B.W.B. FRONT JOINT THROUGH BOLT | | 822-02-04 | 2 | | |
| 23 | F.B.W.B. OUTER JOINT LOCK NUT | | 822-03-07 | 2 | | |
| 24 | FRONT TRACK ROD | 4-112-10 | 802-04-03 | 2 | | |
| 25 | FRONT TRACK ROD INNER JOINT INSERT | | 81C-04-17 | 4 | | |
| 26 | BUMP STEER SPACER LARGE | 4-15-6 | 712-04-11 | AR | | |
| 27 | BUMP STEER SPACER SMALL | 4-24-10 | 712-04-12 | AR | | |
| 28 | F.A.R.B. O.735" | 40-6-1 | 812-05-13 | 1 | | |
| 29 | F.A.R.B. MOUNTING BLOCK | 4-112-11 | 812-05-08 | 2 | | 6-12-15 |
| 30 | F.A.R.B. MOUNTING BLOCK BUSH | 4-115-11 | 812-05-15 | 2 | | |
| 31 | F.A.R.B. MOUNTING BLOCK SPACER 1/8" | | 822-05-02 | 2 | | |
| 32 | F.A.R.B. THRUST WASHER | 4-114-14 | 812-05-09 | 2 | | |
| 33 | F.A.R.B. RETAINING CLIP | 8-26-1 | 812-05-14 | 2 | | |

FRONT SUSP. CON.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

FRONT SUSPENSION-822

Sheet 2 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|----------------------------|----------|-----------|-----|-------|--------|
| 34 | F.A.R.B. LINK | | 822-05-01 | 2 | | |
| 35 | F.A.R.B. LEVER | 4-114-13 | 812-05-11 | 2 | | |
| 36 | F.A.R.B. LEVER SLEEVE NUT | 4-114-15 | 812-05-12 | 2 | | |
| 37 | FRONT SPRING 1600 x 5" | | 822-02-09 | 2 | | |
| 38 | FRONT DAMPER 1401B8 | | | 2 | | |
| 39 | FRONT DAMPER BOTTOM INSERT | 4-61-8 | 771-03-22 | 4 | | |
| 40 | FRONT DAMPER TOP INSERT | 4-82-13 | 80A-02-04 | 2 | | |
| 41 | FRONT SPRING PLATFORM 1" | | 822-02-12 | 2 | | |

REAR SUSP.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

REAR SUSPENSION-822

Sheet 1 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|-----------------------------------|---------------|-----------|-----|-------|-----------------|
| 1 | REAR TOP ROCKER LH | | 822-03-23 | 1 | | |
| 2 | REAR TOP ROCKER RH | | 822-03-24 | 1 | | |
| 3 | REAR TOP ROCKER SUSPENSION PLATE | | 822-03-18 | 1 | | |
| 4 | R.T.R. BACKING PLATE RH | | 822-03-15 | 1 | | |
| 5 | R.T.R. BACKING PLATE LH | | 822-03-19 | 1 | | |
| 6 | R.T.R. BACKING PLATE STUD | | 822-03-32 | 6 | | |
| 7 | R.T.R. REAR MTG. BLOCK RH | | 822-03-16 | 1 | | |
| 8 | R.T.R. REAR MTG. BLOCK LH | | 822-03-17 | 1 | | |
| 9 | R.T.R. REAR JOINT LOCK NUT | | 822-03-34 | 2 | | |
| 10 | REAR TOP ROCKER SUPPORT EAR | | 822-03-25 | 2 | | |
| 11 | R.T.R. EAR/OIL TANK PLUG | | 822-03-29 | 2 | | |
| 12 | R.T.R. EAR/OIL TANK PLUG 'O' RING | GACO R2100 | | 2 | | |
| 13 | R.T.R. EAR/OIL TANK STUD | | 822-16-15 | 8 | | |
| 14 | R.T.R. EAR INSERT | | 822-01-76 | 4 | | |
| 15 | R.T.R. FRONT JOINT WASHER | | 822-20-05 | 2 | | |
| 16 | R.T.R. OUTER JOINT CIRCLIP | 23-5-13 | | 2 | | NAM 1300-150 |
| 17 | REAR BOTTOM WISHBONE RH | | 822-03-04 | 1 | | |
| 18 | REAR BOTTOM WISHBONE LH | | 822-03-05 | 1 | | |
| 19 | R.B.W.B. REAR MOUNT | | 822-16-08 | 1 | | |
| 20 | R.B.W.B. REAR MOUNT STUD | | 822-16-09 | 2 | | |
| 21 | R.B.W.B. REAR MOUNT INSERT | | 822-03-01 | 4 | | |
| 22 | R.B.W.B. REAR JOINT INSERT | | 822-03-02 | 4 | | |
| 23 | R.B.W.B. REAR JOINT SPACER | | 822-03-03 | 4 | | |
| 24 | R.B.W.B. FRONT JOINT UPPER SPACER | | 822-03-08 | 2 | | |
| 25 | R.B.W.B. FRONT JOINT LOWER SPACER | | 822-03-09 | 2 | | |
| 26 | R.B.W.B. OIL TANK INSERT | | 822-03-10 | 2 | | |
| 27 | R.B.W.B. OUTER JOINT LOCK NUT | | 822-03-07 | 2 | | |
| 28 | REAR TRACK ROD 4.25" | | 822-03-28 | 2 | | |
| 29 | TRACK ROD INNER JOINT SPACER | 4-15-13 | 73B-18-01 | 4 | | |
| 30 | REAR ANTI-ROLL BAR 1.375" | 40-5-15 | 812-05-20 | 1 | | |
| 31 | R.A.R.B. BLADE LH | | 81C-05-11 | 1 | | |
| 32 | R.A.R.B. BLADE RH | | 81C-05-10 | 1 | | |
| 33 | R.A.R.B. MTG. BLOCK | 4-116-9 | 812-05-17 | 2 | | |

REAR SUSP. CON.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

REAR SUSPENSION-822

Sheet 2 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|---------------------------------------|----------|-----------|-----|-------|----------|
| 34 | R.A.R.B. MTG. BLOCK BUSH | 4-117-9 | 812-05-18 | 2 | | |
| 35 | R.A.R.B. THRUST WASHER | | 822-05-05 | 1 | | |
| 36 | R.A.R.B. THRUST WASHER | | 822-05-06 | 1 | | |
| 37 | R.A.R.B. RETAINING CLIP | | | 2 | | |
| 38 | R.A.R.B. LINK | | 822-05-04 | 2 | | |
| 39 | R.A.R.B. LINK SPACER | | 822-03-27 | 2 | | |
| 40 | R.A.R.B. BLADE THRUST WASHER | 8-25-12 | | 1 | | |
| 41 | R.A.R.B. BLADE TIE CLAMP | 4-113-10 | 81A-05-02 | 1 | | |
| 42 | R.A.R.B. BLADE TIE CLAMP CIRCLIP | 23-6-3 | | 1 | | DIN1400- |
| 43 | R.A.R.B. CABLE BRK 'U' BOLT | 4-117-10 | 812-05-19 | 1 | | |
| 44 | R.A.R.B. CABLE BRK | | 812-05-22 | 1 | | |
| 45 | R.A.R.B. CABLE CLAMP | 8-16-14 | | 1 | | |
| 46 | R.A.R.B. CABLE CLAMP SPACER | 3-36-14 | 772-01-06 | 1 | | |
| 47 | R.A.R.B. CABLE 2.40 | 34-2-4 | | 1 | | |
| 48 | R.A.R.B. OPERATING LEVER | 3-84-15 | 81A-05-04 | 1 | | |
| 49 | R.A.R.B. OPERATING LEVER BASE | 4-113-11 | 81A-05-06 | 1 | | |
| 50 | R.A.R.B. LEVER LOCATION PLATE | 3-86-9 | 813-05-11 | 1 | | |
| 51 | R.A.R.B. LEVER PEG | 4-118-15 | 813-05-13 | 1 | | |
| 52 | R.A.R.B. ADJUSTING SPACER | 41-10-13 | 812-20-32 | 1 | | |
| 53 | R.A.R.B. LEVER RETAINING BOLT | 4-113-12 | 81A-05-05 | 1 | | |
| 54 | R.A.R.B. LEVER THRUST WASHER | 41-7-3 | | 1 | | |
| 55 | R.A.R.B. LEVER WAVED WASHER | 20-4-8 | | 1 | | |
| 56 | REAR SPRING 1500 x 6" | | 822-03-36 | 2 | | |
| 57 | REAR DAMPER 1404B8 | | | 2 | | |
| 58 | REAR SPRING PLATFORM 1" | | 822-02-12 | 2 | | |
| 59 | REAR DAMPER TOP INSERT | | 822-03-26 | 4 | | |
| 60 | REAR LOWER DAMPER MTG. LH | | 822-03-11 | 1 | | |
| 61 | REAR LOWER DAMPER MTG. RH | | 822-03-12 | 1 | | |
| 62 | REAR LOWER DAMPER MTG. BOLT | | 822-03-13 | 2 | | |
| 63 | REAR LOWER DAMPER INSERT | | 822-03-14 | 2 | | |
| 64 | REAR LOWER DAMPER SAFETY WASHER | | 822-03-25 | 2 | | |
| 65 | G. BOX SIDE PLATE/R.A.R.B. BLOCK STUD | | 822-16-16 | 4 | | |
| 66 | G. BOX SIDE PLATE/R.T.R. PLATE STUD | 4-102-3 | 802-16-19 | 2 | | |

FRONT UPRIGHT

| ISSUE | SIGNATURE | DATE |
|-------|------------|------|
| | ALLOY AXLE | MOLE |
| | | |
| | | |
| | | |
| | | |
| | | |

FRONT UPRIGHT-822 (ALLOY AXLE)

SHEET 1 of 1

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|------------------------------------|----------|---------------|-----|-------|---------|
| 1- | FRONT UPRIGHT | 4-89-15 | 802-06-03 | 2 | | 6-10-15 |
| 2 | FRONT AXLE | | 822-06-03 | 2 | | |
| 3 | FRONT AXLE DRIVE PIN | | 822-06-04 | 6 | | |
| 4 | WHEEL BEARING | 5-1-5 | | 4 | | |
| 5 | WHEEL BEARING SPACER | 4-1-5 | 711-06-07 | 2 | | |
| 6 | WHEEL BEARING OUTER SPACER | | 822-06-05 | 2 | | |
| 7 | WHEEL STUD | | 822-06-01 | 2 | | |
| 8 | WHEEL STUD WASHER | | 822-06-02 | 2 | | |
| 9 | BRAKE DISC <i>CP 2061/107</i> | 7-1-5 | <i>TD-116</i> | 2 | | |
| 10 | BRAKE DISC BELL | 6-66-6 | 802-06-02 | 2 | | |
| 11 | DISC BELL BOLT | 4-59-8 | 771-10-17 | 12 | | |
| 12 | DISC BELL BOLT NUT | 13-2-6 | TD13-2-6 | 12 | | |
| 13 | BOTTOM PIN | 4-92-4 | 802-06-01 | 2 | | |
| 14 | BOTTOM PIN SPACER | 4-92-5 | 802-06-04 | 2 | | |
| 15 | F.B.W.B. OUTER JOINT SAFETY WASHER | 4-82-14 | 802-06-07 | 2 | | |
| 16 | UPRIGHT D/S PLATE | 3-68-3 | 802-06-05 | 4 | | |
| 17 | UPRIGHT D/S PLATE SPACER | 4-91-15 | 802-06-06 | 2 | | 6-11-04 |
| 18 | UPRIGHT SPACER PLATE | 4-107-6 | 80A-06-01 | 2 | | |
| 19 | UPRIGHT D/S PLATE SPACER STUD | 4-102-13 | 802-16-25 | 8 | | |
| 20 | WHEEL WASHER | 4-52-2 | 771-09-01 | 2 | | |
| 21 | WHEEL WASHER INSERT | 4-6-11 | 712-07-11 | 2 | | |
| 22 | WHEEL RETAINING NUT | 13-1-1 | | 2 | | |
| 23 | FRONT WHEEL 10"x5½"x13"Ø | 19-5-3 | 782-09-09 | 2 | | 617.14 |
| 24 | FRONT TYRE | | | 2 | | |

FRONT UPRIGHT

| ISSUE | SIGNATURE | DATE |
|-------|-------------|------|
| | STEEL AXLE. | |
| | | |
| | | |
| | | |
| | | |

FRONT UPRIGHT-822 (STEEL AXLE)

SHEET 1 of 1

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|------------------------------------|----------|-----------|-----|-------|---------|
| 1 | FRONT UPRIGHT | 4-89-15 | 802-06-03 | 2 | | 6-10-15 |
| 2 | FRONT AXLE | 4-27-7 | 751-06-01 | 2 | | |
| 3 | FRONT AXLE DRIVE PIN | 4-1-9 | 711-07-04 | 6 | | |
| 4 | WHEEL BEARING | 8-1-5 | | 4 | | |
| 5 | WHEEL BEARING SPACER | 4-1-5 | 711-06-07 | 2 | | |
| 6 | WHEEL BEARING OUTER SPACER | 4-1-13 | 711-07-05 | 2 | | |
| 7 | WHEEL STUD | 4-93-1 | 803-06-06 | 2 | | |
| 8 | WHEEL STUD WASHER | 4-93-2 | 803-06-05 | 2 | | |
| 9 | BRAKE DISC | 7-1-5 | | 2 | | |
| 10 | BRAKE DISC BELL | 4-66-6 | 802-06-02 | 2 | | |
| 11 | DISC BELL BOLT | 4-59-8 | 771-10-17 | 12 | | |
| 12 | DISC BELL BOLT NUT | 13-2-6 | TD13-2-6 | 12 | | |
| 13 | BOTTOM PIN | 4-92-4 | 802-06-01 | 2 | | |
| 14 | BOTTOM PIN SPACER | 4-92-5 | 802-06-04 | 2 | | |
| 15 | F.B.W.B. OUTER JOINT SAFETY WASHER | 4-82-14 | 802-06-07 | 2 | | |
| 16 | UPRIGHT D/S PLATE | 3-68-3 | 802-06-05 | 4 | | |
| 17 | UPRIGHT D/S PLATE SPACER | 4-91-15 | 802-06-06 | 2 | | |
| 18 | UPRIGHT SPACER PLATE | 4-107-6 | 80A-06-01 | 2 | | |
| 19 | UPRIGHT D/S PLATE SPACER STUD | 4-102-13 | 802-16-25 | 8 | | |
| 20 | WHEEL WASHER | 4-52-2 | 771-09-01 | 2 | | |
| 21 | WHEEL WASHER INSERT | 4-6-11 | 712-07-11 | 2 | | |
| 22 | WHEEL RETAINING NUT | 13-1-1 | | 2 | | ½" UNF |
| 23 | FRONT WHEEL 10" x 5½" x 13" Ø | 19-5-3 | 782-09-09 | 2 | | 6-7-14 |
| 24 | FRONT TYRE | | | 2 | | |

REAR UPRIGHT.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

REAR UPRIGHT-822

SHEET 1 of 1

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|------------------------------------|----------|-----------|-----|-------|----------|
| 1 | REAR UPRIGHT | | 822-07-01 | 2 | | |
| 2 | REAR AXLE | 4-93-6 | 802-07-01 | 2 | | |
| 3 | REAR AXLE DRIVE PIN | 4-1-9 | 711-07-04 | 12 | | |
| 4 | WHEEL BEARING | 8-1-5 | | 4 | | |
| 5 | WHEEL BEARING SPACER | 4-1-5 | 711-06-07 | 2 | | |
| 6 | WHEEL BEARING OUTER SPACER | 4-1-13 | 711-07-05 | 2 | | |
| | BRAKE DISC | 7-1-5 | | 2 | | |
| 8 | BRAKE DISC BELL | 4-66-6 | 802-06-02 | 2 | | |
| 9 | DISC BELL BOLT | 4-59-8 | 711-10-17 | 12 | | |
| 10 | DISC BELL BOLT NUT | 13-2-6 | TD13-2-6 | 12 | | |
| 11 | BOTTOM PIN | 4-92-4 | 802-06-01 | 2 | | |
| 12 | BOTTOM PIN SPACER | 4-92-5 | 802-06-04 | 2 | | |
| 13 | R.B.W.B. OUTER JOINT SAFETY WASHER | 4-82-14 | 802-06-07 | 2 | | |
| 14 | REAR UPRIGHT D/S BRK. RH | | 822-07-02 | 2 | | |
| 15 | REAR UPRIGHT D/S BRK. LH | | 822-07-03 | 2 | | |
| 16 | REAR UPRIGHT D/S BRK. LONG STUD | | 822-07-04 | 4 | | |
| 17 | REAR UPRIGHT D/S BRK. SHORT STUD | | 822-07-05 | 4 | | |
| 18 | REAR UPRIGHT DOWEL | | 822-20-02 | 8 | | |
| 19 | R.T.R. OUTER JOINT SPACER | 4-115-5 | 812-03-09 | 4 | | |
| 20 | R. TRACK ROD OUTER JOINT SPACER | 4-115-9 | 812-03-12 | 4 | | |
| 21 | WHEEL WASHER | 4-52-2 | 771-09-01 | 2 | | |
| 22 | WHEELWASHER INSERT | 4-6-11 | 712-07-11 | 2 | | |
| 23 | WHEEL RETAINING NUT | 13-1-1 | | | | 3/4" UNF |
| 24 | REAR WHEEL 14" x 5 1/2" x 13"Ø | 19-5-12 | 802-09-01 | | | 6-11-07 |
| 25 | REAR TYRE | | | | | |

PEDALS.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |

PEDALS-822

SHEET 1 of 1

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|--|----------|-----------|-----|-------|--------|
| 1 | <u>CLUTCH PEDAL ASSEMBLY COMPRISES:-</u> | | | | | |
| 2 | CLUTCH PEDAL | 2-10-12 | 803-08-02 | 1 | | |
| 3 | CLUTCH PEDAL PIVOT BEARING | 8-1-10 | | 2 | | |
| 4 | CLUTCH PEDAL PIVOT BUSH | 4-5-11 | 712-08-07 | 1 | | |
| 5 | CLUTCH CLEVIS | 4-26-11 | 771-08-04 | 1 | | |
| 6 | CLUTCH CLEVIS PIN | 4-56-14 | 771-08-09 | 1 | | |
| 7 | CLUTCH PEDAL CLEVIS BEARING | 8-18-1 | | 1 | | |
| 8 | CLUTCH PEDAL BUFFER SUPPORT | 4-64-15 | 771-01-81 | 1 | | |
| 9 | CLUTCH PEDAL BUFFER | 2-12-14 | 812-01-44 | 1 | | |
| 10 | <u>BRAKE PEDAL ASSEMBLY COMPRISES:-</u> | | | | | |
| 11 | BRAKE PEDAL | 2-7-14 | 752-08-10 | 1 | | |
| 12 | BRAKE PEDAL PIVOT BEARING | 8-1-10 | | 2 | | |
| 13 | BRAKE PEDAL PIVOT BUSH | 4-5-11 | 712-08-07 | 1 | | |
| 14 | BALANCE BAR SHAFT | 4-103-11 | 802-08-01 | 1 | | |
| 15 | BALANCE BAR YOKE | 3-77-3 | 802-08-02 | 2 | | |
| 16 | BALANCE BAR CABLE | 8-24-13 | | 1 | | 34" |
| 17 | BALANCE BAR CABLE PLASTIC COVER | 8-8-5 | | 1 | | 31" |
| 18 | BALANCE BAR ADJUSTER | 4-103-3 | 792-26-04 | 1 | | |
| 19 | BALANCE BAR ADJUSTER BODY | | 81C-26-02 | 1 | | |
| 20 | BALANCE BAR ADJUSTER SPACER | 41-7-1 | 802-20-22 | 1 | | |
| 21 | BALANCE BAR ADJUSTER KNOB | 9-5-3 | | 1 | | |
| 22 | <u>THROTTLE PEDAL ASSEMBLY COMPRISES:-</u> | | | | | |
| 23 | THROTTLE PEDAL | 2-13-10 | 812-08-01 | 1 | | |
| 24 | THROTTLE PEDAL PIVOT BEARING | 8-1-10 | | 2 | | |
| 25 | THROTTLE PEDAL PIVOT BUSH | 4-5-11 | 712-08-07 | 1 | | |
| 26 | THROTTLE PEDAL BUFFER SUPPORT | 4-64-15 | 771-01-81 | 1 | | |
| 27 | THROTTLE PEDAL BUFFER | 2-12-14 | 812-01-44 | 1 | | |

STEERING RACK

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

STEERING RACK ASSEMBLY-822

SHEET 1 of 1

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|-------------------------------|----------|-----------|-----|-------|--------|
| 1 | STEERING RACK HOUSING | | 822-04-03 | 1 | | |
| 2 | STEERING RACK | | 822-04-04 | 1 | | |
| 3 | STEERING RACK END PLUG | | 822-04-05 | 2 | | |
| 4 | 6 TOOTH PINION | 8-23-14 | | 1 | | |
| 5 | PINION BEARING | 8-1-6 | | 2 | | |
| 6 | PINION SEAL | 8-22-11 | | 1 | | |
| 7 | PINION BEARING CLAMP RING | | | 1 | | |
| 8 | PINION BEARING CLAMP TOP RING | | | 1 | | |
| 9 | TENSION CAP | 4-4-8 | 712-04-19 | 1 | | |
| 10 | SPRING | 4-4-9 | 712-04-21 | 1 | | |
| 11 | SPRING STOP | 4-4-10 | | 1 | | |
| 12 | SPRING RETAINER | 4-4-11 | 712-04-23 | 1 | | |
| 13 | OILITE BUSH | 8-18-5 | | 2 | | |
| 14 | OILITE BUSH SEAL | 8-9-6 | | 2 | | |
| 15 | STEERING RACK CLEVIS | | 81C-04-10 | 2 | | |
| 16 | STEERING RACK CLEVIS LOCK NUT | | 822-04-07 | 2 | | |
| 17 | STEERING RACK CLAMP | | 822-04-01 | 2 | | |
| 18 | STEERING RACK MTG. PLATE | 3-69-3 | 80A-04-02 | 2 | | |
| 19 | STEERING RACK STOP | | 822-20-06 | 2 | | |

ENGINE INSTALLATION

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

ENGINE INSTALLATION-822 BMW

SHEET 1 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|--------------------------------|------------|------------|-----|-------|-----------|
| 1 | ENGINE (SUPPLIED BY CUSTOMER) | | | 1 | | |
| 2 | CLUTCH (SUPPLIED WITH ENGINE) | | | 1 | | |
| 3 | ENGINE SIDE FRAME LH | | 822-01-73 | 1 | | HONEYCOME |
| 4 | ENGINE SIDE FRAME RH | | 822-01-38 | 1 | | HONEYCOME |
| 5 | SIDEFAME CLEVIS | | 82-01-60 | 4 | | |
| 6 | SIDEFAME INNER STUD | | 822-01-42 | 2 | | |
| | SIDEFAME OUTER STUD | | 822-01-43 | 2 | | |
| 8 | SIDEFAME FRONT INSERT | | 822-01-75 | 8 | | |
| 9 | SIDEFAME REAR INSERT | | 822-01-76 | 4 | | |
| 10 | ENGINE MOUNT LOWER BEAM | | 822-01-04 | 1 | | |
| 11 | ENGINE MOUNT LOWER BEAM STUD | 822-01-107 | 802-01-58 | 2 | | |
| 12 | ENGINE MOUNT UPPER BEAM | | 822-01-37 | 1 | | 822-01-37 |
| 13 | ENGINE MOUNT TOP PLATE | | 822-01-34 | 1 | | |
| 14 | ENGINE MOUNT TOP PLATE STUD | | 822-16-18 | 4 | | |
| 15 | ENGINE/OIL TANK TOP STUD | | 822-16-13 | 2 | | |
| 16 | ENGINE/OIL TANK MED-UPPER STUD | | 822-16-14 | 2 | | |
| 17 | EXHAUST SYSTEM | 24-3-14 | | 1 | | |
| 18 | EXHAUST BRACKET | | | 1 | | |
| 19 | AIR BOX | | 822-12-08 | 1 | | |
| | AIR BOX BASE | | | 1 | | |
| 21 | AIR BOX STONE GUARD | | | 1 | | |
| 22 | AIR BOX CLAMP | 3-18-19 | 752-01-110 | 2 | | |
| 23 | AIR BOX SEALING RING | 35-2-1 | | 4 | | |
| 24 | THROTTLE CABLE 2.15 | 8-17-10 | | 1 | | |
| 25 | THROTTLE CABLE CLAMP | 8-16-14 | | 2 | | |
| 26 | THROTTLE CABLE CONNECTOR | 4-45-6 | 762-16-42 | 1 | | |
| 27 | THROTTLE CABLE CLAMP SPACER | 3-36-14 | 772-01-06 | 2 | | |
| 28 | BOWDEN INNER CABLE | 8-2-2 | | 1 | | 9" |
| 29 | BOWDEN OUTER CABLE | 8-2-1 | | 1 | | 6" |
| 30 | NIPPLE | 8-2-5 | | 1 | | |
| 31 | TACHOMETER 0-12000 | | | 1 | | |
| 32 | TACHOMETER DRIVE 7' | | | 1 | | |
| 33 | OIL PRESSURE TAKE OFF ADAPTOR | 4-80-2 | 762-16-19 | 1 | | |
| 34 | OIL PRESSURE TAKE OFF UNION | 21-1-3 | | 1 | | -3C90' |

ENG. INSTAL. CON.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

ENGINE INSTALLATION-822 BMW

Sheet 2 of 2

| Description | Part No. | Drg. No. | No. | Price | Detail |
|------------------------------------|----------|------------------------|-----|-------|--------------------------------|
| 35 OIL PRESSURE LINE | 21-2-7 | | 1 | | -3X6Fr |
| 36 OIL PRESSURE GAUGE INLET UNION | 21-1-2 | | 1 | | -3X45' |
| 37 OIL PRESSURE/TEMP GAUGE | 24-1-14 | | 1 | | 8Fr |
| 38 FUEL PRESSURE TAKE OFF UNION | 21-1-3 | | 1 | | -3X90' |
| 39 FUEL PRESSURE LINE | 21-2-7 | | 1 | | -3X3Fr |
| 40 FUEL SENDER UNIT INLET UNION | 21-1-1 | | 1 | | -3STR |
| 41 FUEL SENDER UNIT | | 802-15-02 823-15-07 | 1 | | |
| 42 FUEL SENDER UNIT OUTLET UNION | 21-1-1 | | 1 | | -3STR |
| 43 FUEL PRESSURE LINE | 21-2-7 | | 1 | | -3x4Fr |
| 44 FUEL PRESSURE GAUGE INLET UNION | 21-1-2 | | 1 | | 13x45' |
| 45 FUEL PRESSURE/WATER TEMP. GAUGE | 34-1-14 | | 1 | | 8Fr |
| 46 FUEL SENDER UNIT 'O' RING GACO | R2031 | (BS011) | 1 | | |
| 47 EXHAUST MTG BUSH | 8-13-1 | | 2 | | 5/16x $\frac{3}{4}$ x 21/32 |
| 48 EXHAUST MTG BUSH INSERT | 4-93-7 | 803-05-02 | 4 | | |

AIR STARTER SYSTEM

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

AIR STARTER SYSTEM

822 BMW

SHEET 1 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|--|--------------|-----------|-----|-------|---------|
| 1 | AIR STARTER G.A. DRAWING | | 822-24-12 | 1 | | |
| 2 | RING GEAR (SUPPLIED WITH ENGINE) | | | 1 | | |
| 3 | AIR MOTOR DESOUTTER | SREM-2R-3000 | | 1 | | |
| 4 | AIR MOTOR BELL HOUSING | | 822-16-17 | 1 | | |
| 5 | BENDIX SHAFT | | 822-16-57 | 1 | | |
| 6 | BENDIX SHAFT BUSH (GLACIER) | | LO710 | 1 | | |
| 7 | 9.T. PINION (LUCAS) | 54244242 | | 1 | | |
| 8 | PINION | | 822-16-40 | 1 | | |
| 9 | PINION LINER BUSH | | 822-16-56 | 1 | | |
| 10 | BENDIX HELIX (LUCAS) | 54258243 | | 1 | | |
| 11 | BENDIX SPRING RETAINER (LUCAS) | 54258243 | 822-16-58 | 1 | | |
| 12 | BENDIX SLEEVE (LUCAS) | 54258243 | | 1 | | |
| 13 | BENDIX SPRING (LUCAS) | 54258243 | | 1 | | |
| 14 | PINION SPRING (LUCAS) | 54258243 | | 1 | | |
| 15 | THRUST WASHER (LUCAS) | 54258243 | | 1 | | |
| 16 | SHAFT CIRCLIP (LUCAS) | 54258243 | | 1 | | |
| 17 | PINION BODY CIRCLIP (LUCAS) | 54258243 | | 1 | | |
| 18 | AIR MOTOR BANJO | | 822-24-04 | 1 | | |
| 19 | AIR MOTOR BANJO BOLT | | 822-24-05 | 1 | | |
| 20 | BANJO BOLT DOWTY SEAL | 20-3-8 | | 2 | | 3/8 BSP |
| | <u>ONBOARD AIR SUPPLY COMPRISES:-</u> | | | | | |
| 21 | AIR BOTTLE MTG. BRK. | | 822-01-87 | 2 | | |
| 22 | AIR BOTTLE | P2263K | | 1 | | |
| 23 | AIR BOTTLE VALVE ADAPTOR | | 822-24-03 | 1 | | |
| 24 | AIR BOTTLE BALL VALVE | | 012-08-17 | 1 | | |
| 25 | BALL VALVE OUTLET ADAPTOR | | 822-24-01 | 1 | | |
| 26 | BALL VALVE OUTLET ADAPTON UNION | 21-1-3 | | 1 | | -3x90° |
| 27 | AIR BOTTLE/MOTOR HOSE | 21-2-17 | | 1 | | -3x3ft |
| 28 | AIR MOTOR INLET BANJO UNION | 21-1-3 | | 1 | | -3x90° |
| 29 | AIR MOTOR INLET BANJO UNION | 21-1-9 | | 1 | | -6x90° |
| 30 | AIR BOTTLE LEVER | | 822-24-02 | 1 | | |
| 31 | AIR BOTTLE LEVER CABLE | | | 1 | | 3ft. |
| 32 | AIR STARTER OPERATING CABLE JOINT | RFP4U | | 1 | | |
| 33 | AIR BOTTLE LEVER SPRING | | | 1 | | |
| | <u>EXTERNAL AIR SUPPLY COMPRISES:-</u> | | | | | |
| 34 | AIR SUPPLY VALVE (SCHRADER) | B936BW | | 1 | | 3/4 BSP |

AIR STARTER SYSTEM.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |

AIR STARTER SYSTEM

822 BMW

SHEET 2 of 2

| Description | Part No. | Drg. No. | No. | Price | Detail |
|------------------------------|----------|-----------|-----|-------|------------|
| 35 AIR SUPPLY VALVE ADAPTOR | | | 1 | | |
| 36 AIR SUPPLY SOCKET | 5601-6-6 | | 1 | | 3/8 BSP/-8 |
| 37 AIR SUPPLY SOCKET ADAPTOR | | | 2 | | 3/8 BSP/-6 |
| 38 AIR SOCKET DOWTY SEAL | | | 2 | | 3/8 BSP |
| 39 AIR PLUG | 5602-6-6 | | 1 | | |
| 40 AIR PLUG UNION | 21-1-9 | | 1 | | -6STR |
| 41 AIR PLUG/AIR MOTOR HOSE | 21-2-9 | | 1 | | -6x3ft |
| 42 AIR PLUG BRK | | 822-24-07 | 1 | | |

TRANSMISSION.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

TRANSMISSION-822 BMW

SHEET 1 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|---|------------|-----------|-----|-------|----------|
| 1 | GEARBOX F200 | 18-3-3 | | 1 | | |
| 2 | GEARBOX FT200 MODIFICATIONS | | 822-16-09 | | | |
| 3 | GEARBOX SIDEPLATE LH | | 822-16-03 | 1 | | |
| 4 | GEARBOX SIDEPLATE RH | | 822-16-02 | 1 | | |
| 5 | GEARBOX SIDEPLATE STUD | 4-99-7 | 802-16-05 | 3 | | |
| 6 | GEARBOX SIDEPLATE STUD | 4-99-8 | 802-16-06 | 6 | | |
| 7 | GEARBOX SIDEPLATE STUD | 4-99-9 | 802-16-07 | 6 | | |
| 8 | INPUT SHAFT (BMW) | | 822-16-05 | 1 | | |
| 9 | CLUTCH RELEASE BEARING | SUF360802 | | 1 | | |
| 10 | CLUTCH RELEASE PISTON | | 822-16-06 | 1 | | |
| 11 | OIL TANK/CLUTCH RELEASE PISTON SEAL | 8-24-3 | | 1 | | CP2383/1 |
| 12 | NOSE PIECE | | 822-16-07 | 1 | | |
| 13 | NOSE PIECE TO OIL TANK FRONT 'O' RING | 126-5575 | | 1 | | |
| 14 | NOSE PIECE TO OIL TANK REAR 'O' RING | GACO R3131 | | 1 | | |
| 15 | NOSE PIECE/CLUTCH RELEASE PISTON SEAL | 8-24-5 | | 1 | | CP2361 |
| 16 | NOSE PIECE ANTI-ROTATION ANS. | | 826-16-21 | 2 | | |
| 17 | GEARBOX ENDCOVER | 4-99-4 | 802-16-04 | 1 | | 6.11.12 |
| 18 | GEARBOX OIL FILTER ASSEMBLY COMPRISES:- | | | | | |
| 19 | OIL FILTER WASHER | 4-103-6 | 802-16-22 | 1 | | |
| 20 | OIL FILTER SPINDLE | 4-103-7 | 802-16-24 | 1 | | |
| 21 | OIL FILTER ELEMENT | FB994/1 | | 1 | | |
| 22 | OIL FILTER WASHER | 4-61-6 | 771-16-38 | 1 | | |
| 23 | OIL FILTER SPRING | 16-6-2 | | 1 | | |
| 24 | OIL FILTER TUBE | | 812-16-41 | 1 | | |
| 25 | OIL FILTER TUBE 'O' RING | DOWTY O32 | | 1 | | |
| 26 | OIL FILTER BOLT | 4-102-9 | 802-16-23 | 1 | | |
| 27 | OIL FILTER BOLT 'O' RING | 8-14-10 | | 1 | | |
| 28 | GEARBOX ENDCOVER BUNG | 4-8-12 | 753-15-06 | 1 | | |
| 29 | GEARBOX OIL PUMP | 18-10-12 | | 1 | | |
| 30 | OIL PUMP OUTLET BANJO | 4-87-13 | 792-16-10 | 1 | | |

TRANSMISSION CON.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

TRANSMISSION-822 BMW

Sheet 2 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|---------------------------------|----------|-----------|-----|-------|--------|
| 31 | OIL PUMP OUTLET BANJO BOLT | 4-103-8 | 792-16-11 | 1 | | |
| 32 | OIL PUMP OUTLET BANJO UNION | 21-1-8 | | 1 | | -6x45' |
| 33 | OIL PUMP RETURN HOSE | 21-2-9 | TD292 | 1 | | -6x18" |
| 34 | GEARBOX INLET UNION | 21-1-9 | | 1 | | -6x90' |
| 35 | GEARBOX INLET ADAPTOR | 4-8-13 | 752-15-10 | 1 | | -6x-6 |
| 36 | GEARBOX SPRAY TUBE | 4-94-11 | 792-14-09 | 1 | | |
| 37 | SPRAY TUBE DOWTY SEAL | 20-3-14 | TD20-3-14 | 1 | | |
| 38 | OIL PUMP BANJO BOLT DOWTY SEAL | 20-3-3 | TD1024 | 2 | | |
| 39 | DRIVESHAFT ASSEMBLY COMPRISES:- | | | | | |
| 40 | DRIVESHAFT 15.71" | 14-3-2 | 802-10-02 | 2 | | |
| 41 | PLUNGE JOINT HOUSING | 14-2-9 | 782-10-03 | 2 | | 89ST |
| 42 | PLUNGE JOINT HOUSING SPACER | 4-106-2 | 813-10-02 | 2 | | |
| 43 | PLUNGE JOINT HOUSING BOLT | 12-13-8 | | 12 | | |
| 44 | PLUNGE JOINT INNER TRACK | 14-1-6 | | 2 | | |
| 45 | PLUNGE JOINT CAGE | 14-1-7 | | 2 | | |
| 46 | PLUNGE JOINT BALL | 14-1-8 | | 12 | | |
| 47 | PLUNGE JOINT GAITER | | | 2 | | |
| 48 | DRIVESHAFT INNER CIRCLIP | 8-1-9 | | 2 | | |
| 49 | DRIVESHAFT OUTER CIRCLIP | 23-5-5 | | 2 | | |
| 50 | DRIVESHAFT YOKE | 14-2-12 | 762-10-05 | 2 | | |
| 51 | CENTRE CROSS | 14-2-14 | | 2 | | |
| 52 | AXLE YOKE | 14-2-13 | 762-10-03 | 2 | | |
| 53 | AXLE YOKE THRUST RING | 14-2-15 | 762-10-04 | 2 | | |
| 54 | WHEEL RETAINING STUD | 4-103-9 | 802-07-07 | 2 | | |
| 55 | FRONT GEAR ROD | 3-77-14 | 802-11-01 | 1 | | |
| 56 | MIDDLE GEAR ROD | | | 1 | | |
| 57 | REAR GEAR ROD | | | 1 | | |
| 58 | OIL TANK GEAR ROD JOINT CIRCLIP | | | 2 | | RRT10C |

POWER LOCK DIFF. ASSY.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

POWER LOCK DIFF ASSEMBLY-822

SHEET 1 of 1

| | Description | Part No. | Dr. No. | No. | Price | Detail |
|----|-----------------------------------|-----------|-----------|-----|-------|--------|
| 1 | OUTPUT SHAFT LH | 4-106-11 | 802-16-35 | 1 | | |
| 2 | OUTPUT SHAFT RH | 4-106-12 | 802-16-36 | 1 | | |
| 3 | BEARING SPACER LH | 4-106-14 | 802-16-38 | 1 | | |
| 4 | BEARING SPACER RH (STD HEWLAND) | | | 1 | | |
| 5 | BEARING SPACER SHIM (STD HEWLAND) | | | AR | | |
| 6 | TAB WASHERS (STD HEWLAND) | | | 4 | | |
| 7 | C.W.P. BOLTS | | | 8 | | |
| 8 | DIFF ASSEMBLY COMPRISES:- | | | 1 | | |
| 9 | DIFF CASE | ✓4-106-15 | 802-16-45 | 1 | | |
| 10 | DIFF CASE COVER | ✓4-106-13 | 802-16-37 | 1 | | |
| 11 | RETAINING SCREW | | | 3 | | |
| 12 | SIDE GEAR RING RH | ✓4-107-2 | 782-16-48 | 1 | | 45° |
| 13 | SIDE GEAR RING LH | ✓4-107-1 | 782-16-49 | 1 | | 45° |
| 14 | CROSS SHAFT | 7HA012-3 | | 2 | | |
| 15 | SIDE GEARS | 7HA007-3 | | 2 | | |
| 16 | PLANT WHEELS | 7HA008 | | 4 | | |
| 17 | DISC (FLAT) | 7HA111 | | 4 | | |
| 18 | DISC (SPLINED) | 7HA112 | | 4 | | |

OIL SYSTEM.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

OIL SYSTEM-822 BMW

SHEET 1 of 1

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|----------------------------------|--------------|-----------|-----|-------|--------------|
| 1 | OIL TANK | | 822-14-01 | 1 | | |
| 2 | OIL TANK FILLER TUBE | | 822-14-13 | 1 | | |
| 3 | OIL TANK FILLER TUBE 'O' RING | BS643 | | 1 | | |
| 4 | OIL TANK FILLER CAP | 4-20-1 | 722-18-11 | 1 | | |
| 5 | OIL FILLER CAP 'O' RING | 8-8-9 | TD70 | 1 | | 200-224-5560 |
| 6 | OIL TANK RH LOWER BLANKING PLUG | | 822-14-19 | 1 | | |
| 7 | OIL TANK FILTER HOUSING | | 822-14-09 | 1 | | |
| 8 | OIL TANK FILTER GAUZE | | 822-14-05 | 1 | | |
| 9 | OIL TANK FILTER 'O' RING | R3137 | | 3 | | |
| 10 | OIL TANK OUTLET FLANGE | | 822-14-11 | 1 | | |
| 11 | OIL TANK OUTLET HOSE | | | 1 | | 3/8 I.D. |
| 12 | OIL TANK/ENGINE ALLOY PIPE | | 822-14-22 | 1 | | |
| 13 | BMW ENGINE INLET HOSE | | | 1 | | 3/8 I.D. |
| 14 | BMW ENGINE INLET ADAPTOR | | 822-14-4 | 1 | | |
| 15 | BMW ENGINE OUTLET ADAPTOR | 4-12-4 | 732-14-02 | 1 | | |
| 16 | BMW ENGINE OUTLET UNION | 21-2-6 | | 1 | | -16x90' |
| 17 | BMW ENGINE OUTLET HOSE | 21-2-13 | | 1 | | -16x24" |
| 18 | OIL COOLER INLET UNION | 21-214 | | 1 | | -16STR |
| 19 | OIL COOLER BRK | 3-77-12 | 802-01-55 | 1 | | |
| 20 | OIL COOLER | 6-11-7 | TD8.11.7 | 1 | | 13 ROW |
| 21 | OIL COOLER OUTLET UNION | 21-2-5 | | 1 | | -16x45' |
| 22 | OIL COOLER OUTLET HOSE | 21-2-13 | | 1 | | -16x48" |
| 23 | OIL TANK INLET UNION | 21-2-6 | | 1 | | -16x90' |
| 24 | OIL TANK BREATHER CROSSOVER PLUG | | 822-14-18 | 2 | | |
| 25 | BREATHER CROSSOVER PLUG 'O' RING | GACO 2087 | | 2 | | |
| 26 | BREATHER OUTLET PLUG | | 822-14-17 | 2 | | |
| 27 | BREATHER OUTLET PLUG 'O' RING | GACO 2087 | | 2 | | |
| 28 | BREATHER OUTLET HOSE | | | 1 | | 48" |
| 29 | BREATHER CROSSOVER HOSE | | | 1 | | 9"x3/8" I. |
| 30 | BMW BREATHER BUNG | 4-104-14 | 802-14-10 | 1 | | |

WATER SYSTEM

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

WATER SYSTEM-822 BMW

SHEET 1 of 1

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|------------------------------------|----------|-----------|-----|-------|--------|
| 1 | RADIATOR LH | | 822-13-01 | 1 | | |
| 2 | RADIATOR RH | | 822-13-02 | 1 | | |
| 3 | HEADER TANK BRK | | 812-13-03 | 1 | | |
| 4 | HEADER TANK | | 822-13-05 | 1 | | |
| 5 | HEADER TANK CAP | 8-6-11 | | 1 | | |
| 6 | HEADER TANK HOSE 1/2" I.D. | | | 1 | | |
| 7 | SWIRL POT | | 822-13-06 | 1 | | |
| 8. | RADIATOR PIPE RH (STRAIGHT 3/4 LG) | | | 1 | | |
| 9 | RUBBER BEND 90° | | | 2 | | |
| 10 | FRONT CROSSOVER PIPE | | 822-13-03 | 1 | | |
| 11 | RADIATOR PIPE LH | | | 1 | | |
| 12 | REAR CROSSOVER PIPE | | 822-13-07 | 1 | | |
| 13 | RUBBER HOSE 1 1/2 I.D. x 3" | | | 6 | | |
| 14 | CYLINDER HEAD ADAPTOR | 4-15-2 | 755-13-07 | 1 | | |
| 15 | CYLINDER HEAD ADAPTOR HOSE | | | | | |
| 16 | 1/2" B.S.P. 90° UNION | 3-30-7 | | 4 | | |
| 17 | 1/2" B.S.P. 90° UNION NUT | 8-22-4 | | 4 | | |
| 18 | WATER BLEED PIPE | | | 6ft | | |
| 19 | WATER BLEED PIPE 'O' CLIP | 23-4-8 | | 4 | | |
| 20 | RADIATOR SCREEN | | 822-13-04 | 2 | | |
| 21 | HEADER TANK RAWLNUT 1/2" U.N.F. | 23-3-1 | | 2 | | |
| 22 | WATER HOSE JUBILEE CLIPS | | | 14 | | |

FUEL SYSTEM

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

FUEL SYSTEM-822 BMW

SHEET 1 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|--------------------------------|----------|-----------|-----|-------|----------------|
| 1 | FUEL TANK | | 822-15-01 | 1 | | |
| 2 | COLLECTOR POT | 3-72-13 | 80A-15-02 | 1 | | |
| 3 | COLLECTOR POT FILTER STEM | 3-61-4 | 792-15-05 | 1 | | |
| 4 | COLLECTOR POT FILTER ELEMENT | 8-23-5 | 792-15-07 | 1 | | |
| 5 | COLLECTOR POT OUTLET UNION | 21-1-12 | TD314 | 1 | | -8x90° |
| 6 | COLLECTOR POT OUTLET HOSE | 21-2-10 | TD293 | 1 | | -8x12" |
| 7 | TANK OUTLET INNER UNION | 21-1-12 | TD314 | 1 | | -8x90° |
| 8 | TANK OUTLET ADAPTOR | 4-35-14 | 792-15-06 | 1 | | |
| 9 | TANK OUTLET OUTER UNION | 21-1-10 | TD300 | 1 | | -8STR |
| 10 | TANK OUTLET HOSE | 21-2-10 | TD293 | 1 | | -8x12" |
| 11 | FUEL PUMP INLET UNION | 21-1-12 | TD314 | 1 | | -8x90° |
| 12 | FUEL PUMP INLET ADAPTOR | 4-89-6 | 792-15-18 | 1 | | |
| 13 | FUEL PUMP INLET ADAPTOR SEAL | 20-3-3 | TD1024 | 1 | | |
| 14 | FUEL PUMP | 8-16-8 | TD8-16-8 | 1 | | |
| 15 | FUEL PUMP BRK | 3-77-5 | 802-15-05 | 1 | | |
| 16 | FUEL PUMP OUTLET ADAPTOR | 4-71-9 | 782-15-05 | 1 | | |
| 17 | FUEL PUMP OUTLET ADAPTOR SEAL | 20-3-7 | TD20-3-7 | 1 | | |
| 18 | FUEL PUMP OUTLET UNION | 21-1-9 | | 1 | | -6x90° |
| 19 | FUEL PUMP/METERING UNIT HOSE | 21-2-9 | TD292 | 1 | | -6x36" |
| 20 | METERING UNIT INLET UNION | 21-1-8 | TD306 | 1 | | -6x45° |
| 21 | METERING UNIT INLET BANJO | 4-80-6 | 782-15-18 | 1 | | |
| 22 | METERING UNIT FILTER ELEMENT | 4-76-13 | 783-15-05 | 1 | | |
| 23 | METERING UNIT BANJO BOLT | 4-80-5 | 782-15-17 | 1 | | |
| 24 | METERING UNIT OUTLET ADAPTOR | 4-16-6 | 755-13-14 | 1 | | |
| 25 | METERING UNIT OUTLET UNION | 3-30-7 | | 1 | | ½BSPx90 |
| 26 | METERING UNIT OUTLET UNION NUT | 8-22-4 | | 1 | | |
| 27 | METERING UNIT RETURN PIPE | | | 1 | | |
| 28 | FUEL RETURN PIPE BANJO | 8-26-2 | | 2 | | INTEC 46462 |
| 29 | FUEL RETURN PIPE BANJO BOLT | 4-116-4 | 812-15-01 | 2 | | |
| 30 | BANJO BOLT DOWTY SEAL | | | 4 | | |
| 31 | FUEL RETURN PIPE 'O' CLIP | 23-4-8 | | 4 | | |
| 32 | FILLER NECK/FUEL RETURN BLOCK | | 82-15-04 | 1 | | |
| 33 | FILLER NECK/TANK TOP 'O' RING | BS141 | | 1 | | |
| 34 | FUEL TANK TOP SEAL | 8-24-11 | TD8-24-11 | 1 | | |

FUEL SYSTEM. Cont

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

FUEL SYSTEM-822 BMW

Sheet 2 of 2

| Description | Part No. | Drg. No. | No. | Price | Detail |
|-----------------------------|----------|-----------|-----|-------|--------|
| 35 FUEL TANK CAP | 4-20-1 | 722-18-11 | 1 | | |
| 36 FUEL TANK CAP 'O' RING | 8-8-9 | TD70 | 1 | | |
| 37 FUEL TANK BREATHER PIPE | | | 1 | | 24" |
| 38 FUEL TANK BREATHER VALVE | 4-103-14 | 802-15-08 | 1 | | |

SPHERICAL JOINTS.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

SPHERICAL JOINTS-822

SHEET 1 of 1

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|--------------------------|----------|----------|-----------|-------|--------|
| 1 | FRONT TOP ROCKER OUTER | RBF8B | 15-4-3 | TD15-4-3 | 2 | |
| 2 | FBWB INNER | RSTWRO8E | 15-2-3 | | 4 | |
| 3 | FBWB OUTER | RA10J | 4-94-10 | 802-29-01 | 2 | |
| 4 | FRONT TRACK ROD INNER | RMR5UF | 15-3-2 | TD15-3-2 | 2 | |
| 5 | FRONT TRACK ROD OUTER | RMLR5UF | 15-3-3 | TD15-3-3 | 2 | |
| 6 | FARB LINK BTM | RMR5UF | 15-3-2 | TD15-3-2 | 2 | |
| 7 | FARB LINK TOP | RMLR5UF | 15-3-3 | TD15-3-3 | 2 | |
| 8 | REAR TOP ROCKER OUTER | RBF8B | 15-4-3 | TD15-4-3 | 2 | |
| 9 | RTR SWIVEL FRONT | RSTWR10 | | | 2 | |
| 10 | RTR SWIVEL REAR | RSTNR08A | | | 2 | |
| 11 | RBWB INNER FRONT | RCA06 | | | 2 | |
| 12 | RBWB INNER REAR | RC7H | | | 2 | |
| 13 | RBWB OUTER | RA10J | 4-94-10 | 802-29-01 | 2 | |
| 14 | REAR TRACK ROD INNER | RC6E | 15-1-14 | TD52 | 2 | |
| 15 | REAR TRACK ROD OUTER | RCL7 | 15-3-9 | | 2 | |
| 16 | RARB LINK BTM | RMR5UF | 15-3-2 | TD15-3-2 | 2 | |
| 17 | RARB LINK TOP | RMLR5UF | 15-3-3 | TD15-3-3 | 2 | |
| 18 | RARB BLADE BEARING | RAX720 | 8-25-11 | | 2 | |
| 19 | RARB CABLE FRONT/REAR | RF3U | 15-2-7 | TD15-2-7 | 2 | |
| 20 | GEARLEVER LOCATION JOINT | RBJ67U | 15-2-12 | TD1013 | 2 | |
| 21 | GEARSHIFT MONO FRONT | RAC8 | 15-2-14 | | 1 | |
| 22 | GEARSHIFT MONO REAR | RAC12 | 15-2-13 | | 1 | |
| 23 | GEARSHIFT/OIL TANK | RBJ205L | | | 1 | |
| 24 | MIRROR MOUNT (MOD) | RMP4U | 4-73-11 | 782-12-25 | 2 | |

HYDRAULICS

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

HYDRAULICS-822

SHEET 1 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|-------------------------------------|----------|-----------|-----|-------|-----------------|
| | <u>FRONT BRAKES</u> | | | | | |
| 1 | MASTER CYLINDER 0.75 | 7-3-14 | TD1078 | 1 | | |
| 2 | MASTER CYLINDER RESERVOIR | 7-3-13 | TD1120 | 1 | | |
| 3 | MASTER CYLINDER RESERVOIR SEAL | 20-3-7 | TD20-3-7 | 1 | | 7/16" DOF |
| 4 | MASTER CYLINDER DIAPHRAGM | 7-7-12 | | 1 | | |
| 5 | MASTER CYLINDER PUSH ROD (LONG) | 7-1-7 | TD7-1-7 | 1 | | |
| 6 | BANJO | 979-03P | | 1 | | |
| 7 | BANJO BOLT | 21-4-4 | | 1 | | |
| 8 | BANJO BOLT COPPER WASHER | | | 6 | | |
| 9 | BANJO OUTLET UNION | 21-1-2 | TD699 | 2 | | -3x45" |
| 10 | MASTER CYLINDER/CALIPER HOSE | 21-2-7 | TD290 | AR | | -3AEROQ |
| 11 | CALIPER INLET BANJO | 21-4-3 | TD21-4-3 | 2 | | -3x30" B |
| 12 | CALIPER INLET BANJO BOLT | 21-4-6 | TD690 | 2 | | |
| 13 | CALIPER | 7-2-1 | TD107 | 2 | | |
| 14 | BRAKE PAD | 7-2-8 | TD276 | 4 | | |
| | <u>REAR BRAKES</u> | | | | | |
| 15 | MASTER CYLINDER 0.75 | 7-3-14 | TD1078 | 1 | | |
| 16 | MASTER CYLINDER RESERVOIR | 7-3-13 | TD1120 | 1 | | |
| 17 | MASTER CYLINDER RESERVOIR SEAL | 20-3-7 | TD20-3-7 | 1 | | 7/16" DO |
| 18 | MASTER CYLINDER DIAPHRAGM | 7-7-12 | | 1 | | |
| 19 | MASTER CYLINDER PUSH ROD (LONG) | 7-1-7 | TD7-1-7 | 1 | | |
| 20 | MASTER CYLINDER OUTLET ADAPTOR | 4-8-7 | 732-06-18 | 1 | | 1/8" BSP / 3/8" |
| 21 | MASTER CYLINDER OUTLET UNION | 21-1-3 | TD701 | 1 | | -3x90" |
| 22 | MASTER CYLINDER/TEE PIECE HOSE | 21-2-7 | TD290 | AR | | -3AEROQ |
| 23 | TEE PIECE INLET/OUTLET UNION | 21-1-1 | TD697 | 3 | | -3 STR |
| 24 | TEE PIECE/CALIPER HOSE | 21-2-7 | TD290 | AR | | -3AEROQ |
| 25 | CALIPER INLET BANJO | 21-4-3 | TD21-4-3 | 2 | | -3x30" B |
| 26 | CALIPER INLET BANJO BOLT | 21-4-6 | TD690 | 2 | | |
| 27 | BANJO BOLT COPPER WASHER | | | 4 | | |
| 28 | CALIPER | 7-2-1 | TD107 | 2 | | |
| 29 | BRAKE PADS | 7-2-8 | TD276 | 4 | | |
| | <u>CLUTCH SYSTEM</u> | | | | | |
| 30 | MASTER CYLINDER 0.75 (SHORT DRIVER) | 7-3-14 | TD1078 | 1 | | |

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|-------------------------------------|---------------|-----------|-----|-------|--------------------|
| 31 | MASTER CYLINDER O.875 (TALL DRIVER) | | | AR | | |
| 32 | MASTER CYLINDER RESERVOIR | 7-3- | | 1 | | |
| 33 | MASTER CYLINDER RESERVOIR SEAL | 20-3-7 | TD20-3-7 | 1 | | 7/16" DOWT |
| 34 | MASTER CYLINDER DIAPHRAGM | 7-7-12 | | 1 | | |
| 35 | MASTER CYLINDER PUSH ROD (LONG) | 7-1-7 | TD7-1-7 | 1 | | |
| 36 | MASTER CYLINDER OUTLET ADAPTOR | 4-8-7 | 732-06-18 | 1 | | 1/8" BSP / 3/8" UN |
| 37 | MASTER CYLINDER OUTLET UNION | 21-1-3 | TD701 | 1 | | -3x90° |
| 38 | MASTER CYLINDER/OIL TANK HOSE | 21-217 | TD290 | AR | | -3AEROQU |
| 39 | CLUTCH FEED PIPE INLET UNION | 21-1-3 | TD701 | 1 | | -3x90° |
| 40 | CLUTCH FEED PIPE ASS. | | 822-25-02 | 2 | | |
| 41 | CLUTCH FEED PIPE 'O' RING | GACO R3037 | | 2 | | |
| 42 | CLUTCH FEED OUTLET UNION | 21-1-3 | TD701 | 1 | | -3x90° |
| 43 | CLUTCH FEED/CLUTCH BLEED HOSE | 21-2-7 | TD290 | AR | | -3AEROQU |
| 44 | CLUTCH BLEED INLET UNION | 21-1-1 | TD697 | 1 | | -3STR |
| 45 | CLUTCH BLEED | 4-102-11 | 802-25-01 | 1 | | |
| 46 | CLUTCH BLEED LOCK NUT | 13-5-8 | TD13-5-8 | 1 | | |
| 47 | CLUTCH BLEED NIPPLE | 8-24-4 | | 1 | | |
| 48 | MASTER CYLINDER TOP HAT SPACER | 44-12-9 | 792-19-07 | 6 | | |

ELECTRICS.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

ELECTRICS-822 AIR START

SHEET 1 of 1

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|-----------------------------|-----------|-----------|-----|-------|--------|
| 1 | BATTERY 12 VOLT YUASA | 12M53B | | 1 | | |
| 2 | ZENNER DIODE LUCAS | 49589 | | 1 | | |
| 3 | MASTER SWITCH | 8825-B140 | 26864-46 | 1 | | |
| 4 | KILL SWITCH | 9-1-12 | TD426 | 1 | | |
| 5 | IGNITION SWITCH | 9-1-12 | TD426 | 1 | | |
| 6 | FUEL PUMP/FIRE EXT M/SWITCH | 8825-B140 | 26864-46 | 1 | | |
| 7 | REAR LIGHT SWITCH | 9-1-12 | TD426 | 1 | | |
| 8 | REAR LIGHT | 9-9-7 | | 1 | | |
| 9 | OIL PRESSURE SWITCH | 9-4-6 | TD951 | 1 | | |
| 10 | OIL PRESSURE WARNING LIGHT | 9-9-6 | TD9-9-6 | 1 | | |
| 11 | FIRE EXTINGUISHER BUTTON | 9-1-2 | TD274 | 1 | | |
| 12 | WIRING LOOM | | | 1 | | |
| 13 | FIRE POWER PACK | 29-1-6 | TD1006 | 1 | | |
| 14 | SPARK BOX BASE | | | 1 | | |
| 15 | SPARK BOX BASE MTG | | | 1 | | |
| 16 | SPARK BOX PLUG | 9-10-4 | | 1 | | |
| 17 | SPARK BOX SOCKET | 9-10-5 | | 1 | | |
| 18 | REAR LIGHT BRK | | 822-12-16 | 1 | | |
| 19 | MASTER SWITCH BRK | | 822-01-91 | 1 | | |
| 20 | FIRE PULL BRK | | 822-01-90 | 1 | | |
| 21 | FIRE PULL CABLE | | | 1 | | 18" |
| 22 | FIRE PULL CABLE SLEEVE | | | 1 | | 6" |
| 23 | FIRE PULL NIPPLE | 8-2-5 | | 2 | | |

Body work.

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

BODYWORK-822

SHEET 1 of 2

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|----------------------------------|----------|-----------|-----|-------|--------|
| 1 | NOSE TOP PANEL | | | 1 | | |
| 2 | NOSE UNDER PANEL | | | 1 | | |
| 3 | NOSE BOX | | 822-01-78 | 1 | | |
| 4 | FRONT WING LH | | 822-12-09 | 1 | | |
| 5 | FRONT WING RH | | 822-12-10 | 1 | | |
| 6 | FRONT WING PIVOT BLOCK | | 81C-01-35 | 2 | | |
| 7 | FRONT WING CENTRE TUBE | | 822-12-12 | 1 | | |
| 8 | FRONT WING ADJUSTER SCREW | | 822-01-79 | 1 | | |
| 9 | FRONT WING ADJUSTER CLEVIS | | 822-01-80 | 1 | | |
| 10 | FRONT WING ADJUSTER CLEVIS BRK | | 822-01-8L | 1 | | |
| 11 | FRONT WING ADJUSTER SCREW BARREL | | 822-01-82 | 1 | | |
| 12 | FRONT WING ADJUSTER SCREW SOCKET | | 822-01-83 | 1 | | |
| 13 | NOSE FRAME CLEVIS SPACER | | 822-20-03 | 1 | | |
| 14 | FRONT WING FLAP | | 822-12-17 | 2 | | |
| 15 | FRONT WING END PLATE | | | 2 | | |
| 16 | BATTERY BOX BASE | | 822-28-01 | 1 | | |
| 17 | BATTERY BOX TOP | | 822-28-02 | 1 | | |
| 18 | NOSE BODY BOBBIN | | 81C-12-93 | 4 | | |
| 19 | NOSE BODY BOBBIN 'O' RING | | | 2 | | |
| 20 | FUEL TOWER CRUSHABLE LH | | | 1 | | |
| 21 | FUEL TOWER CRUSHABLE RH | | | 1 | | |
| 22 | COCKPIT | | | 1 | | |
| 23 | COCKPIT SCREEN | 11-7-11 | | 1 | | |
| 24 | COCKPIT SCREEN BOLT 2BA NYLON | 12-2-9 | | 13 | | |
| 25 | COCKPIT SCREEN NUT 2BA NYLON | 13-1-10 | | 13 | | |
| 26 | MIRROR LH | 11-11-13 | | 1 | | |
| 27 | MIRROR RH | 11-11-14 | | 1 | | |
| 28 | SIDE POD FRONT PANEL LH | | | 1 | | |
| 29 | SIDE POD FRONT PANEL RH | | | 1 | | |
| 30 | SIDE POD REAR PANEL LH | | | 1 | | |
| 31 | SIDE POD REAR PANEL RH | | | 1 | | |
| 32 | UNDER WING CENTRE PANEL | | | 1 | | |
| 33 | UNDER WING MTG BRK TOP LH | | 822-12-19 | 1 | | |
| 34 | UNDER WING MTG BRK TOP RH | | 822-12-20 | 1 | | |

| ISSUE | SIGNATURE | DATE |
|-------|-----------|------|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |

| | Description | Part No. | Drg. No. | No. | Price | Detail |
|----|------------------------------------|----------|-----------|-----|-----------|-----------|
| 35 | UNDER WING MTG BRK LOWER | | 822-12-21 | 2 | | |
| 36 | UNDER WING MTG STAY | | | 2 | | |
| 37 | UNDER WING MTG BUSH | | | 4 | | |
| 38 | REAR BULKHEAD/SIDEWING MTG STUD | | 822-01-88 | 4 | | |
| 39 | REAR BULKHEAD/SIDEWING MTG TOP | | | 2 | | |
| 40 | REAR BULKHEAD/SIDEWING MTG BTM | | | 2 | | |
| 41 | UNDER WING/OIL TANK REAR MTG | | | 2 | | |
| 42 | REAR TOP DECK LH | | | 1 | | |
| 43 | REAR TOP DECK RH | | | 1 | | |
| 44 | HEAD REST | 11-11-15 | | 1 | | |
| 45 | HELMET REST | 11-12-4 | | 1 | | |
| 46 | SEAT KIT | 11-13-15 | | 1 | | |
| 47 | RUBBING STRIP FRONT LH | | | 1 | | |
| 48 | RUBBING STRIP FRONT RH | | | 1 | | |
| 49 | RUBBING STRIP REAR LH | | | 1 | | |
| 50 | RUBBING STRIP REAR RH | | | 1 | | |
| 51 | RUBBING STRIP CENTRE | | | 2 | | |
| 52 | CERAMIC BLOCK | | 822-12-14 | 8 | | |
| 53 | CERAMIC RODS 3" | 8-25-3 | | 8 | | |
| 54 | RAD DUCT SPACERS 1" | | 822-12-29 | 2 | | |
| 55 | REAR WING PILLAR | | 822-12-03 | 1 | | HONEYCOMB |
| 56 | WING PILLAR SANDWICH PLATE | | 822-12-13 | 2 | | |
| 57 | WING PILLAR MTG PLATE | | 822-12-04 | 2 | | |
| 58 | WING PILLAR MTG BUSH | | 822-12-05 | 2 | | |
| 59 | WING PILLAR SILENT BLOCK BUSH | 8-13-2 | | 4 | | |
| 60 | WING PILLAR SILENT BLOCK SPACER | 4-103-15 | 802-12-20 | 2 | | |
| 61 | WING PILLAR MTG PLATE INSERT INNER | 4-104-12 | 802-12-11 | 4 | | |
| 62 | WING PILLAR MTG PLATE INSERT OUTER | 41-7-7 | 802-2028 | 4 | | |
| 63 | WING MAINPLANE | | 822-12-22 | 1 | | |
| 64 | WING FLAP | 46-2-6 | 792-12-01 | 1 | | |
| 65 | WING SIDEPLATE | | 822-12-26 | 2 | 753-12-05 | |
| 66 | WING MOUNTING WASHER | 46-2-11 | 792-12-08 | 2 | | |