

MARCH ENGINEERING LTD.  
862 KIT LIST.  
MONOCOQUE.

	Description	No.	Part Number
1	MONOCOQUE	1	862-00-00
2	BATH TUB SKIN (HONEYCOMB)	1	862-01-09
3	FRONT BULKHEAD (HONEYCOMB)	1	86B-01-14
4	MID FRONT BULKHEAD (HONEYCOMB)	1	85B-01-12
5	MID REAR BULKHEAD (HONEYCOMB)	1	86B-01-08
6	DASH BULKHEAD (HONEYCOMB)	1	85B-01-29
7	SEATBACK BULKHEAD (HONEYCOMB)	1	85B-01-28
8	REAR BULKHEAD (HONEYCOMB)	1	862-01-02
9	CARBON TOP BODY	1	86B-01-01
10	F.L.W.B. MASTER CYL MYG 6.26.3	1	85B-01-07
11	F.T.W.B. INNER MTG INSERT	2	842-02-24 ✓
12	L.W.B. FRONT MTG SLEEVE	2	842-02-33 ✓
13	BRAKE/CLUTCH CHANNEL 6.16.1	2	86B-01-06
14	THROTTLE PEDAL CHANNEL 6.16.1	1	822-08-01
15	INNER COCKPIT PANEL R.H.	1	85B-01-60
16	INNER COCKPIT PANEL L.H.	1	85B-01-61
17	SPRING COVER PANEL	2	85B-01-62
18	MID INNER PANEL L.H.	1	85B-01-63
19	MID INNER PANEL R.H.	1	85B-01-64
20	DIAPHRAGM-COCKPIT PANEL L.H.	1	85B-01-67
21	DIAPHRAGM-COCKPIT PANEL R.H.	1	85B-01-68
22	FRONT INNER SKIN R.H.	1	85B-01-54
23	FRONT INNER SKIN L.H.	1	85B-01-55
24	CLUTCH REST	1	803-01-98

MARCH ENGINEERING LTD.  
 B&Z KIT LIST.  
 MONOCOQUE (CON., T) .

	Description	No.	Part Number
25	CRASH HOOP	1	86B-01-02
26	FRONT CRASH HOOP MTG L.H.	1	85B-01-46
27	FRONT CRASH HOOP MTG R.H.	1	85B-01-47
28	CRASH HOOP FRONT MTG BOLT	2	85B-01-59
29	THROTTLE SPACER	1	772-01-06
30	THROTTLE CABLE CLAMP	1	8-16-14
31	THROTTLE CABLE FRONT MTG BRK	1	792-01-87
32	SEAT BELT HARNESS	1	8-25-9
33	SEAT BELT TOP MTG.BRKT.	2	86A-01-13
34	SEAT BELT TOP MTG SPACER	2	792-20-44
35	SEAT BELT TOP MTG BOLT	2	12-19-15
36	SEAT BELT LOWER MTG ANGLE R.H.	1	86B-01-16
37	SEAT BELT LOWER MTG.ANGLE LH	1	86B-01-15
38	SEAT BELT ANCHOR SP.LONG	2	842-01-44 ✓
39	SEAT BELT ANCHOR SP.SHORT	2	842-01-43 ✓
40	5.0 KG FIRE EXTINGUISHER	1	29-1-8
41	5.0 KG FIRE BOTTLE ADPT 400003	1	29-4-14
42	7.5 KG BOTTLE CLIP 140-160	2	25-2-10
43	2.5 KG FIRE EXTINGUISHER	1	29-1-10
44	1/8 BSP X 1/8 BSP ADAPTOR	1	752-14-04
45	2.5 KG BOTTLE CLIP 120/140	2	25-3-2
46	2.5 KG FIRE BOTTLE BRK	1	85B-22-02
47	LIFE SUPPORT BOTTLE	1	29-3-14
48	LIFE SUPPORT BOTTLE HOSE	1	29-3-9

Section Number: 1 Page Number: 3 Date: 10/07/86

MARCH ENGINEERING LTD.  
B&B KIT LIST.  
MONDOQUE (CON, T) .

	Description	No.	Part Number
49	FIRE PULL CABLE BRK	1	B6C-01-85

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 FRONT SUSPENSION.

	Description	No.	Part Number
1	F.T.W.B. INNER MTG RH	2	842-02-01 ✓
2	F.T.W.B. INNER MTG LH	2	842-02-02 ✓
3	F.T.W.B. INNER MTG INSERT	8	842-02-24 ✓
4	FRONT TOP WISHBONE RH	1	85B-02-10
5	FRONT TOP WISHBONE LH	1	85B-02-11
6	W.B. INNER JOINT INSERT	8	842-02-23 ✓
7	ROSE JOINT ABWT7	4	15-7-1
8	CIRCLIP 1300-93	4	23-7-2
9	FTWB OUTER JT.INSERT	4	803-02-16
10	ROSE JOINT RBF 8B	2	15-4-3
11	CIRCLIP 1300-150	2	23-5-13
12	* F.T.W.B. ASSEMBLY	1	
13	PULL ROD 18.31" STD	2	85B-02-12
14	ROSE JOINT ARHTL 7	2	15-7-11
15	ROSE JOINT ARHT 7	2	15-7-2
16	PULL ROD JOINT BUSH	4	842-02-12 ✓
17	* PULL ROD ASSEMBLY	1	
18	FRONT LOWER WISHBONE	2	85B-02-06
19	ROSE JOINT RH RC7H	4	15-4-10
20	F.L.W.B. REAR JOINT INSERT	4	842-02-22 ✓
21	W.B. INNER JOINT INSERT	4	842-02-23 ✓
22	NMB JOINT ARHT10E	2	15-7-13
23	OUTER JOINT LOCK NUT	2	85B-02-07
24	* F.L.W.B. ASSEMBLY	1	

MARCH ENGINEERING LTD.  
 B62 KIT LIST.  
 FRONT SUSPENSION (CON, T) .

	Description	No.	Part Number
25	PULL ROD LEVER	2	85B-02-14
26	PULL ROD LEVER BUSH	4	84C-02-10 ✓
27	PULL ROD LEVER INSERT	4	85B-02-15
28	LEVER THRUST WASHER	1	842-02-04 ✓
29	LEVER PIVOT BOLT	1	84C-02-13
30	LEVER PIVOT BOLT WASHER	1	83C-02-17
31	PIVOT BOLT INSERT	2	83C-02-66
32	PIVOT BOLT PRELOAD WASHER	1	83C-02-51
33	KONI DAMPER 3012 1610 BASS	2	16-11-10
34	FRONT LOWER DAMPER INSERT	4	842-02-27 ✓
35	FRONT LOWER DAMPER MOUNTING	2	842-02-21 ✓
36	FRONT LOWER DAMPER MTG DOWEL	4	842-02-26
37	800 LB X 6" ROAD SPRING	2	16-11-8
38	FRONT TOP DAMPER MTG.	2	86B-02-01
39	FRONT TOP DAMPER PIN	4	86B-02-05
40	DAMPER TOP MTG BEARING	4	86B-02-02
41	DAMPER TOP MTG LOCK NUT	2	85B-02-09
42	DAMPER TOP MTG TOP NUT	2	86B-02-03
43	DAMPER TOP PIN RETAINER	2	86B-02-06
44	DAMPER TOP SHAFT INSERT	2	86B-02-04
45	M.F.B.H. DAMPER SLEEVE INSERT	2	85B-01-36
46	M.R.B.H. DAMPER SLEEVE INSERT	2	85B-01-37

MARCH ENGINEERING LTD.  
 B&B KIT LIST.  
 STEERING RACK.

	Description	No.	Part Number
1	STEERING WHEEL V2.Ø192/5	1	8-41-11
2	KILL SW SANDWICH PLATE	1	832-04-11✓
3	STEERING WHEEL HUB	1	830-04-05
4	QUICK RELEASE SPRING	1	16-10-03
5	QUICK RELEASE COLLAR	1	810-04-14
6	QUICK RELEASE BALLS	3	8-25-13
7	QUICK RELEASE SPLINED END	1	850-04-15
8	STEERING COLUMN	1	842-04-10✓
9	STEERING COLUMN SAFETY COLLAR	1	812-20-76
10	STEERING COLUMN COUPLING	1	782-04-04
11	STEERING COLUMN MTG BLOCK	1	830-04-01
12	STEERING COLUMN MTG BRK	1	842-04-06✓
13	STEERING RACK HOUSING	1	842-04-03✓
14	STEERING RACK BAR 19.25"	1	842-04-02✓
15	STEERING RACK END PLUG	2	822-04-05
16	STEERING RACK PINION 6 TOOTH	1	8-23-14
17	RACK PINION BEARING	2	8-1-6
18	PINION SEAL	1	8-22-11
19	PINION BRG. SPRING WASHER	1	4-45-11
20	PINION BRG RETAINING PLATE	1	8-38-4
21	RACK CIRCLIP	1	8-17-3
22	RACK TENSION CAP	1	8-38-1
23	RACK TENSION SPRING	1	8-38-2
24	RACK TENSION SPRING STOP	1	4-4-10

MARCH ENGINEERING LTD.  
 842 KIT LIST.  
 STEERING RACK (CON.T)

	Description	No.	Part Number
25	SPRING RETAINER	1	8-38-3
26	RACK OILITE BUSH	2	8-18-5
27	RACK HOUSING SEAL	2	8-9-6
28	STEERING RACK ASSEMBLY	1	37-2-4
29	STEERING RACK MTS BLOCK 6.15.1	2	842-04-01✓
30	STEERING RACK STOP	2	832-20-07✓
31	STEERING RACK CLEVIS	2	810-04-10
32	RACK CLEVIS LOCK NUT	2	842-04-07✓
33	RACK MTS SHIM	1	842-04-08✓
34	RACK MTS NUT	4	842-04-11✓
35	FRONT TRACK ROD STD	2	858-04-02
36	ROSE JOINT RH RMR 5UF	2	15-3-2
37	ROSE JOINT LH RMLR 5UF	2	15-3-3
38	TRACK ROD INNER JOINT INSERT	4	810-04-17
39	BUMP STEER SPACER LARGE	2	712-04-11
40	BUMP STEER SPACER MED	2	712-04-12
41	BUMP STEER SPACER SMALL	2	792-20-32

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 REAR SUSPENSION.

	Description	No.	Part Number
1	REAR SUSPENSION PLATE	1	862-03-01
2	REAR SUSP PLATE MTG STUD	4	842-23-05 ✓
3	R.T.R. FRONT MOUNTING BLOCK RH	1	862-03-06
4	R.T.R. FRONT MOUNTING BLOCK LH	1	862-03-05
5	R/U/R D/S DRK DOWEL	4	822-20-02
6	MOUNTING STUD	8	822-16-18
7	REAR TOP ROCKER LH	1	862-03-03
8	REAR TOP ROCKER RH	1	862-03-02
9	SWIVEL JOINT RSTWR 10	2	15-5-1
10	SWIVEL JOINT RSTNR 08A	2	15-4-15
11	R.T.R. FRONT JOINT WASHER	2	822-20-05
12	R.T.R. PIVOT NUT	2	832-03-02 ✓
13	ROSE JOINT RSTWR08	2	15-6-5
14	CIRCLIP NAM 1300/100	2	23-4-13
15	RLWB FRONT MOUNTING LH	1	862-03-07
16	RLWB FRONT MOUNTING RH	1	862-03-08
17	RLWB REAR MTG. PLATE 6.28.11	1	862-03-13
18	UNDERTRAY/GEARBOX ADAPTOR	2	862-12-01
19	R.L.W.B. REAR MTG INSERT	4	858-03-35
20	REAR LOWER WISHBONE	2	862-03-04
21	ROSE JOINT RH RC7H	4	15-4-10
22	W.B. INNER JOINT INSERT	8	842-02-23 ✓
23	RLWB FRONT MTG. INSERT	4	862-03-20 ✓
24	ROSE JOINT RA 08	2	15-7-12

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 REAR SUSPENSION (CON, T) .

	Description	No.	Part Number
25	CIRCLIP (ANDERTON 2300-29)	4	23-6-14
26	OUTER JNT HSG STUD LONG	4	860-23-05
27	OUTER JNT HSG INSERT 0.93"	4	860-19-01
28	OUTER JOINT HOUSING	2	86B-03-37
29	* R.L.W.B. ASSEMBLY	1	
30	REAR TRACK ROD 4.93	2	862-03-10
31	ROSE JOINT LH ARTL 6ECR	2	15-3-12
32	ROSE JOINT RH RC6H	2	15-1-13
33	REAR TRACK ROD ASSEMBLY	1	
34	R.A.R.B. JOINT LINK CTR. 2.625	2	862-05-04
35	RH ROSE JOINT ARHT SECR	2	15-7-9
36	ROSE JOINT ARHT 5	2	15-8-8
37	RARB LINK SPACER	2	842-03-06/
38	REAR LOWER DAMPER MTG. LH	1	842-03-11
39	REAR LOWER DAMPER MTG. RH	1	842-03-10
40	1000 LBS. X 6" SPRING	2	16-12-2
41	KONI DAMPER 3012 1610 B453	2	16-11-10
42	KONI DAMPER TOP (HONDA)	2	862-03-24
43	REAR LOWER DAMPER INSERT	2	822-03-14
44	REAR LOWER DAMPER BOLT	2	822-03-13
45	REAR DAMPER SAFETY WASHER	2	822-03-33
46	REAR TOP DAMPER INSERT	4	822-03-26
47	R.T.R./DAMPER THROUGH BOLT	2	12-18-8
48	RLWB REAR TOP BRACKET LH	1	862-03-11

MARCH ENGINEERING LTD.  
862 KIT LIST.  
REAR SUSPENSION (CON. T) .

	Description	No.	Part Number
49	RLWB REAR TOP BRACKET RH	1	862-03-12
50	RLWB CAMBER SHIM 0.166	2	862-03-14
51	RLWB CAMBER SHIM 0.208	2	862-03-15
52	RLWB CAMBER SHIM 0.249	2	862-03-16
53	RLWB CAMBER SHIM 0.290	2	862-03-17
54	RLWB CAMBER SHIM 0.125	2	862-03-18

MARCH ENGINEERING LTD.  
 B&Z KIT LIST.  
 ANTI ROLL BARS.

	Description	No.	Part Number
1	F.A.R.B. Ø.750" DIA	1	86B-05-09
2	F.A.R.B. Ø.625" DIA	1	86B-05-10
3	F.A.R.B. Ø.575" DIA (STD)	1	86B-05-13
4	F.A.R.B. MOUNTING CHANNEL	2	85B-01-38
5	F.A.R.B. MOUNTING BLOCK NUT	4	842-05-09 ✓
6	A.R.B. MTG BLOCK	2	85B-05-07
7	R.A.R.B. CABLE MTG BLOCK	1	862-05-05
8	A.R.B. CABLE BRK "U" BOLT	1	86B-05-08
9	FARB CABLE 22" 3222	1	28-2-3
10	FARB CABLE OUTER EXTENSION	1	86B-05-12
11	UNDERWING REAR HT. ADJ. BODY	1	86C-12-36
12	RML3U ROSE JOINT	1	15-8-13
13	A.R.B. BLADE CROSS LINK	1	86B-23-03
14	ROSE JOINT RH RFSU	3	15-2-7
15	A.R.B. BLADE ADJUSTER	2	86B-05-11
16	A.R.B. ADJUSTER BLADE CAP	2	83C-05-14
17	A.R.B. ADJUSTABLE BLADE WASHER	2	83C-05-15
18	BEARING RAX720	4	8-25-11
19	BEARING T/WASHER SMALL	2	8-25-12
20	F.A.R.B. BLADE	2	86B-05-06
21	ROSE JOINT RFC 4U	2	15-7-3
22	ROSE JOINT RC4 H	2	15-7-4
23	F.A.R.B. DROP LINK INSERT	6	842-02-25 /
24	MTG. BLOCK A.R.B. ADJUSTER	1	85C-05-43

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 ANTI ROLL BARS (CON, T) .

	Description	No.	Part Number
25	PIVOT ROD	1	85C-05-45
26	LOCK PLATE	2	85B-05-16
27	LOCKING PIN	2	85C-05-49
28	ANTI ROLL BAR ADJUSTER LEVER	2	85C-05-46
29	KNOB	2	8-41-12
30	HANDLE FRONT	1	85C-05-51
31	HANDLE REAR	1	85C-05-50
32	ARB ADJUST ARM SPRING 1"	1	86C-05-15
33	A.R.B. CABLE 2.30 METERS	1	85B-05-12
34	ROSE JOINT RH RF3U	4	15-2-7
35	A.R.B. CABLE BRK "U" BOLT	1	86B-05-08
36	R.A.R.B. CABLE MTG BLOCK	1	862-05-05
37	R.A.R.B. MTG. BLOCK 6.22.14	2	842-05-10 ✓
38	R.A.R.B. MTG. BLOCK BUSH	2	83C-05-26
39	REAR ANTI ROLL BAR 0.75	1	862-05-03
40	R.A.R.B. FIXED BLADE	1	842-05-02 ✓
41	R.A.R.B. ADJUSTABLE BLADE	1	84C-05-22 ✓
42	BEARING RAX720	1	8-25-11
43	BEARING T/WASHER SMALL	1	8-25-12
44	R.A.R.B. END FLOAT SPACER	1	842-05-03 ✓
45	A.R.B. BLADE ADJUSTER	1	86B-05-11
46	A.R.B. ADJUSTER BLADE CAP	1	83C-05-14
47	A.R.B. ADJUSTABLE BLADE WASHER	1	83C-05-15

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 FRONT UPRIGHT.

	Description	No.	Part Number
1	FRONT UPRIGHT 6-25-11	2	862-06-01
2	FRONT AXLE	2	822-06-03
3	FRONT AXLE DRIVE PIN	6	822-06-04
4	WHEEL BEARING	4	8-1-5
5	WHEEL BEARING SPACER	2	832-07-02
6	WHEEL BEARING OUTER SPACER	2	822-06-05
7	FRONT BOTTOM PIN STD	2	85B-06-11
8	BOTTOM PIN SPACER	2	802-06-04
9	OUTER JOINT SAFETY WASHER	2	802-06-07
10	*FRONT UPRIGHT ASSEMBLY	1	
11	WHEEL STUD	2	822-06-01
12	WHEEL STUD WASHER	2	822-06-02
13	WHEEL STUD WASHER LOCK NUT	2	822-06-06
14	BRAKE DISC	2	7-1-5
15	BRAKE DISC BELL	2	802-06-02
16	DISC BOLT	12	4-59-8
17	DISC BELL BOLT NUT	12	13-2-6
18	UPRIGHT D/S PLATE LH	2	85B-04-04
19	UPRIGHT D/S PLATE RH	2	85B-04-03
20	UPRIGHT D/S SPACER 6.11.4	2	85B-06-12
21	UPRIGHT D/S PLATE LONG STUD	8	802-16-25
22	D/S PLATE ROCKER PIVOT INSERT	4	832-04-06
23	D/S PLATE T/RDD PIVOT INSERT	4	832-04-04
24	FRONT BRAKE DUCT	2	85B-12-09

MARCH ENGINEERING LTD.  
862 KIT LIST.  
FRONT UPRIGHT (CON, T) .

	Description	No.	Part Number
25	BRAKE DUCT BRACKET LH	1	86B-06-01
26	BRAKE DUCT BRACKET RH	1	86B-06-02
27	WHEEL WASHER	2	771-09-01
28	WHEEL WASHER INSERT	2	712-07-11
29	WHEEL RETAINING NUT	2	13-1-1
30	FRONT WHEEL 10" X 5.5" X 13"	2	782-09-09

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 REAR UPRIGHT.

	Description	No.	Part Number
1	REAR UPRIGHT LH 6.28.7	1	862-07-01
2	REAR UPRIGHT RH 6.28.8	1	862-07-02
3	REAR AXLE	2	802-07-01
4	REAR AXLE DRIVE PIN	12	822-09-06
5	WHEEL BEARING	4	8-1-5
6	WHEEL BEARING SPACER	2	832-07-02 ✓
7	WHEEL BEARING OUTER SPACER	2	711-07-05
8	UPRIGHT BOTTOM PIN	2	86C-07-13
9	BOTTOM PIN D/S PLATE	2	86B-07-13
10	BOTTOM PIN SPACER	2	86C-07-14
11	* REAR UPRIGHT ASSEMBLY	1	
12	BRAKE DISC	2	7-1-5
13	BRAKE DISC BELL	2	802-06-02
14	DISC BOLT	12	4-59-8
15	DISC BELL BOLT NUT	12	13-2-6
16	R/U/R FRONT D/S BRK LH 2"	1	86B-07-01
17	R/U/R FRONT D/S BRK RH 2"	1	86B-07-02
18	R/U/R REAR D/S BRK LH 2"	1	86B-07-03
19	R/U/R REAR D/S BRK RH 2"	1	86B-07-04
20	R.T.R. OUTER JOINT BOLT	2	86B-03-03
21	R.T. ROD OUTER JOINT BOLT	2	86B-03-04
22	R/U/R D/S BRK SHORT STUD	2	822-07-05
23	R/U/R D/S BRK DOWEL	4	822-20-02
24	R.T.R. OUTER JOINT INSERT	4	85B-03-11

MARCH ENGINEERING LTD.  
 842 KIT LIST.  
 REAR UPRIGHT (CON, T) .

	Description	No.	Part Number
25	R.T. ROD. JOINT INSERT	10	85B-03-33
26	WHEEL WASHER	2	771-09-01
27	WHEEL WASHER INSERT	2	712-07-11
28	WHEEL RETAINING NUT	2	13-1-1
29	REAR WHEEL 14" X 5.5" X 13"	2	002-09-01
30	DRIVESHAFT 457 F/F	2	14-4-13
31	PLUNGE JOINT ASSY	4	842-16-14
32	CV JOINT BAITER	4	8-34-8
33	CV JOINT WASHER	4	8-34-9
34	CV JOINT CIRCLIP	4	23-9-8
35	DUCKHAMS 5795 GREASE 3 kg	1	8-34-10
36	* DRIVESHAFT ASSEMBLY	1	
37	CV JOINT INNER/OUTER BOLT	24	85B-16-30
38	5/16" U.N.F. 'K' NUT	24	13-2-2
39	CV JOINT OUTER FLANGE	2	832-10-04
40	REAR WHEEL RETAINING STUD	2	602-07-07

MARCH ENGINEERING LTD.  
 B&B KIT LIST.  
 PEDALS.

	Description	No.	Part Number
1	THROTTLE PEDAL	1	812-08-01
2	PEDAL PIVOT BEARING 06 DU 08	2	8-1-10
3	PEDAL PIVOT BUSH	1	712-08-07
4	THROTTLE PEDAL ASSEMBLY	1	
5	BRAKE PEDAL	1	856-08-01
6	PEDAL PIVOT BEARING 06 DU 08	2	8-1-10
7	PEDAL PIVOT BUSH	1	712-08-07
8	* BRAKE PEDAL ASSEMBLY	1	
9	BALANCE BAR SHAFT	1	810-08-09
10	BALANCE BAR YOKE	2	802-08-02
11	BALANCE BAR CABLE (Per foot)	3	8-24-13
12	1/8" BSP NYLON PIPE (Per foot)	3	8-8-5
13	BALANCE BAR ADJUSTER	1	792-26-04
14	ADJUSTER BODY BUSH	1	842-19-01
15	BALANCE BAR ADJUSTER KNOB	1	9-5-3
16	BRAKE ADJUSTER ASSEMBLY	1	
17	CLUTCH PEDAL	1	803-08-02
18	PEDAL PIVOT BEARING 06 DU 08	2	8-1-10
19	PEDAL PIVOT BUSH	1	712-08-07
20	OILITE BUSH	1	8-18-1
21	* CLUTCH PEDAL ASSEMBLY	1	
22	CLUTCH CLEVIS	1	771-08-04
23	CLUTCH CLEVIS PIN	1	771-08-09
24	CLEVIS PIN 'R' CLIP	1	23-7-1

MARCH ENGINEERING LTD.  
862 KIT LIST.  
PEDALS (CON.T).

	Description	No.	Part Number
25	PEDAL STOP	2	832-01-01 ✓
26	PEDAL STOP ADJUSTER	2	832-01-52 ✓

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 ENGINE INSTALLATION.

	Description	No.	Part Number
1	THROTTLE CABLE 2.15 MTRS.	1	28-2-5
2	OIL PRESS SW "T" PIECE	1	85B-14-08
3	OIL PRESS. SWITCH WS14 40-60LB	1	9-19-9
4	OIL PRESS TAKE OFF (YAMAHA)	1	862-16-35
5	OIL PRESS TAKE OFF (HONDA)	1	822-14-26
6	OIL INLET ADAPTOR (HONDA)	1	832-14-07 ✓
7	TOP ENGINE MTG L.H. (HONDA)	1	862-16-11
8	TOP ENGINE MTG R.H. (HONDA)	1	862-16-12
9	ENGINE TOP MTG PLATE L.H.	1	85B-16-26 } }
10	ENGINE TOP MTG PLATE R.H.	1	85B-16-27 } }
11	TOP ENG MTG INNER STUD (HONDA)	2	842-16-47 ✓
12	TOP ENG MTG OUTER STUD (HONDA)	2	842-16-48 ✓
13	TOP ENG MTG LOWER STUD (HONDA)	2	842-16-49 ✓
14	LOWER ENG BEAM (HONDA)	1	862-16-32
15	LOWER ENG MTG (HONDA)	1	862-16-15
16	LOWER ENG MTG STUD (HONDA)	2	862-16-31
17	LOWER ENG BEAM STUD (HONDA)	2	862-16-45
18	ADAPTOR PLATE 6.28.9 (HONDA)	1	862-16-14
19	ADAPTOR PLATE 6.28.12 (YAM)	1	862-16-02
20	ENG/ADAP TOP STUD (HONDA)	2	822-16-75
21	ENG/ADP MED UPPER STUD (HONDA)	2	822-16-76
22	ENG/OIL TANK LOW STUD (HONDA)	2	832-16-12 ✓
23	SIDEPLATE THROUGH BOLT	2	802-16-05
24	TANK/ADP MED UP RH STUD HONDA	1	832-16-19 ✓

MARCH ENGINEERING LTD.  
 B&B KIT LIST.  
 ENGINE INSTALLATION (CON. T) .

	Description	No.	Part Number
25	ADAPTOR PLATE/GEARBOX DOWEL	2	832-20-08
26	START SHAFT MTG PLATE (HONDA)	1	822-16-64
27	STARTER SHAFT MTG BUSH (HONDA)	1	822-16-65
28	TOP CHASSIS MTG (YAMAHA)	2	862-16-18
29	TOP ENG PLATE R.H. (YAMAHA)	1	862-16-17
30	TOP ENG PLATE L.H. (YAMAHA)	1	862-16-16
31	TOP MTG PLATE/TUB STUD (YAM)	10	862-23-02
32	FRONT LOWER ENG MTG (YAMAHA)	1	862-16-19
33	LOWER ENG MTG STUD (YAMAHA)	2	862-16-29
34	ENG/ADAPT PLATE STUD (YAMAHA)	10	862-16-30
35	ENG/ADAPT PLATE STUD (YAMAHA)	2	862-16-34
36	WATER HEAD OUTLET FLANGE	1	862-13-03
37	1/4 BSP X -6 ADAPTOR	1	75B-15-12
38	EXHAUST SYSTEM (HONDA)	1	862-16-46
39	EXHAUST SYSTEM (YAMAHA)	1	862-16-47
40	EXHAUST BRK (HONDA)	2	862-16-43
41	EXHAUST BRK (YAMAHA)	2	862-16-48
42	SILENT BLOCK BUSH	2	8-13-1
43	EXHAUST MTG BUSH INSERT	4	803-05-02
44	CLIP 80-100	4	25-2-2

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 GEAR LINKAGE.

	Description	No.	Part Number
1	GEAR LEVER	1	842-11-04 ✓
2	GEAR LEVER KNOB	1	842-11-05 ✓
3	GEAR LEVER PIVOT	2	712-11-10
4	GEAR LEVER HSG.	1	860-11-01
5	BUSH (PHOSPHOR BRONZE)	2	850-11-18
6	GEARSHIFT ANCHOR ROD	1	842-11-07 ✓
7	MTG. BOLT G/ANCHOR ROD	1	850-11-02
8	JOINT < ABTB-1 > RAC 8	1	15-2-14
9	GEAR ROD/STEERING RACK BALL	1	842-01-52 /
10	FRONT GEAR ROD	1	868-11-01
11	MIDDLE GEAR ROD	1	862-11-01
12	REAR GEAR ROD	1	862-11-02
13	GEAR ROD REAR MTG	1	862-03-19
14	GEAR ROD JOINT RB3205L	1	15-5-4
15	JOINT CIRCLIP RTT100	1	23-5-2
16	GEAR ROD APEX JOINT 1/2" I.D.	1	832-11-09 ✓
17	GEAR ROD APEX JOINT 5/8" I.D.	2	832-11-08 ✓

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 OIL SYSTEM.

	Description	No.	Part Number
1	OIL TANK - BMW 6.16.15	1	862-14-01
2	OIL TANK - HONDA 6.16.15	1	862-14-02
3	OIL TANK - YAMAHA 6.16.15	1	862-14-04
4	OIL TANK FILLER TUBE - BMW	1	862-14-11
5	OIL TANK FILLER TUBE - HONDA	1	862-14-10
6	OIL TANK FILLER TUBE - YAMAHA	1	842-14-06
7	OIL TOWER TOP 'O'RING BS643	1	33-3-7
8	TANK FILLER CAP	1	722-18-11
9	'O' RING BS 224	1	33-4-1
10	OIL TANK RH BLANKING PLUG	1	822-14-19
11	OIL TANK FILTER HSG. - HONDA	1	862-14-05
12	OIL TANK FILTER HSG. - YAMAHA	1	822-14-07
13	OIL TANK FILTER GAUZE	1	822-14-05
14	'O'RING BS126	2	33-1-6
15	OIL TANK OUTLET FLANGE-YAMAHA	1	862-14-18
16	OIL TANK CORE PLUG 1" OD	4	8-24-6
17	1 5/16" CORE PLUG	1	8-31-15
18	OIL TANK CORE PLUG 1 3/8" OD	1	8-32-1
19	BENDIX SHAFT BUSH LO 710	1	8-27-11
20	RLWB FRONT JOINT UPPER INSERT	2	842-03-13
21	RLWB FRONT JOINT LOWER BUSH	2	842-03-14
22	NOSE PIECE - HONDA	1	822-16-61
23	NOSE PIECE - YAMAHA	1	862-16-28
24	ANTI-ROTATION PIN	2	826-16-21

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 OIL SYSTEM (CON, T) .

	Description	No.	Part Number
25	O-RING BS125	2	33-4-3
26	DUMMY NOSE PIECE - YAMAHA	1	862-14-03
27	REMOTE CLUTCH HOUSING	1	850-16-18
28	CLUTCH PISTON 7.1/2 (HONDA)	1	822-16-62
29	CLUTCH PISTON 5.1/2 (HONDA)	1	822-16-63
30	CLUTCH PISTON	1	850-16-19
31	CLUTCH PISTON SEAL (SMALL)	1	8-24-5
32	CLUTCH PISTON SEAL (LARGE)	1	8-24-3
33	CLUTCH RELEASE BEARING	1	18-5-8
34	OIL TANK/GEARBOX STUD	2	822-16-10
35	OIL TANK/G. BOX MID UPPER STUD	2	802-16-19
36	OIL TANK/LOWER DAMPER MTG. STUD	2	822-16-11
37	OIL DRAIN PLUG	2	862-14-15
38	OIL LEVEL BANJO	2	862-14-12
39	OIL LEVEL BANJO BOLT	2	862-14-14
40	OIL TANK/ENG. ALLOY PIPE-YAMAHA	1	862-14-19
41	OIL COLLER 44 RDW	1	862-14-06
42	OIL COOLER MTG. LOWER - YAMAHA	1	862-14-08
43	OIL COOLER MTG. LOWER - HONDA	1	862-14-17
44	OIL COOLER MTG UPPER	1	862-14-07
45	AVIMO RUBBER COUPLING	4	8-37-9
46	AVIMO RUBBER COUPLING CLAMP	8	8-37-10

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 FUEL SYSTEM.

	Description	No.	Part Number
1	FUEL TANK	1	86B-15-01
2	FUEL TANK BOLT RING 6.20.12	1	832-15-04 ✓
3	FUEL COLLECTOR POT	1	832-15-03 ✓
4	CAV FUEL FILTER	1	8-31-13
5	CAV FUEL FILTER TOP	1	832-15-05 ✓
6	'O' RING BS108	1	33-4-9
7	FUEL PUMP INLET ADAPTOR	1	792-15-18
8	9/16 ID DOWTY SEAL	1	20-3-3
9	ELECTRIC FUEL PUMP	1	8-16-8
10	FUEL PUMP BRK	1	832-15-07 ✓
11	MOUNTING CLIP (40-60)	1	25-2-4
12	FUEL PUMP DUTLET ADAPTOR	1	782-15-05
13	FUEL PIPE BANJO BOLT	1	812-15-01
14	FUEL FILLER NECK/RETURN BLOCK	1	812-15-04
15	'O' RING BS141	1	33-4-8
16	FUEL TANK TOP PANEL	1	842-01-78 ✓
17	FUEL TANK TOP SEAL	1	832-15-11 ✓
18	TANK FILLER CAP	1	722-18-11
19	'O' RING BS 224	1	33-4-1
20	1/8" B.S.P. STR STEM (S101)	1	8-5-12
21	1/8" B.S.P. LARGE NUT (104459)	1	8-22-4
22	1/8" BSP NYLON PIPE (Per foot)	1	8-8-5
23	1/8" B.S.P. BANJO (46462)	1	8-26-2
24	7/16" ID DOWTY SEAL	2	20-3-7

MARCH ENGINEERING LTD.  
B&2 KIT LIST.  
FUEL SYSTEM (CON, T) .

	Description	No.	Part Number
25	1/8" BSP NYLON PIPE (Per foot)	1	8-8-5
26	FUEL BREATHER VALVE TOP	1	802-15-07
27	FUEL BREATHER VALVE BOTTOM	1	802-15-06
28	FUEL BREATHER VALVE BALL	1	8-4-13
29	T PIECE/FUEL SENDER UNIT ADPT.	1	832-15-09 ✓
30	FUEL SENDER UNIT BODY	1	802-15-02
31	FUEL SENDER PISTON	1	822-15-03
32	O-RING BS011	1	33-4-4
33	FUEL TANK WIRE SEALING UNION	2	832-15-13 ✓
34	FUEL TANK WIRE SEALING CAP	2	832-15-14 ✓
35	O-RING BS004	2	33-4-11
36	FUEL SENDER UNIT TOP	1	802-15-03

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 WATER SYSTEM.

	Description	No.	Part Number
1	WATER RADIATOR	1	862-13-01
2	HEADER TANK	1	86B-13-07
3	HEADER TANK CAP	1	8-6-11
4	HEADER TANK OVERFLOW PIPE	1	8-12-8
5	MOUNTING GROMMET	2	8-15-12
6	MOUNTING GROMMET SPACER	2	8-20-7
7	WATER RAD SCREEN	2	862-13-04
8	ENGINE OUTLET PIPE	1	862-13-05
9	SWIRL FOT	1	862-13-06
10	WATER RAIL L.H.	1	862-13-07
11	WATER RAIL R.H.	1	862-13-08
12	FRONT CROSS OVER PIPE	1	862-13-09
13	1.1/4" ID WATER RAIL HOSE	1	10-3-7
14	HOSE CLIP (25-40)	12	25-2-8
15	1/8" B.S.P. NYLON PIPE	1	10-4-6
16	1/8" B.S.P. NYLON PIPE CLIP	6	23-4-8
17	1/8" B.S.P. 90 DEG UNION	2	76B-13-08
18	1/8" B.S.P. LARGE NUT (104459)	3	8-22-4
19	1/8" B.S.P. STR STEM (S101)	3	8-5-12
20	1/8" B.S.P. SMALL NUT (F101)	0	8-44-2
21	BANJO BOLT (SHORT 20MM) 775-3P	1	21-12-12
22	3/8" ID DOWTY SEAL	4	20-3-1
23	1/8" B.S.P. BANJO (46462)	1	8-26-2
24	-8 AERQUIP HOSE	1	21-2-10

Section Number: 13 Page Number: 2 Date: 10/07/86

MARCH ENGINEERING LTD.  
B&B KIT LIST.  
WATER SYSTEM (CON, T) .

	Description	No.	Part Number
25	-8 STR AEROQUIP UNION	2	21-1-10

MARCH ENGINEERING LTD.  
 B&B KIT LIST.  
 DASH FIRE & ELECT..

	Description	No.	Part Number
1	DASH PANEL	1	85B-01-58
2	DASH PANEL SPACER	1	85C-12-81
3	RUBBER MTG BUSH	4	8-20-4
4	FIRE NOZZLE	1	826-01-127
5	FIRE NOZZLE LOCK NUT	1	826-01-128
6	ENGINE BAY FIRE NOZZLE	1	842-22-01 /
7	0-12000 TACHOMETER	1	34-2-7
8	DUAL GAUGE 8 FT PT1612 BB	2	34-3-9
9	BATTERY (RED TOP VARLEY)	1	9-20-1
10	BATTERY BOX (HONDA)	1	862-28-01
11	BATTERY BRKT.TOP	1	86A-28-02
12	BATTERY	1	9-10-13
13	BATTERY MTG BRK	1	85B-01-70
14	COIL MOUNTING - YAMAHA	1	862-16-37
15	WIRING LOOM	1	9-19-1
16	COSWORTH DIODE DAG264	1	9-10-14
17	COSWORTH DIODE MTG	1	83C-28-03
18	MASTER SWITCH 8825-B140/268446	2	9-11-4
19	TOGGLE SWITCH	3	9-1-12
20	BUTTON SWITCH	2	9-1-2
21	REAR LIGHT	1	9-9-7
22	REAR LIGHT BULB 12V	1	9-14-3
23	OIL PRESS.SWITCH WS14 40-60LB	1	9-19-9
24	ORANGE LIGHT	1	9-9-6

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 DASH FIRE & ELECT. (CON, T) .

	Description	No.	Part Number
25	FIRE POWER PACK	1	29-1-6
26	BOWDEN INNER CABLE	1	8-2-2
27	FIRE PULL CABLE RED SLEEVE	1	8-18-13
28	BOWDEN CABLE NIPPLE	1	8-43-6
29	MASTER SWITCH BRKT.	1	822-01-91
30	MOUNTING GROMMET	2	8-15-12
31	MOUNTING GROMMET SPACER	2	8-20-7
32	SPARK BOX PLUG 7 PIN (LUCAS)	1	9-18-3
33	JUMP PLUG SOCKET	1	9-5-12
34	JUMP PLUG	1	9-5-13
35	2 WAY TAB HOUSING	4	9-2-15
36	FIRE POWER PACK PLUG 478-150	4	29-4-9
37	FIRE POWER PACK PLUG 478-150	4	9-11-2
38	SINGLE TERMINAL HOUSING MALE	1	9-7-11
39	SINGLE TERMINAL HOUSING FEMALE	1	9-7-12
40	16 GAUGE RACHEM WIRE Per foot	40	9-18-10
41	18 GAUGE RACHEM WIRE Per foot	60	9-18-7
42	22 GAUGE RACHEM WIRE Per foot	40	9-18-9
43	FUEL PUMP ELECT WIRE KPL50/16	10	9-11-3

MARCH ENGINEERING LTD.  
B&Z KIT LIST.  
HYDRAULICS.

	Description	No.	Part Number
1	Ø.75" DIA MASTER CYLINDER	1	7-3-14
2	MASTER CYLINDER RESERVOIR	1	7-3-13
3	7/16" ID DOWTY SEAL	1	20-3-7
4	MASTER CYLINDER DIAPHRAGM	1	7-7-12
5	MASTER CYL PUSH ROD 3.25"	1	7-1-7
6	BRAKE MASTER CYLINDER RUBBER	1	7-2-7
7	ANTI-KNOCK OFF VALVE	1	8-23-11
8	3/8" ID COPPER WASHER	1	20-2-14
9	DOUBLE BANJO 979-03P	1	21-12-4
10	BANJO BOLT 775-3P	1	81-12-3
11	7/16" ID COPPER WASHER	1	20-4-3
12	3/8" ID COPPER WASHER	1	20-2-14
13	* FRONT M/CYL ASSEMBLY	1	
14	-3 STR AERODQUIP UNION	2	21-1-1
15	-3 AERODQUIP HOSE	6	21-2-7
16	-3 X 90 DEG AERODQUIP UNION	2	21-1-3
17	1/8 BSP X 3/8"UNF ADAPTOR	2	732-06-18
18	3/8" COPPER WASHER	2	20-2-13
19	CALIPER RH (ALCON)	2	7-16-14
20	CALIPER LH (ALCON)	2	7-16-15
21	ALCON BRAKE PAD M171	8	7-17-13
22	ALCON BRAKE PAD D511 (STD)	8	7-17-14
23	CALIPAR MTG BOLT	8	12-29-3
24	Ø.75" DIA MASTER CYLINDER	1	7-3-14

MARCH ENGINEERING LTD.  
 B&2 KIT LIST.  
 HYDRAULICS (CON. T) .

	Description	No.	Part Number
25	MASTER CYLINDER RESERVOIR	1	7-3-13
26	7/16" ID DOWTY SEAL	1	20-3-7
27	MASTER CYLINDER DIAPHRAGM	1	7-7-12
28	MASTER CYL PUSH ROD 3.25"	1	7-1-7
29	BRAKE MASTER CYLINDER RUBBER	1	7-2-7
30	ANTI-KNOCK OFF VALVE	1	8-23-11
31	3/8" ID COPPER WASHER	1	20-2-14
32	* REAR M/CYL ASSEMBLY	1	
33	1/8 BSP X 3/8"UNF ADAPTOR	2	732-06-18
34	3/8" COPPER WASHER	1	20-2-13
35	-3 X 90 DEG AERDQUIP UNION	1	21-1-3
36	-3 AERDQUIP HOSE	10	21-2-7
37	1/8 BSP 'T' PEICE	1	7-8-13
38	-3 STR AERDQUIP UNION	3	21-1-1
39	-3 AERDQUIP HOSE	10	21-2-7
40	-3 X 90 DEG AERDQUIP UNION	2	21-1-3
41	1/8 BSP X 3/8"UNF ADAPTOR	2	732-06-18
42	3/8" COPPER WASHER	2	20-2-13
43	Ø.75 MASTER CYL.C/W RESERVOIR	1	7-9-9
44	MASTER CYLINDER EXTENSION	1	7-9-10
45	BRAKE MASTER CYLINDER RUBBER	1	7-2-7
46	1/8 BSP X 3/8"UNF ADAPTOR	1	732-06-18
47	* CLUTCH M/CYL ASSEMBLY	1	
48	-3 X 45 DEG AERDQUIP UNION	1	21-1-2

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 HYDRAULICS (CON, T) .

	Description	No.	Part Number
49	-3 X 90 DEG AERDQUIP UNION	1	21-1-3
50	CLUTCH FEED INLET ADAPTOR	2	822-25-01
51	O RING BS110	2	33-5-4
52	CLUTCH FEED BUNDY PIPE 1/4" OD	2	7-3-1
53	BUNDY PIPE 7/16" UNF MALE FTG.	2	7-8-7
54	-3 AERDQUIP HOSE	2	21-2-7
55	-3 X 90 DEG AERDQUIP UNION	1	21-1-3
56	-3 STR AERDQUIP UNION	1	21-1-1
57	CLUTCH BLEED HOUSING	1	802-25-01
58	1/8" BSP LOCK NUT	1	13-5-8
59	CLUTCH BLEED NIPPLE	1	8-24-14
60	CLUTCH BLEED BRK	1	842-25-01 /
61	MASTER CYL MTG STUD	6	85B-23-24

MARCH ENGINEERING LTD.  
 B&B KIT LIST.  
 BODYWORK.

	Description	No.	Part Number
1	UNDERTRAY	1	85B-12-53-
2	NOSE (PRE-PREG)	1	86B-12-18
3	NOSE (PRE-PREG)	1	86B-12-42
4	DAMPER COVER PANEL	1	11-23-7
5	SIDE PANEL L.H.	1	11-23-5
6	SIDE PANEL R.H.	1	11-23-4
7	INLET DUCT L.H.	1	11-23-9
8	INLET DUCT R.H.	1	11-23-10
9	OIL COOLER DUCT	1	11-23-11
10	ENGINE COVER	2	11-23-6
11	MONOCOQUE RUBBING STRIP	1	85B-01-66 ,
12	FRONT BODY STRUT (WATER SIDE)	1	862-12-15
13	FRONT BODY STRUT (OIL SIDE)	1	862-12-16
14	FRONT STRUT TOP BRK	2	85B-12-81
15	FRONT/MED LOWER STRUT BRK	4	85B-12-84
16	MID BODY STRUT (HONDA)	2	862-12-30
17	MID BODY STRUT (YAMAHA)	2	862-12-19
18	REAR BODY STRUT	2	86B-12-71
19	REAR STRUT TOP CLEVIS	1	85B-12-89
20	REAR STRUT LOWER BRK	2	85B-12-82
21	REAR STRUT LOWER BRK STRAP	2	85B-12-145
22	ROSE JOINT RMP4U	4	15-1-1
23	ROSE JOINT RMLP4U	6	15-8-14
24	BODY STRUT JOINT INSERT	20	85B-19-01

MARCH ENGINEERING LTD.  
 862 KIT LIST.  
 BODYWORK (CON, T) .

	Description	No.	Part Number
25	UNDERTRAY C/SUNK WASHER 3/16"	45	832-12-22 ✓
26	ENGINE COVER FRONT BRKT.	2	86B-12-80
27	ENGINE COVER REAR BRK	2	862-12-20
28	NOSE MTG STUD	4	85B-23-15
29	NOSE MTG STUD	8	85B-23-16
30	MIRROR BODY	2	842-12-18 ✓
31	MIRROR REFLECTOR MTG	2	842-12-19 ✓
32	MIRROR MTG BOSS	2	82C-12-08
33	MIRROR STEM	2	82C-12-26
34	MIRROR GLASS	2	11-20-2
35	RMF4U MIRROR MTG JOINT	2	782-12-25
36	MIRROR GLASS RETAINER	4	86B-12-79
37	MOUNTING WASHER	4	792-12-08
38	* MIRROR ASSEMBLY	1	
39	CAM LOCK 9	3	11-20-11
40	CAM LOCK 11	2	11-20-12
41	CAM LOCK 13	1	11-20-13
42	CAM LOCK FASTENER	6	11-20-14

MARCH ENGINEERING LTD.  
 B62 KIT LIST.  
 WINGS.

	Description	No.	Part Number
1	FIRE FLY FRONT WING 12" RH	1	86B-12-12
2	FIRE FLY FRONT WING 12" LH	1	86B-12-11
3	FIRE FLY FRONT WING FLAP RH	1	86B-12-38
4	FIRE FLY FRONT WING FLAP LH	1	86B-12-37
5	FIRE FLY 12" END PLATE	2	85B-12-14
6	FRONT WING PIVOT BLOCK 6.15.2	2	85B-12-49
7	FRONT WING PIVOT TUBE	1	86B-12-87
8	FRONT WING ADJUSTER SCREW	1	85C-12-28 ✓
9	BARREL NUT F/WING ADJUSTER	1	85C-12-26 ✓
10	FRONT WING ADJUSTER SOCKET	1	85C-12-27 ✓
11	JOINT ABWT4	1	15-8-10
12	CIRCLIP 1308-62	1	23-8-6
13	FRONT WING MTG. BLOCK SPACER	2	86B-12-20
14	FRONT WING ADJUSTMENT BLOCK	1	86B-12-21
15	REAR WING MAINPLANE (CARBON)	1	822-12-22
16	REAR WING REAR FLAP	1	862-12-12
17	REAR WING END PLATE	2	862-12-13
18	REAR WING PILLAR (HONEYCOMB)	1	862-12-09
19	WING PILLAR SANDWICH PLATE	2	822-12-13
20	WING PILLAR MTG. PLATE	2	862-12-11
21	WING PILLAR MTG BUSH	2	842-12-01 ✓
22	WING PILLAR SILENTBLOCK BUSH	4	8-13-2
23	W/PILLAR SILENT BLOCK SPACER	2	842-12-03 ✓
24	W/PILLAR MTG PLATE INSERT	4	802-12-11

MARCH ENGINEERING LTD.  
862 KIT LIST.  
WINGS (CON. T).

	Description	No.	Part Number
25	W/PILLAR MTG PLATE WASHER	8	802-20-28
26	BOLT NAS 1304-20	2	12-33-12
27	REAR LIGHT BRK	1	842-12-04 ✓
28	RUBBER MTG BUSH	2	8-20-4
29	4.1/2" X 1/4" UNF HEX BOLT	1	12-19-9
30	AIR DEFLECTOR PLATE	4	862-12-07
31	AIR DEFLECTOR	6	862-12-06

MARCH ENGINEERING LTD.  
862 KIT LIST.  
AIR STARTER.

	Description	No.	Part Number
1	AIR MOTOR SRBM-Z-3000	1	8-45-7
2	AIR MOTOR MTG.- YAMAHA	1	862-24-01
3	AIR MOTOR INLET ADAPTOR	1	85B-24-03
4	BENDIX SHAFT	1	85B-16-20
5	9T.PINION (LUCAS 54244242)	1	8-27-12
6	PINION HOUSING	1	822-16-40
7	PINION LINER BUSH	1	822-16-56
8	BENDIX SPRING RETAINER	1	822-16-58
9	BENDIX HELIX LUCAS 54243006	1	8-42-6
10	BENDIX SLEEVE LUCAS 54243006	1	8-42-7
11	BENDIX SPRING LUCAS 54258243	1	8-27-15
12	PINION SPRING LUCAS 54258243	1	8-28-1
13	THRUST WASHER LUCAS 54258243	1	8-28-2
14	SHAFT CIRCLIP LUCAS 54258243	1	8-28-3
15	PINION BODY CIRCLIP M2300 0400	1	8-28-4
16	AIR BOTTLE MTG BRK	1	85B-24-06
17	AIR BOTTLE BRACKET CLIP	2	25-2-3
18	AIR BOTTLE (LUXFER P23700)	1	29-4-13
19	AIR BOTTLE/VALVE ADAPTOR	1	85B-24-01
20	VITON 'O' RING BS 019	1	33-1-12
21	AIR BOTTLE VALVE S.V.121K04	1	8-28-6
22	AIR BOTTLE COIL S.V.42706265	1	8-28-7
23	AIR VALVE OUTLET ADAPTOR	1	822-24-14
24	-3 X 90 DEG AEROGUIP UNION	1	21-1-3

MARCH ENGINEERING LTD.  
662 KIT LIST.  
AIR STARTER (CON., T) ..

	Description	No.	Part Number
25	-3 AERQUIP HOSE	3	21-2-7
26	-3 X 90 DEG AERQUIP UNION	1	21-1-3
27	AIR SUPPLY VALVE 89368W	1	8-28-8
28	AIR SUPPLY VALVE ADP. 2063.6-8	3	8-28-9
29	-8 STR AERQUIP UNION	1	21-1-10
30	-8 AERQUIP HOSE	2	21-2-10
31	-8 STR AERQUIP UNION	1	21-1-10
32	AIR SUPPLY SOCKET B5601-6-6	1	8-28-10
33	AIR SUPPLY PLUG B5602-6-6	1	8-28-12
34	AIR SUPPLY PLUG ADP. 2063.6-6	1	8-28-11
35	-6 X 45 DEG AERQUIP UNION	1	21-1-8
36	-6 AERQUIP HOSE	3	21-2-9
37	-6 X 90 DEG AERQUIP UNION	1	21-1-9